

WTI Part No. 14102  
Rev. K

# **VMR Series**

Managed Power Controllers

# **NPS Series**

Network Power Switches

## **User's Guide**



Power & Console Solutions | [wti.com](http://wti.com)



## Warnings and Cautions: Installation Instructions



### Secure Racking

If Secure Racked units are installed in a closed or multi-unit rack assembly, they may require further evaluation by Certification Agencies. The following items must be considered.

1. The ambient within the rack may be greater than room ambient. Installation should be such that the amount of air flow required for safe operation is not compromised. The maximum temperature for the equipment in this environment is 55°C. Consideration should be given to the maximum rated ambient.
2. Installation should be such that a hazardous stability condition is not achieved due to uneven loading.
3. Side vents are used to dissipate heat generated within the unit. When mounting the unit in an equipment rack, make certain to allow adequate clearance for venting.

### Input Supply

Check nameplate ratings to assure there is no overloading of supply circuits that could have an effect on overcurrent protection and supply wiring.

### Grounding

Reliable earthing of this equipment must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than direct connections to the branch circuit.

### No Serviceable Parts Inside; Authorized Service Personnel Only

Do not attempt to repair or service this device yourself. Internal components must be serviced by authorized personnel only.

- **Shock Hazard - Do Not Enter**
- **Lithium Battery**  
**CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.**

## Disconnect Power

If any of the following events are noted, immediately disconnect the unit from the outlet and contact qualified service personnel:

1. If the power cord becomes frayed or damaged.
2. If liquid has been spilled into the device or if the device has been exposed to rain or water.

## Up to Four Power Supply Cables



Note that some VMR/NPS series units feature two separate power inlets and a separate power supply cable for each power inlet.

In addition, some VMR-HD4D-8 series units feature four separate power inlets and a separate power supply cable for each power inlet. Make certain to disconnect all power supply cables from their power source before attempting to service or remove the unit.

## Detached 15-Amp "Starter" Cable(s)

If the VMR or NPS unit includes a detached, 125 VAC, 15 Amp "Starter" Cable(s), this allows you to connect the VMR or NPS to power for bench testing and initial start up and is adequate for applications that only require 15 Amps. For 20-Amp power switching applications, please refer to the WTI Power Cable guide supplied with the unit, or use appropriate 20-Amp cables.

## Units with Attached Power Supply Cable(s)

For units with fixed Power Cords the socket-outlet shall be installed near the equipment and shall be easily accessible.

## Restricted Access Location

Equipment is intended for installation in Restricted Access Location.

Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.

# Agency Approvals

## FCC Part 15 Regulation

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into an outlet on a circuit that is different from the one used by the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation of this device is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may cause undesired operation.

***WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment***

## EMC, Safety, and R&TTE Directive Compliance

The CE mark is affixed to this product to confirm compliance with the following European Community Directives:

- **Council Directive 2014/30/EU of 26 February 2014 on the approximation of the laws of Member States relating to electromagnetic compatibility;**  
**and**
- **Council Directive 2014/35/EC of 26 February 2014 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits.**

## Industry Canada - EMI Information

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

# Table of Contents

<b>1. Introduction</b> .....	<b>1-1</b>
<b>2. Unit Description</b> .....	<b>2-1</b>
2.1. VMR Standard Series - Front Panel .....	2-1
2.2. VMR Standard Series - Back Panel .....	2-2
2.3. VMR-HD4D Series - Front Panel .....	2-3
2.4. VMR-HD4D Series - Back Panel .....	2-4
2.5. VMR-HD4D-8 Series - Front Panel .....	2-5
2.6. VMR-HD4D-8 Series - Back Panel .....	2-6
2.7. VMR-12B Series - Front Panel .....	2-7
2.8. VMR-12B Series - Back Panel .....	2-8
2.9. NPS Series - Front Panel .....	2-9
2.10. NPS Series - Back Panel .....	2-10
2.11. Additional Button Functions .....	2-11
<b>3. Getting Started</b> .....	<b>3-1</b>
3.1. Installing the VMR or NPS Hardware .....	3-1
3.1.1. Apply Power to the VMR or NPS .....	3-1
3.1.2. Connect your PC to the VMR or NPS .....	3-1
3.2. Communicating with the VMR or NPS .....	3-2
3.3. The WMU Enterprise Management Solution .....	3-4
<b>4. Hardware Installation</b> .....	<b>4-1</b>
4.1. Connecting the Power Supply Cables .....	4-1
4.1.1. Installing the Power Supply Cable Keepers .....	4-1
4.1.2. Connect the VMR or NPS to Your Power Supply .....	4-2
4.2. Connection to Switched Outlets .....	4-2
4.3. Serial SetUp Port Connection .....	4-2
4.3.1. Connecting a Local PC .....	4-2
4.3.2. Connecting an External Modem .....	4-2
4.4. Connecting the Network Cable .....	4-3
4.5. Rack Mounting .....	4-3
4.6. Emergency Shut Off Function .....	4-3
<b>5. Basic Operation</b> .....	<b>5-1</b>
5.1. Communicating with the VMR/NPS Unit .....	5-1
5.1.1. The Text Interface .....	5-1
5.1.2. The Web Browser Interface .....	5-3
5.1.3. The WMU Enterprise Management Solution .....	5-3
5.2. Controlling Power - Web Browser Interface .....	5-4
5.2.1. The Plug Control Screen - Web Browser Interface .....	5-4
5.2.2. The Plug Group Control Screen - Web Browser Interface .....	5-5
5.3. Controlling Power - Text Interface .....	5-6
5.3.1. The Port and Plug Status Screen - Text Interface .....	5-6
5.3.2. Switching and Reboot Commands - Text Interface .....	5-7
5.3.2.1. Applying Commands to Several Plugs - Text Interface .....	5-9
5.4. The Automated Mode .....	5-10
5.5. Manual Operation .....	5-11
5.6. Logging Out of Command Mode .....	5-11
5.7. Emergency Shut Off Function .....	5-11

<b>6.</b>	<b>Configuration Options</b>	<b>6-1</b>
6.1.	Configuration Menus	6-1
6.2.	Defining System Parameters	6-2
6.2.1.	The Real Time Clock and Calendar	6-5
6.2.2.	The Invalid Access Lockout Feature	6-7
6.2.3.	Log Configuration	6-10
6.2.3.1.	Audit Log and Alarm Log Configuration Options	6-10
6.2.3.2.	The Temperature Log (NPS Units Only)	6-11
6.2.3.3.	Reading, Downloading and Erasing Logs	6-11
6.2.3.4.	Current Metering Log Display Options (VMR Only)	6-12
6.2.3.5.	Power Metering Log Display Options (VMR Only)	6-12
6.2.4.	Callback Security	6-13
6.2.5.	Power Source Configuration (VMR Only)	6-14
6.2.6.	Scripting Options	6-15
6.2.6.1.	Automated Mode	6-17
6.3.	User Accounts	6-19
6.3.1.	Command Access Levels	6-19
6.3.2.	Granting Plug Access	6-20
6.3.3.	Granting Port Access	6-20
6.4.	Managing User Accounts	6-21
6.4.1.	Viewing User Accounts	6-21
6.4.2.	Adding User Accounts	6-21
6.4.3.	Modifying User Accounts	6-24
6.4.4.	Deleting User Accounts	6-24
6.5.	The Plug Group Directory	6-25
6.5.1.	Viewing Plug Groups	6-25
6.5.2.	Adding Plug Groups	6-26
6.5.3.	Modifying Plug Groups	6-26
6.5.4.	Deleting Plug Groups	6-26
6.6.	Defining Plug Parameters	6-27
6.6.1.	The Boot Priority Parameter	6-28
6.6.1.1.	Example 1: Change Plug A3 to Priority 1	6-28
6.6.1.2.	Example 2: Change Plug A5 to Priority 2	6-29
6.7.	Serial Port Configuration	6-30
6.7.1.	The Serial Port Configuration Menu	6-30
6.8.	Network Configuration	6-34
6.8.1.	Network Port Parameters	6-36
6.8.2.	IP Tables	6-42
6.8.3.	Static Route	6-42
6.8.4.	DNS Services	6-42
6.8.4.1.	DNS Parameters	6-42
6.8.4.2.	DDNS Parameters	6-43
6.8.5.	SNMP Access Parameters	6-43
6.8.6.	SNMP Trap Parameters	6-45
6.8.7.	LDAP Parameters	6-46
6.8.7.1.	Adding LDAP Groups	6-48
6.8.7.2.	Viewing LDAP Groups	6-48
6.8.7.3.	Modifying LDAP Groups	6-49
6.8.7.4.	Deleting LDAP Groups	6-49
6.8.8.	TACACS Parameters	6-50
6.8.9.	RADIUS Parameters	6-53
6.8.9.1.	Dictionary Support for RADIUS	6-54
6.8.10.	Email Messaging Parameters	6-56
6.9.	Save User Selected Parameters	6-57
6.9.1.	Restore Configuration	6-57

---

<b>7. Reboot Options</b> .....	<b>7-1</b>
7.1. Ping-No-Answer Reboot .....	7-2
7.1.1. Adding Ping-No-Answer Reboots .....	7-2
7.1.2. Viewing Ping-No-Answer Reboot Profiles .....	7-4
7.1.3. Modifying Ping-No-Answer Reboot Profiles .....	7-4
7.1.4. Deleting Ping-No-Answer Reboot Profiles .....	7-4
7.2. Scheduled Reboot .....	7-5
7.2.1. Adding Scheduled Reboots .....	7-5
7.2.2. Viewing Scheduled Reboot Actions .....	7-6
7.2.3. Modifying Scheduled Reboots .....	7-6
7.2.4. Deleting Scheduled Reboots .....	7-6
<b>8. Alarm Configuration</b> .....	<b>8-1</b>
8.1. The Over Current Alarms (VMR Only) .....	8-2
8.1.1. Over Current Alarms - Load Shedding and Auto Recovery .....	8-4
8.2. The Over Temperature Alarms .....	8-6
8.2.1. Over Temperature Alarms - Load Shedding and Auto Recovery .....	8-8
8.3. The Circuit Breaker Open Alarm .....	8-9
8.4. The Lost Voltage (Line In) Alarm .....	8-11
8.5. The Ping-No-Answer Alarm .....	8-12
8.6. The Serial Port Invalid Access Lockout Alarm .....	8-14
8.7. The Power Cycle Alarm .....	8-16
8.8. The Plug Current Alarm (VMR Only) .....	8-17
8.9. The Emergency Shutoff Alarm .....	8-20
8.10. The No Dialtone Alarm .....	8-22
<b>9. The Status Screens</b> .....	<b>9-1</b>
9.1. Product Status .....	9-1
9.2. The Network Status Screen .....	9-1
9.3. The Plug Status Screen .....	9-2
9.4. The Plug Group Status Screen .....	9-3
9.5. The Current Metering Status Screen .....	9-4
9.6. The Current History Screen (VMR Only) .....	9-5
9.7. The Power Range Status Screen (VMR Only) .....	9-6
9.8. The Power History Screen (VMR Only) .....	9-7
9.9. The Port Diagnostics Screen .....	9-8
9.10. Alias Status Screen .....	9-8
9.11. The Alarm Status Screen .....	9-8
9.12. The Serial Port Parameters Screen .....	9-8
9.13. The Event Logs .....	9-9
9.13.1. The Audit Log .....	9-9
9.13.2. The Alarm Log .....	9-9
<b>10. SSH Encryption</b> .....	<b>10-1</b>
<b>11. Syslog Messages</b> .....	<b>11-1</b>
11.1. Configuration .....	11-1
<b>12. SNMP Traps</b> .....	<b>12-1</b>
12.1. Configuration .....	12-1

<b>13. Operation via SNMP</b> .....	<b>13-1</b>
13.1. VMR/NPS SNMP Agent .....	13-1
13.2. SNMPv3 Authentication and Encryption .....	13-1
13.3. Configuration via SNMP .....	13-2
13.3.1. Viewing Users .....	13-3
13.3.2. Adding Users .....	13-3
13.3.3. Modifying Users .....	13-3
13.3.4. Deleting Users .....	13-3
13.4. Plug Control via SNMP .....	13-4
13.4.1. Plug Status/Control .....	13-4
13.4.2. Plug Group Status/Control .....	13-5
13.5. Viewing VMR/NPS Status via SNMP .....	13-6
13.5.1. System Status - Ethernet Port Mac Addresses .....	13-6
13.5.2. Plug Status .....	13-6
13.5.3. Unit Environment Status .....	13-6
13.5.4. Alarm Status .....	13-7
13.6. Sending Traps via SNMP .....	13-8
<b>14. Creating Web Certificates</b> .....	<b>14-1</b>
14.1. Creating a Self Signed Certificate .....	14-2
14.2. Creating a Signed Certificate .....	14-3
14.3. Downloading the Server Private Key .....	14-5
14.4. Harden Web Security .....	14-5
14.5. TLS Mode .....	14-5
<b>15. Saving and Restoring Configuration Parameters</b> .....	<b>15-1</b>
15.1. Sending Parameters to a File .....	15-1
15.1.1. Downloading & Saving Parameters via Text Interface .....	15-1
15.1.2. Downloading & Saving Parameters via Web Browser Interface .....	15-2
15.2. Restoring Saved Parameters .....	15-2
15.3. Restoring Previously Saved Parameters .....	15-3
<b>16. Upgrading VMR/NPS Firmware</b> .....	<b>16-1</b>
16.1. WMU Enterprise Management Software (Recommended) .....	16-1
16.2. The Upgrade Firmware Function (Alternate Method) .....	16-1
<b>17. Command Reference Guide</b> .....	<b>17-1</b>
17.1. Command Conventions .....	17-1
17.2. Command Summary .....	17-2
17.3. Command Set .....	17-3
17.3.1. Display Commands .....	17-3
17.3.2. Control Commands .....	17-8
17.3.3. Configuration Commands .....	17-14
 <b>Appendices:</b>	
<b>A. Specifications</b> .....	<b>Apx-1</b>
<b>B. Interface Descriptions</b> .....	<b>Apx-2</b>
B.1. SetUp Port (RS232) .....	Apx-2
<b>C. Customer Service</b> .....	<b>Apx-3</b>



**List of Figures**

2.1.	VMR Standard Series - Front Panel (Model VMR-16HD20-1 Shown) . . . . .	2-1
2.2.	VMR Standard Series - Back Panel (Model VMR-16HD20-1 Shown) . . . . .	2-2
2.3.	VMR-HD4D Series - Front Panel (Model VMR-HD4D32 Shown) . . . . .	2-3
2.4.	VMR-HD4D Series - Back Panel (Model VMR-HD4D32 Shown) . . . . .	2-4
2.5.	VMR-HD4D-8 Series - Front Panel . . . . .	2-5
2.6.	VMR-HD4D-8 Series - Back Panel . . . . .	2-6
2.7.	VMR-12B Series - Front Panel (Model VMR-HD4D32-12B Shown) . . . . .	2-7
2.8.	VMR Series - Back Panel (Model VMR-HD4D32-12B Shown) . . . . .	2-8
2.9.	NPS Series - Front Panel (Model NPS-16HD20-1 Shown) . . . . .	2-9
2.10.	NPS Series - Back Panel (Model NPS-16HD20-1 Shown) . . . . .	2-10
6.1.	Boot Priority Example 1 . . . . .	6-28
6.2.	Boot Priority Example 2 . . . . .	6-29
14.1.	Web Access Parameters (Text Interface Only) . . . . .	14-1
B.1.	RS232 SetUp Port Interface . . . . .	Apx-2

# 1. Introduction

WTI's VMR series Managed Power Controllers and NPS series Network Power Switches allow secure, remote management of AC powered rack mount equipment via SSL, SSH, SNMP, web browser, telnet, external modem or local terminal. Both VMR and NPS series units provide the ability to perform power reboot and power switching functions and automatically notify you when changes in rack temperature, ping command response, invalid access attempts, circuit breaker status and other factors are detected.

In addition to these power management and alarm functions, VMR models also include the ability to monitor power to your equipment, and automatically notify you when changes in current consumption exceed user-defined threshold values. (Note that NPS series models do not support current and power metering functions.)

## **Security and Co-Location Features:**

Secure Shell (SSHv2) encryption and address-specific IP security masks help to prevent unauthorized access to command and configuration functions.

Both the VMR and NPS provide four different levels of security for user accounts: Administrator, SuperUser, User and ViewOnly. The Administrator level provides complete access to all plug functions, operating features and configuration menus. The SuperUser level allows switching and rebooting of all plugs but does not allow access to configuration functions. The User level allows access to only a select group of Administrator-defined plugs. The ViewOnly level allows you to check plug status and unit status, but does not allow switching or rebooting of outlets or access to configuration menus.

The VMR and NPS also include full Radius support, LDAP capability, TACACS capability, MIB capability, DHCP and an invalid access lockout feature. An Audit Log records all user access, login and logout times and command actions.

## **Current and Power Metering (VMR Series Only):**

VMR series units can measure and report current and power consumption trends. If the VMR detects that user defined thresholds for current consumption have been exceeded the unit can provide prompt notification to network administrators and IT personnel. The VMR also records current consumption data to a convenient log file, which can be retrieved in ASCII, XML, or CSV format or displayed in graph format.

## Models Numbers Covered

This user's guide covers both VMR series Managed Power Controllers and NPS series Network Power Switches. When features are available to both VMR and NPS models, this user's guide will refer to the model as VMR/NPS. The text will also note features that are not available on NPS models.

## WTI Management Utility

VMR/NPS units include the WTI Enterprise Management Utility (WMU,) which allows you to manage multiple WTI units via a single menu. For more information on the Enterprise Management Utility, please refer to the WMU User's Guide, which can be downloaded from the WTI web site at: <http://www.wti.com/t-product-manuals.aspx>.

## Typographic Conventions

^ (e.g. ^x)	Indicates a control character. For example, the text " <b>^x</b> " (Control X) indicates <b>[Ctrl]</b> and <b>[X]</b> key must be pressed at the same time.
<b>COURIER FONT</b>	Indicates characters typed on the keyboard. For example, / <b>AC</b> or / <b>ON A2</b> .
<b>[Bold Font]</b>	Text set in bold face and enclosed in square brackets indicates a specific key. For example, <b>[Enter]</b> or <b>[Esc]</b> .
< >	Indicates required keyboard entries. For Example: / <b>P</b> < <b>n</b> >.
[ ]	Indicates optional keyboard entries. For Example: / <b>P</b> [ <b>n</b> ].

## 2. Unit Description

### 2.1. VMR Standard Series - Front Panel




Figure 2.1: VMR Standard Series - Front Panel (Model VMR-16HD20-1 Shown)

As shown in Figure 2.1, the VMR Series Front Panel includes the following components:

1. **SetUp Port:** An RJ45 RS232 serial port (DCE configuration) used for connection to a local terminal or external modem, as described in Section 4.3. Note that on VMR-HD4H series units, the SetUp port is located on the back panel. For a description of the Setup Port interface, please refer to Appendix B.1.
2. **"ON" Indicator:** An LED which lights when power is applied to the VMR.
3. **"RDY" Indicator:** (Ready) Flashes if unit is ready to receive commands.
4. **Default Button:** Toggles outlets On/Off or resets unit to factory default parameters as described in Section 2.11.
5. **Reset Button:** Reboots and/or resets the VMR to factory defaults as described in Section 2.11.  
**Note:** All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 6.2.
6. **Output Status Indicators:** LEDs light when corresponding outlet is switched On.
7. **Branch A Current Usage:** Ten LEDs which light to indicate total current usage by Power Circuit A. The first LED lights when 0% to 9% of maximum rated current is used, and the last LED lights when over 100% of maximum rated current is used.
8. **Branch B Current Usage:** Same as Item 7 above, except displays values for Power Circuit B. (Not present on VMR-4HS and VMR-8HS series units.)
9. **Branch A Circuit Breakers:** Two circuit breakers, which protect Branch A. One circuit breaker protects outlets A1 through A4, and the other circuit breaker protects outlets A5 through A8.
10. **Branch B Circuit Breakers:** Same as Item 9 above, except circuit breakers protect outlets on Branch B. (Not present on VMR-4HS and VMR-8HS series units.)




Figure 2.2: VMR Standard Series - Back Panel (Model VMR-16HD20-1 Shown)

## 2.2. VMR Standard Series - Back Panel

As shown in Figure 2.2, the VMR Series Back Panel includes the following components:

1. **Power Circuit A - Power Inlet:** An IEC320-C20 AC inlet which supplies power to VMR control functions and Circuit “A” outlets. Also includes cable keeper (not shown.)

### Notes:

- VMR-4HS15 and VMR-8HS20 series units feature a single Power Inlet.
- VMR-HD4D-30 and VMR-HD4D-32 units feature attached power supply cables.

2. **Power Circuit B - Power Inlet:** An IEC320-C20 AC inlet which supplies power to VMR control functions and Circuit “B” outlets. Also includes cable keeper (not shown.) (Not present on VMR-4HS15 and VMR-8HS20 series units.)
3. **Power Circuit A - Switched Outlets:** AC Outlets that can be switched On, Off, rebooted or set to default state in response to user commands.
4. **Power Circuit B - Switched Outlets:** Same as Item 3 above. (Not present on VMR-4HS15 and VMR-8HS20 series units.)
5. **Alarm Indicator Lights:** Two LEDs which light when an alarm condition is detected at the corresponding power circuit. Note that VMR-4HS15 and VMR-8HS20 series units only include one power circuit and one Alarm Indicator Light. For information on Alarm Configuration, please refer to Section 8.
6. **Network Port:** An RJ45 Ethernet port for connection to your 100Base-T, TCP/IP network. Note that the VMR features a default IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 6.8.




Figure 2.3: VMR-HD4D Series - Front Panel (Model VMR-HD4D32 Shown)

### 2.3. VMR-HD4D Series - Front Panel

As shown in Figure 2.3, the VMR-HD4D Series Front Panel includes the following components:

1. **Branch B Circuit Breakers:** Two circuit breakers, which protect Branch B. One circuit breaker protects outlet B1 and the other circuit breaker protects outlet B2.
  2. **Branch A Circuit Breakers:** Same as Item 1 above, except circuit breakers protect outlets on Branch A.
  3. **"ON" Indicator:** An LED which lights when power is applied to the VMR.
  4. **"RDY" Indicator:** (Ready) Flashes if unit is ready to receive commands.
  5. **Default Button:** Toggles outlets On/Off or resets unit to factory default parameters as described in Section 2.11.
  6. **Reset Button:** Reboots and/or resets the VMR to factory defaults as described in Section 2.11.
- Note:** All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 6.2.
7. **Output Status Indicators:** LEDs light when corresponding outlet is switched On.
  8. **Current Usage Indicators:** Ten LEDs which light to indicate total current usage by each Power Circuit. The first LED lights when 0% to 9% of maximum rated current is used, and the last LED lights when over 100% of maximum rated current is used.




Figure 2.4: VMR-HD4D Series - Back Panel (Model VMR-HD4D32 Shown)

## 2.4. VMR-HD4D Series - Back Panel

As shown in Figure 2.4, the VMR-HD4D Series Back Panel includes the following components:

1. **Power Circuit A - Power Inlet:** Supplies power to VMR control functions and Circuit "A" outlets.

**Notes:**

- VMR-HD4D16 and VMR-HD4D20 units feature detachable power supply cables.
- VMR-HD4D30 units feature attached power supply cables with NEMA L6-30P Plugs.
- VMR-HD4D32 units feature attached power supply cables with IEC 60309 Plugs.

2. **Power Circuit B - Power Inlet:** Supplies power to VMR control functions and Circuit "A" outlets. Please refer to the notes under item 1 above.
3. **Power Circuit A - Switched Outlets:** AC Outlets that can be switched On, Off, rebooted or set to default state in response to user commands.
4. **Power Circuit B - Switched Outlets:** Same as Item 3 above.
5. **Alarm Indicator Lights:** Two LEDs which light when an alarm condition is detected at the corresponding power circuit. For information on Alarm Configuration, please refer to Section 8.
6. **Setup Port:** An RJ45 RS232 serial port (DCE configuration) used for connection to a local terminal or external modem, as described in Section 4.3. For a description of the Setup Port interface, please refer to Appendix B.1.
7. **Network Port:** An RJ45 Ethernet port for connection to your 100Base-T, TCP/IP network. Note that the VMR features a default IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 6.8.




Figure 2.5: VMR-HD4D-8 Series - Front Panel

## 2.5. VMR-HD4D-8 Series - Front Panel

As shown in Figure 2.5, the VMR-HD4D-8 Series Front Panel includes the following components:

1. **Network Port:** An RJ45 Gigabit Ethernet port for connection to your 10/100/1000Base-T, TCP/IP network. Note that the VMR features a default IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 6.8.
  2. **SetUp Port:** An RJ45 RS232 serial port (DCE configuration) used for connection to a local terminal or external modem, as described in Section 4.3. For a description of the Setup Port interface, please refer to Appendix B.1.
  3. **"ON" Indicator:** An LED which lights when power is applied to the VMR.
  4. **"RDY" Indicator:** (Ready) Flashes if unit is ready to receive commands.
  5. **Default Button:** Toggles outlets On/Off or resets unit to factory default parameters as described in Section 2.11.
  6. **Reset Button:** Reboots and/or resets the VMR to factory defaults as described in Section 2.11.
- Note:** All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 6.2.
7. **Output Status Indicators:** LEDs light when corresponding outlet is switched On.
  8. **Current Usage Indicators:** Ten LEDs which light to indicate total current usage by each Power Circuit. The first LED lights when 0% to 9% of maximum rated current is used, and the last LED lights when over 100% of maximum rated current is used.
  9. **Circuit Breakers:** Eight circuit breakers. Each circuit breaker protects one of the switched outlets on the VMR-HD4D-8 Back Panel.






Figure 2.6: VMR-HD4D-8 Series - Back Panel

## 2.6. VMR-HD4D-8 Series - Back Panel

As shown in Figure 2.6, the VMR-HD4D-8 Series Back Panel includes the following components:

### Power Inlets:

Each inlet provides power to the two switched outlets on the corresponding branch.

### Notes:

- VMR-HD4D30-8 units feature attached power supply cables with NEMA L6-30P Plugs.
- VMR-HD4D32-8 units feature attached power supply cables with IEC 60309 Plugs.

1. **Branch A1-A2 Power Inlet:** Supplies power to outlets A1 and A2.
2. **Branch A3-A4 Power Inlet:** Supplies power to outlets A3 and A4.
3. **Branch B1-B2 Power Inlet:** Supplies power to outlets B1 and B2.
4. **Branch B3-B4 Power Inlet:** Supplies power to outlets B3 and B4.

### Switched Power Outlets:

Each pair of switched IEC 60320 C19 outlets draws power from the corresponding branch power inlet.

5. **Branch A1-A2 - Switched Power Outlets:** Outlets A1 and A2 draw power from the Branch A1-A2 Power Inlet.
6. **Branch A3-A4 - Switched Power Outlets:** Outlets A3 and A4 draw power from the Branch A3-A4 Power Inlet.
7. **Branch B1-B2 - Switched Power Outlets:** Outlets B1 and B2 draw power from the Branch B1-B2 Power Inlet.
8. **Branch B3-B4 - Switched Power Outlets:** Outlets B3 and B4 draw power from the Branch B3-B4 Power Inlet.




Figure 2.7: VMR-12B Series - Front Panel (Model VMR-HD4D32-12B Shown)

## 2.7. VMR-12B Series - Front Panel

As shown in Figure 2.7, the VMR-12B Series Front Panel includes the following components:

1. **Network Port:** An RJ45 Ethernet port for connection to your 100Base-T, TCP/IP network. Note that the VMR features a default IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 6.8.
2. **SetUp Port:** An RJ45 RS232 serial port (DCE configuration) used for connection to a local terminal or external modem, as described in Section 4.3. For a description of the Setup Port interface, please refer to Appendix B.1.
3. **"ON" Indicator:** An LED which lights when power is applied to the VMR.
4. **"RDY" Indicator:** (Ready) Flashes if unit is ready to receive commands.
5. **Default Button:** Toggles outlets On/Off or resets unit to factory default parameters as described in Section 2.11.
6. **Reset Button:** Reboots and/or resets the VMR to factory defaults as described in Section 2.11.
 

**Note:** All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 6.2.
7. **Output Status Indicators:** LEDs light when corresponding outlet is switched On.
8. **Branch A Current Usage:** Ten LEDs which light to indicate total current usage by Power Circuit A. The first LED lights when 0% to 9% of maximum rated current is used, and the last LED lights when over 100% of maximum rated current is used.
9. **Branch B Current Usage:** Same as Item 7 above, except displays values for Power Circuit B.
10. **Circuit Breakers:** Six circuit breakers, which protect Branches A and B.




Figure 2.8: VMR Series - Back Panel (Model VMR-HD4D32-12B Shown)

## 2.8. VMR-12B Series - Back Panel

As shown in Figure 2.8, the VMR-12B Series Back Panel includes the following components:

1. **Power Circuit A - Power Inlet:** An IEC320-C20 AC inlet which supplies power to VMR control functions and Circuit “A” outlets.

**Notes:**

- VMR-HD4D30-12B series units feature attached power supply cables with NEMA L6-30P plugs.
- VMR-HD4D32-12B units feature attached power supply cables with IEC 60309 plugs.

2. **Power Circuit B - Power Inlet:** An IEC320-C20 AC inlet which supplies power to VMR control functions and Circuit “B” outlets.
3. **Power Circuit A - Switched Outlets:** AC Outlets that can be switched On, Off, rebooted or set to default state in response to user commands.
4. **Power Circuit B - Switched Outlets:** Same as Item 3 above.




Figure 2.9: NPS Series - Front Panel (Model NPS-16HD20-1 Shown)

## 2.9. NPS Series - Front Panel

As shown in Figure 2.9, the NPS Series Front Panel includes the following components:

1. **SetUp Port:** An RJ45 RS232 serial port (DCE configuration) used for connection to a local terminal or external modem, as described in Section 4.3. For a description of the Setup Port interface, please refer to Appendix B.1.
2. **"ON" Indicator:** An LED which lights when power is applied to the VMR unit.
3. **"RDY" Indicator:** (Ready) Flashes if unit is ready to receive commands.
4. **Default Button:** Manually toggles outlets On/Off or resets unit to factory default parameters as described in Section 2.11.
5. **Reset Button:** Reboots and/or resets the NPS to factory defaults as described in Section 2.11.
 

**Note:** All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 6.2.
6. **Output Status Indicators:** LEDs light when corresponding outlet is switched On.
7. **Branch A Circuit Breakers:** Two circuit breakers, which protect Branch A. One circuit breaker protects outlets A1 through A4, and the other circuit breaker protects outlets A5 through A8.
8. **Branch B Circuit Breakers:** Same as Item 7 above, except circuit breakers protect outlets on Branch B. (Not present on NPS-8HS series units.)




Figure 2.10: NPS Series - Back Panel (Model NPS-16HD20-1 Shown)

## 2.10. NPS Series - Back Panel

As shown in Figure 2.10, the NPS Series Back Panel includes the following components:

1. **Power Circuit A - Power Inlet:** An IEC320-C20 AC inlet which supplies power to NPS control functions and the Circuit “A” outlets. Also includes cable keeper (not shown.)

### Notes:

- NPS-8HS series units feature a single Power Inlet.
- NPS-ATS series units feature dual, redundant power inlets.

2. **Power Circuit B - Power Inlet:** An IEC320-C20 AC inlet which supplies power to NPS control functions and the Circuit “B” outlets. Also includes cable keeper (not shown.) (Not present on NPS-8HS series units.)
3. **Power Circuit A - Switched Outlets:** AC Outlets that can be switched On, Off, rebooted or set to default state in response to user commands:
4. **Power Circuit B - Switched Outlets:** Same as Item 3 above. (Not present on NPS-8HS series units.)
5. **Alarm Indicator Lights:** Two LEDs which light when an alarm condition is detected at the corresponding power circuit. Note that NPS-8HS series units only include one power circuit and one Alarm Indicator Light. For information on Alarm Configuration, please refer to Section 8.
6. **Network Port:** An RJ45 Ethernet port for connection to your 100Base-T, TCP/IP network. Note that the NPS features a default IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 6.8.

## 2.11. Additional Button Functions

The Default and Reset buttons on the VMR or NPS front panel can be used to perform the functions described below:

### Notes:

- *All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 6.2.*
- *When the VMR or NPS is reset to factory defaults, all user-defined configuration parameters will be cleared, and the default "super" user account will also be restored.*

### 1. Reboot Operating System:

- a) Press and hold the Reset button for five seconds, and then release it.
- b) The VMR or NPS will reboot its operating system; all plugs will be left in their current On/Off state.

### 2. Set Parameters to Factory Defaults:

- a) Simultaneously press both the Default button and the Reset button, hold them for five seconds, and then release them.
- b) All VMR/NPS parameters will be reset to their original factory default settings, and the unit will then reboot. All plugs will be left in their current On/Off state.

### 3. Toggle/Default All Plugs:

- a) Press the Default button, hold it for five seconds, and then release the Default Button.
- b) The VMR or NPS will switch all plugs to the Off state. If all plugs are already in the Off state, then the unit will reset all plugs to their user defined default states.

## 3. Getting Started

This section describes a simplified installation procedure for the VMR/NPS series hardware which will allow you to communicate with the unit in order to demonstrate basic features and check for proper operation. In order to take full advantage of the features provided by this unit it is recommended that you should also refer to the remainder of this User's Guide.

### 3.1. Installing the VMR or NPS Hardware

#### 3.1.1. Apply Power to the VMR or NPS

Refer to power rating nameplate on the VMR or NPS unit, and then connect the unit to an appropriate power source.

**Notes:**

- *To determine the exact model number and power requirements for your VMR or NPS unit, either refer to the nameplate on the back of the unit, or access command mode as described in Section 5.1 and then type **J** \* and press **[Enter]**.*
- *VMR-HD4D-8 Series units include four power inlets.*
- *Standard VMR Series, VMR-HD4D Series and VMR-12B Series units include two power inlets.*
- *NPS-HD Series units include two power inlets.*
- *NPS-ATS Series units include dual, redundant power inlets.*
- *NPS-HS Series units include a single power inlet.*

Connect power cable(s) to the Power Inlet(s), install the cable keeper(s) (as described in Section 4.1.), then connect the cables to an appropriate power supply.

#### 3.1.2. Connect your PC to the VMR or NPS

The VMR or NPS unit can either be controlled by a local PC, that communicates with the unit via the SetUp port, controlled via external modem, or controlled via TCP/IP network. In order to switch plugs or select parameters, commands are issued to the VMR or NPS via either the Network Port or SetUp Port. Note that it is not necessary to connect to both the Network and SetUp Ports, and that the SetUp Port can be connected to either a local PC or External Modem.

- **Network Port:** Connect your network cable to the VMR or NPS Network port. Note that VMR-HD4D-8 Series units include 10/100/1000Base-T Ethernet Ports, while all other VMR/NPS Models include 10/100Base-T Ethernet Ports.
- **Setup Port:** Use the DX9F-WTI Adapter supplied with the unit to connect your PC COM port to the VMR or NPS SetUp Port.
- **External Modem:** Use the optional DX9M-RJ-KIT (not included) to connect your external modem to the VMR or NPS Setup (RS232) Port.

## 3.2. Communicating with the VMR or NPS

In order to ensure security, both Telnet and Web Browser Access are disabled when the VMR or NPS is shipped from the factory. To enable Telnet and/or Web Browser access, please refer to Section 6.8. When properly installed and configured, the VMR or NPS will allow command mode access via Telnet, Web Browser, SSH client, modem, or local PC.

### Notes:

- *Default VMR/NPS serial port parameters are set as follows: 9600 bps, RTS/CTS Handshaking, 8 Data Bits, One Stop Bit, No Parity. Although these parameters can be easily redefined, for this Quick Start procedure, it is recommended to configure your communications program to accept the default parameters.*
  - *The VMR and NPS feature a default IP Address (192.168.168.168) and a default Subnet Mask (255.255.255.0.) This allows network access to command mode, providing that you are contacting the VMR or NPS from a node on the same subnet. When attempting to access the VMR or NPS from a node that is not on the same subnet, please refer to the Section 6.8 for further configuration instructions.*
1. **Access Command Mode:** The VMR/NPS includes two user interfaces; the Text Interface and the Web Browser Interface. The Text Interface is available via Local PC, SNMP, SSH Client, Telnet, or Modem, and the Web Browser interface is only available via TCP/IP network. In addition, when contacted via PDA, the VMR/NPS will also present a third interface, which is similar to the Web Browser Interface, but offers limited command functions.
    - a) **Via Local PC:** Start your communications program and then press **[Enter]**.
    - b) **Via SSH Client:** Start your SSH client, enter the default IPv4 format address (192.168.168.168) for the VMR/NPS and invoke the connect command.
    - c) **Via Web Browser:** Make certain that Web Browser access is enabled as described in the Section 6.8 in this User's Guide. Start your JavaScript enabled Web Browser, enter the default IPv4 format VMR/NPS IP address (192.168.168.168) in the Web Browser address bar, and then press **[Enter]**.
    - d) **Via Telnet:** Make certain that Telnet access is enabled as described in Section 6.8. Start your Telnet client, and enter the default IPv4 format VMR/NPS IP address (192.168.168.168).
    - e) **Via Modem:** Make certain the VMR/NPS SetUp Port is configured for Modem Mode as described in Section 6.7, then use your communications program to dial the number for the external Modem connected to the SetUp Port.



2. **Username / Password Prompt:** A message will be displayed, which prompts you to enter your username and password. The default username is "super" (all lower case, no quotes), and the default password is also "super". If a valid username and password are entered, the VMR or NPS will display either the Main Menu (Web Browser Interface) or the Port Status Screen (SSH, Telnet, or Modem.)

**Notes:**

- *The default Username is "super".*
  - *The default Password is "super"*
  - *If a Login Banner has been defined as described in Section 6.2, then a banner page will appear before the command interface is displayed. The Login Banner can be used to display legal warnings or other information.*
3. **Review Help Menu:** If you are communicating with the VMR/NPS via the text interface (SSH, Telnet or Modem), type `/H` and press **[Enter]** to display the Help Menu, which lists most VMR/NPS commands. Note that the Help Menu is not available via the Web Browser Interface.
  4. **Test Switching Functions:** You may wish to perform the following tests in order to make certain that the VMR or NPS is responding to commands. When switching and reboot commands are executed, the VMR/NPS Output Status LEDs will also turn On or Off to indicate the status of each outlet.
    - a) **Reboot Outlet:**
      - i. **Web Browser Interface:** Click on the "Plug Control" link on the left hand side of the screen to display the Plug Control Menu. From the Plug Control Menu, click the down arrow in the row for Plug A1 to display the dropdown menu, then select "Reboot" from the drop down menu and click on the "Execute Plug Actions" button.
      - ii. **Text Interface:** Type `/BOOT A1` and press **[Enter]**.
    - b) **Switch Outlet Off:**
      - i. **Web Browser Interface:** From the Plug Control Menu, click the down arrow in the "Action" column for Plug A1 to display the drop down menu, then select "Off" from the drop down menu and click on the "Execute Plug Actions" button.
      - ii. **Text Interface:** Type `/OFF A1` and press **[Enter]**.
    - c) **Switch Outlet On:**
      - i. **Web Browser Interface:** From the Plug Control Menu, click the down arrow in the "Action" column for Plug A1 to display the drop down menu, then select "On" from the drop down menu and click on the "Execute Plug Actions" button.
      - ii. **Text Interface:** Type `/ON A1` and press **[Enter]**.

5. **Logging Out:** When you log off, this ensures that the unit has completely exited from command mode, and is not waiting for the inactivity timeout to elapse before allowing additional connections.
  - a) **Web Browser Interface:** Click on the "LOGOUT" link on the left hand side of the screen.
  - b) **Text Interface:** Type /x and press **[Enter]**.

### 3.3. The WMU Enterprise Management Solution

The WMU Enterprise Management Solution provides a centralized interface that can be used to configure, manage and control multiple WTI out-of-band management devices spread throughout a large corporate network infrastructure. When installed at your network operation center or support facility, the WMU eliminates the need to individually access WTI units in order to perform firmware updates, control power switching functions, edit user accounts and perform other management and control functions.

The WMU software and user's guide can be downloaded at:

**<ftp://wtiftp.wti.com/pub/TechSupport/WMU/WtiManagementUtilityInstall.exe>**

This completes the Quick Start Guide for the VMR/NPS. Prior to placing the unit into operation, it is recommended to refer to the remainder of this User's Guide for important information regarding advanced configuration capabilities and more detailed operation instructions. If you have further questions regarding the VMR/NPS unit, please contact WTI Customer Support as described in Appendix C.

## 4. Hardware Installation

### 4.1. Connecting the Power Supply Cables

#### 4.1.1. Installing the Power Supply Cable Keepers

The VMR/NPS includes cable keepers, which are designed to prevent the power supply cables from being accidentally disconnected from the unit.

- **VMR-8HD & NPS-8HD Series Units:** The cable keepers for these units must be installed by the user.
  1. First make certain that both of the VMR/NPS's two power cables are disconnected from the power source.
  2. Install the two standoff screws (included with the cable keeper) in the two vacant screw holes, located between the two power inlets. When the standoff screws are in place, thread the two screws supplied with the cable keeper into the top end of both of the standoff screws.
  3. Connect the power cables to the power inlets. Check to make sure that both cables are firmly seated in the power inlet connectors.
  4. Install the cable keeper plate, by slipping the plate over the two screws which protrude from the top of the standoffs. Slip the cable keeper plate into place, so that the notches in the bottom of the plate slip over the power cables, and the holes in the middle of the plate align with the screws in the tops of the standoffs.
  5. Tighten the two screws into the standoffs to secure the plate and the power supply cables to the unit. Check to make certain that the cables are held firmly in place by the cable keepers.
- **VMR-8HS, VMR-16HD, VMR-HD4D, VMR-HD4D-8, NPS-8HS & NPS-16HD Series Units:** These units include pre-installed cable keepers. When attaching the power supply cables to the unit, first swing the cable keepers out of the way, then plug the power cables securely into the power inputs. When the cables are in place, snap the cable keepers over each plug to secure the cables to the unit.

#### 4.1.2. Connect the VMR or NPS to Your Power Supply

Refer to the cautions listed below and at the beginning of this User's Guide, and then connect the VMR/NPS unit to an appropriate power supply.

**Note:** *Some VMR/NPS units are shipped with one or two detachable 125 VAC, 15 Amp "Starter" Cables. These cable(s) will allow you to connect a 120 VAC VMR/NPS unit to power for bench testing and initial start up and are adequate for applications that only require 15 Amps. For higher amp power switching applications, please refer to the WTI Power Cable Guide (which can be found on the CDROM included with the unit) or use appropriate cables.*



#### CAUTIONS:



- **Before attempting to install this unit, please review the warnings and cautions listed at the front of the user's guide.**
- **This device should only be operated with the type of power source indicated on the instrument nameplate. If you are not sure of the type of power service available, please contact your local power company.**
- **Reliable earthing (grounding) of this unit must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than directly to the branch circuit.**
- **VMR/NPS models may include up to four power inlets to allow connection to multiple power supplies.**

### 4.2. Connection to Switched Outlets

Connect the power cord from your switched device to one of the AC Outlets on the VMR/NPS unit. Note that when power is applied to the VMR/NPS, the AC Outlets will be switched "ON" by default. Note that some VMR/NPS models include up to four separate power branches, while others feature only one power branch.

### 4.3. Serial SetUp Port Connection

The VMR/NPS SetUp Port is a female, RJ45 RS232 connector, wired in a DCE configuration. In the default state, the Setup port is configured for 9600 bps, no parity, 8 data bits, 1 stop bit. The Setup Port can be connected to either an external modem or a local PC, but not both items at the same time. Appendix B.1 describes the Setup Port interface.

#### 4.3.1. Connecting a Local PC

Use the DX9F-WTI Adapter supplied with the unit to connect your PC COM port to the VMR/NPS Setup Port. Make certain that the Serial Port Mode is set to "Normal" as described in Section 6.7.

#### 4.3.2. Connecting an External Modem

When connecting directly to an external modem, use the optional DX9M-RJ-KIT (not included) to connect your external modem to the VMR/NPS Setup Port. Make certain that the modem is initialized at the same default parameters as the VMR Setup Port and that the VMR/NPS Serial Port Mode is set to "Modem" as described in Section 6.7.

#### 4.4. Connecting the Network Cable

The Network Port is an RJ45 Ethernet jack, for connection to a TCP/IP network. Connect your network cable to the Ethernet Port on the VMR/NPS unit.

**Notes:**

- *VMR/NPS units include a default IPv4 format IP address (192.168.168.168) and a default IPv4 protocol subnet mask (255.255.255.0.)*
- *VMR-HD4D-8 units include 10/100/1000Base-T Ethernet ports. All other VMR/NPS units include 10/100Base-T Ethernet Ports.*

When installing the VMR or NPS in a working network environment, it is recommended to define network parameters as described in Section 6.8.

#### 4.5. Rack Mounting

To install a VMR/NPS Series unit in your equipment rack, attach the L-Brackets included with the unit and then mount the unit in a vacant space in your equipment rack.

#### 4.6. Emergency Shut Off Function

VMR/NPS Series units also include an Emergency Shut Off function, that can be used to immediately shut off all VMR/NPS power outlets in case of emergency. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).

This completes the VMR/NPS installation instructions. Please proceed to the next Section for instructions regarding unit configuration.

## 5. Basic Operation

### 5.1. Communicating with the VMR/NPS Unit

In order to control and configure the VMR/NPS, you must first connect to the unit, and access command mode. Note that, the VMR/NPS offers two separate command interfaces; the Web Browser Interface and the Text Interface.

In addition, the VMR/NPS also offers three different methods for accessing command mode; via network, via external modem, or via local console. The Web Browser interface is only available via network, and the Text Interface is available via network (SSH or Telnet), modem or local PC.

#### 5.1.1. The Text Interface

The Text Interface consists of a series of simple ASCII text menus, which allow you to set options and define parameters by entering the number for the desired option using your keyboard, and then typing in the value for that option.

Since the Web Browser Interface and Telnet accessibility are both disabled in the default state, you will need to use the Text Interface to contact the VMR/NPS via Local PC or SSH connection when setting up the unit for the first time. After you have accessed command mode using the Text Interface, you can then enable Web Access and Telnet Access, if desired, in order to allow future communication with the unit via Web Browser or Telnet. You will not be able to contact the unit via Web Browser or Telnet until you have enabled these options.

Once Telnet Access is enabled, you will then be able to use the Text Interface to communicate with the VMR/NPS via local PC, Telnet or SSH connection. You can also use the Text Interface to access command mode via an external modem installed at the VMR/NPS serial Setup Port.

In order to use the Text Interface, your installation must include:

- **Access via Network:** The VMR/NPS must be connected to your TCP/IP Network, and your PC must include a communications program (such as TeraTerm or PuTTY.)
- **Access via Modem:** An external modem must be installed at the VMR/NPS RS232 Setup Port (see Section 4.3.2), a phone line must be connected to the external modem, and the Setup Port must be configured for Modem Mode. In addition, your PC must include a communications program.
- **Access via Local PC:** Your PC must be physically connected to the VMR/NPS RS232 Setup Port as described in Section 4.3.1, the VMR/NPS Setup Port must be configured for Normal Mode, and your PC must include a communications program.

To access command mode via the Text Interface, proceed as follows:

**Note:** *When communicating with the unit for the first time, you will not be able to contact the unit via Telnet, until you have accessed command mode, via Local PC or SSH Client, and used the Network Parameters Menu to enable Telnet as described in Section 6.8.*

1. Contact the VMR/NPS Unit:
  - a) **Via Local PC:** Start your communications program and press **[Enter]**. Wait for the connect message, then proceed to Step 2.
  - b) **Via Network:** The VMR/NPS includes a default IP address (192.168.168.168) and a default subnet mask (255.255.255.0.) This allows you to contact the unit from any network node on the same subnet, without first assigning an IP Address to the unit. For more information, please refer to Section 6.8.
    - i. **Via SSH Client:** Start your SSH client, and enter the VMR/NPS IP Address. Invoke the connect command, wait for the connect message, then proceed to Step 2.
    - ii. **Via Telnet:** Start your Telnet Client, and then Telnet to the VMR/NPS IP Address. Wait for the connect message, then proceed to Step 2.
  - c) **Via Modem:** Use your communications program to dial the number for the external modem which you have connected to the VMR/NPS Setup Port.
2. **Login / Password Prompt:** A message will be displayed, which prompts you to enter a username (login name) and password. The default username is "super" (all lower case, no quotes), and the default password is also "super".
3. If a valid username and password are entered, the VMR/NPS will display the Plug Status Screen.

**Note:** *If a Login Banner has been defined as described in Section 6.2, then a banner page will appear before the command prompt is displayed. The Login Banner can be used to display legal warnings or other information.*

### 5.1.2. The Web Browser Interface

The Web Browser Interface consists of a series of web forms, which can be used to select configuration parameters and perform reboot operations, by clicking on buttons and/or entering text into designated fields.

**Note:** *In order to use the Web Browser Interface, Web Access must first be enabled via the Text Interface Network Parameters Menu (IN), the VMR/NPS must be connected to a TCP/IP network, and your PC must be equipped with a JavaScript enabled web browser.*

1. Start your JavaScript enabled Web Browser, key the VMR/NPS IP address (default = 192.168.168.168) into the web browser's address bar, and press **[Enter]**.
2. **Username / Password Prompt:** A message box will prompt you to enter your username and password. The default username is "super" (all lower case, no quotes), and the default password is also "super".
3. If a valid username and password are entered, the Plug Control Screen will be displayed.

**Note:** *If a Login Banner has been defined as described in Section 6.2, then a banner page will appear before the command prompt is displayed. The Login Banner can be used to display legal warnings or other information.*

### 5.1.3. The WMU Enterprise Management Solution

The WMU Enterprise Management Solution provides a centralized interface that can be used to configure, manage and control multiple WTI out-of-band management devices spread throughout a large corporate network infrastructure. When installed at your network operation center or support facility, the WMU eliminates the need to individually access WTI units in order to perform firmware updates, control power switching functions, edit user accounts and perform other management and control functions.

The WMU software and user's guide can be downloaded at:

<ftp://wtiftp.wti.com/pub/TechSupport/WMU/WtiManagementUtilityInstall.exe>



## 5.2. Controlling Power - Web Browser Interface

When using the Web Browser Interface, switching commands are invoked via the Plug Control Screen and Plug Group Control Screen.

### 5.2.1. The Plug Control Screen - Web Browser Interface

The Plug Control Screen lists the On/Off status of the VMR/NPS Series unit's Switched Outlets and is used to control switching and rebooting of the outlets. To invoke power switching commands, access command mode and then click on the "Plug Control" link on the left hand side of the screen to display the Plug Control Screen. When the Plug Control Screen appears, click the down arrow in the "Action" column for the desired outlet(s), then select the desired switching option from the dropdown menu and click on the "Confirm Plug Actions" button.

When the "Confirm Plug Actions" button is pressed, the VMR/NPS Series unit will display a screen which lists the selected action(s) and asks for confirmation before proceeding. To implement the selected action(s), click on the "Execute Plug Actions" button. The VMR/NPS Series unit will display a screen which indicates that a switching operation is in progress, then display the Plug Status screen when the command is complete. At that time, the Status Screen will list the updated On/Off status of each plug.

#### Notes:

- *When switching and reboot operations are initiated, Boot/Sequence Delay times will be applied as described in Section 6.6.*
- *If a switching or reboot command is directed to a plug that is already in the process of being switched or rebooted, then the new command will be placed in a queue until the plug is ready to receive additional commands.*
- *If the Status column in the Plug Control Screen includes an asterisk, this means that the outlet is busy completing a previously invoked command.*
- *When the Plug Control Screen is displayed by an account that permits Administrator or SuperUser level commands, all switched outlets will be shown.*
- *When the Plug Control Screen is displayed by an account that permits User or ViewOnly command access, the screen will only include the switched outlets that are specifically allowed by the account.*

### 5.2.2. The Plug Group Control Screen - Web Browser Interface

The Plug Group Control Screen is used to send switching and reboot commands to the user-defined Plug Groups. As described in Section 6.5, Plug Groups allow you to specify a group of outlets that are dedicated to a similar purpose or client, and then direct switching commands to the group, rather than switching one plug at a time.

To apply power switching commands to Plug Groups, first access command mode via the Web Browser Interface (see Section 5.1.) Click on the "Plug Group Control" link on the left hand side of the screen to display the Plug Group Control Screen. When the Plug Group Control Screen appears, click the down arrow in the "Action" column for the desired Plug Group(s), then select the desired switching option from the dropdown menu and click on the "Confirm Plug Actions" button

When the "Confirm Plug Group Actions" button is pressed, the VMR/NPS Series unit will display a screen which lists the selected action(s) and asks for confirmation before proceeding. To implement the selected plug group action(s), click on the "Execute Plug Group Actions" button. The VMR/NPS Series unit will display a screen which indicates that a switching operation is in progress, then display the Plug Status screen when the command is complete. At that time, the Status Screen will list the updated On/Off status of each plug.

#### **Notes:**

- *When switching and reboot operations are initiated, Boot/Sequence Delay times and user-defined Plug Priority values will be applied as described in Section 6.6.*
- *If a switching or reboot command is directed to a plug that is already in the process of being switched or rebooted by a previous command, then the new command will be placed in a queue until the plug is ready to receive additional commands.*
- *When the Plug Group Control Screen is displayed by an account that permits Administrator or SuperUser command access, all user-defined Plug Groups will be displayed.*
- *When the Plug Control Screen is displayed by an account that permits User or ViewOnly level commands, the screen will only include the Plug Groups that are allowed by the account.*

---

## 5.3. Controlling Power - Text Interface

When using the Text Interface, all power switching functions are performed by invoking simple, ASCII commands. ASCII commands are also used to display status screens and to log out of command mode. The Text Interface includes a Help Menu, which summarizes all available commands. To display the Text Interface Help Menu, type `/H` and press **[Enter]**.

**Note:** *When the Help Menu is displayed by an account that permits SuperUser, User or ViewOnly level commands, the screen will not include commands that are only available to Administrators.*

### 5.3.1. The Port and Plug Status Screen - Text Interface

The Port and Plug Status Screen lists the status of the VMR/NPS Series unit's serial ports and AC Outlets, displays the temperature and displays the user-defined Site I.D. Message. The Status Screen will be re-displayed each time a command is successfully executed. To display the Port and Plug Status Screen via the Text Interface, type `/S` and press **[Enter]**. The VMR/NPS will display a screen that shows port status; to display plug status, press **[Enter]** or press **[Esc]** to exit from the Port and Plug Status Screen.

### 5.3.2. Switching and Reboot Commands - Text Interface

These commands can be used to switch or reboot the VMR/NPS Series unit's switched plugs, and can also be used to set plugs to the user-defined Power-Up Default values. Plugs may be specified by name or number.

#### Notes:

- *If an asterisk appears in the "Status" column for any given plug, this indicates that the plug is currently busy, processing a previously issued command.*
- *If a switching or reboot command is directed to a plug that is already busy completing a previous command, then the new command will be placed in a queue until the plug is ready to receive additional commands.*
- *Administrator and SuperUser level accounts can use the Port and Plug Status Screen to display information for all serial ports and switched outlets.*
- *User and ViewOnly level accounts can only use the Port and Plug Status Screen to display information for serial ports and outlets that are allowed by the account.*
- *Administrator or SuperUser level accounts can direct switching and reboot commands to all plugs.*
- *User Level accounts can only direct switching and reboot commands to the plugs that are specifically allowed by that account.*
- *The Status Screen will be displayed after switching and reboot commands are successfully completed.*
- *When switching and reboot operations are initiated, Boot/Sequence Delay times and user-defined Plug Priority values will be applied as described in Section 6.6.*
- *Text Interface commands are **not** case sensitive. When used in On/Off/Reboot command lines, plug names and plug group names are also **not** case sensitive.*

When switching and reboot commands are executed, the VMR/NPS Series unit will display a "Sure?" prompt, wait for user response, and then complete the command. The unit will pause for a moment while the command is executed, and then return to the Port and Plug Status Screen.

To Switch Plugs, or initiate a Reboot Cycle, proceed as follows:

1. **Switch Plug(s) On:** To power-on a plug or Plug Group, type `/ON n` and press **[Enter]**. Where "n" is the number or name of the desired plug or Plug Group. For example:

`/ON 1 [Enter]` or `/ON ROUTER [Enter]`

- 
2. **Switch Plug(s) Off:** To power-off a plug or Plug Group, type `/OFF n` and press **[Enter]**. Where "n" is the number or name of the desired plug or Plug Group. Note that the `/OFF` command can also be entered as `/OF`. For example:

`/OFF 2 [Enter]` or `/OF ROUTER [Enter]`

3. **Reboot Plug(s):** To initiate a Boot cycle, type `/BOOT n` and press **[Enter]**. Where "n" is the number or name of the desired plug or Plug Group. Note that the `/BOOT` command can also be entered as `/BO`. For example:

`/BOOT 3 [Enter]` or `/BO ATMSWICH [Enter]`

4. **Set All Plugs to Power Up Defaults:** Type `/DPL` and press **[Enter]**. All plugs permitted by your account will be set to their default On/Off status, which is defined via the Plug Parameters Menu as described in Section 6.6.

**Notes:**

- *When you have accessed command mode using an account that permits Administrator or SuperUser level command access, the Default command will be applied to all plugs.*
  - *When you have accessed command mode using an account that only permits User level command access, the Default command will only be applied to the plugs specifically allowed by that account.*
  - *Switching commands are not available in ViewOnly mode.*
5. **Suppress Command Confirmation Prompt:** To execute a Boot/On/Off command without displaying the "Sure?" prompt, you can either disable command confirmation via the System Parameters Menu, or include the `,Y` option at the end of the command line. For example:

`/ON ROUTER,Y` or `/BOOT 2,Y`

### 5.3.2.1. Applying Commands to Several Plugs - Text Interface

As described below, switching and reboot commands can be applied to only one Switched AC Outlet, or to an assortment of outlets.

**Note:** *When switching and reboot operations are initiated, Boot/Sequence Delay times and user-defined Plug Priority values will be applied as described in Section 6.6.*

1. **Switch Several Plugs:** To apply a command to several plugs, enter the numbers or names for the plugs, separated by a "plus sign" (+) or a comma (,). For example to switch plugs 1, 3, and 4 Off, enter either of the following commands:

`/OFF 1+3+4 [Enter]`

or

`/OFF 1,3,4 [Enter]`

**Note:** *When the "+" or "," are used, do not enter spaces between the plug name or number and the plus sign or comma.*

2. **Switch a Series of Plugs:** To apply a command to a series of plugs, enter the number for the plugs that mark the beginning and end of the series, separated by a colon. For example to switch On plugs 1 through 3, enter the following:

`/ON 1:3 [Enter]`

3. **All Plugs:** To apply a command to all plugs, enter an asterisk in place of the name or number. For example, to Boot all plugs, enter the following:

`/BO * [Enter]`

**Note:** *When this command is invoked by an account that permits only User level command access, it will be applied only to the plugs that are allowed for that account.*

## 5.4. The Automated Mode

The Automated Mode allows the VMR/NPS to execute switching and reboot commands, without displaying menus or generating response messages. Automated Mode is designed to allow the VMR/NPS to be controlled by a device which can generate commands to control power switching functions without human intervention.

When Automated Mode is enabled, the /ON, /OFF, /BOOT, /DPL and /X commands are executed without a "Sure?" confirmation prompt and without command response messages; the only reply to these commands is the command prompt, which is displayed when the command is complete.

Note that although Automated Mode can be enabled using either the Web Browser Interface or Text Interface, Automated Mode is designed primarily for users who wish to send ASCII commands to the VMR/NPS without operator intervention, and therefore does not specifically apply to the Web Browser Interface. When Automated Mode is enabled, the Web Browser Interface can still be used to invoke On / Off / Boot commands.

### Notes:

- *When Automated Mode is enabled, all VMR/NPS password security functions are disabled, and users are able to access System Level command functions (including the configuration menus) and control plugs without entering a password.*
- *If you need to enable the Automated Mode, but want to restrict network access to VMR/NPS configuration menus, it is recommended to enable and configure the IP Tables Function as described in Section 6.8.2.*

To enable/disable Automated Mode, access the System Parameters menu (see Section 6.2,) then set the "Automated Mode" option to "On". When Automated Mode is enabled, VMR/NPS functions will change as follows:

1. **All Password Security Suppressed:** When a user attempts to access command mode, the password prompt will not be displayed at either the SetUp Port or the Network Port. Unless specifically restricted by the IP Security Function, all users will be allowed to access both switching and configuration functions, and all commands will be immediately accepted without the requirement to enter a password.
2. **Status Screen Suppressed:** The status screens will not be automatically displayed after commands are successfully executed. Note however, that the /S command can still be invoked to display the status screen as needed.
3. **"Sure?" Prompt Suppressed:** All commands are executed without prompting for user confirmation.
4. **Error Messages Suppressed:** If the [Enter] key is pressed without entering a command, the VMR/NPS will not respond with the "Invalid Command" message. Note however, that an error message will still be generated if commands are invoked using invalid formats or arguments.

All other status display and configuration commands will still function as normal.

## 5.5. Manual Operation

In addition to the command driven functions available via the Web Browser Interface and Text Interface, some VMR/NPS functions can also be controlled manually. For a summary of front panel control functions, please refer to Section 2.11.

## 5.6. Logging Out of Command Mode

When you have finished communicating with the VMR/NPS, it is important to always disconnect using either the "LogOut" link (Web Browser Interface) or the /X command (Text Interface), rather than by simply closing your browser window or communications program.

When you disconnect using the LogOut link or /X command, this ensures that the VMR/NPS has completely exited from command mode, and is not waiting for the inactivity timeout period to elapse before allowing additional connections.

## 5.7. Emergency Shut Off Function

VMR/NPS Series units also include an Emergency Shut Off function, that can be used to immediately shut off all power outlets on an VMR/NPS Series unit in case of emergency. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).



## 6. Configuration Options

This section describes the basic configuration procedure for VMR/NPS Series units.

### 6.1. Configuration Menus

Although the Web Browser Interface and Text Interface provide two separate means for selecting parameters, both interfaces allow access to the same set of basic parameters, and parameters selected via one interface will also be applied to the other. To access the configuration menus, proceed as follows:

- **Text Interface:** Refer to the Help Screen (/H) and then enter the appropriate command to access the desired menu. When the configuration menu appears, key in the number for the parameter you wish to define, and follow the instructions in the resulting submenu.
- **Web Browser Interface:** Use the links and fly-out menus on the left hand of the screen to access the desired configuration menu. To change parameters, click in the desired field and key in the new value or select a value from the pull-down menu. To apply newly selected parameters, click on the "Change Parameters" button at the bottom of the menu or the "Set" button next to the field.

The following sections describe options and parameters that can be accessed via each of the configuration menus. Please note that essentially the same set of parameters and options are available to both the Web Browser Interface and Text Interface.

#### **Notes:**

- *To Access the configuration menus, proceed as described in Section 5.1.*
- *Configuration menus are only available when you have logged into command mode using a password that permits Administrator Level commands. SuperUser accounts are able to view configuration menus, but are not allowed to change parameters.*
- *Configuration menus are not available when you are communicating with the VMR/NPS via mobile device.*
- *When defining parameters via the Text Interface, make certain to press the **[Esc]** key to completely exit from the configuration menu and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message has been displayed and the cursor returns to the command prompt.*

## 6.2. Defining System Parameters

The System Parameters menus are used to define the Site ID Message, set the system clock and calendar, and configure the Invalid Access Lockout feature and Callback feature.

To access the System Parameters menu via the Text Interface, type `/F` and press **[Enter]**. To access the System Parameters menu via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear and then click on the "System Parameters" link. The System Parameters Menus are used to define the following:

- **User Directory:** This function is used to view, add, modify and delete user accounts and passwords. As discussed in Section 6.3 and Section 6.4, the User Directory allows you to set the security level for each account as well as determine which plugs each account will be allowed to control.

**Note:** *The "User Directory" option does not appear in the Web Browser Interface's System Parameters menu, and is instead accessed via the "User Configuration" link on the left hand side of the menu.*

- **Site ID:** A text field, generally used to note the installation site or name for the VMR/NPS unit. (Up to 64 characters; Default = undefined)

### Notes:

- *The Site I.D. will be cleared if the VMR/NPS is reset to default settings.*
- *When viewed via the Text Interface (CLI) Site I.D. messages that are over 30 characters long will be truncated. To display the entire Site I.D. message via the Text Interface, type `/J*` and press **[Enter]***
- **Real Time Clock:** This prompt provides access to the Real Time Clock menu, which is used to set the clock and calendar, and to enable and configure the NTP (Network Time Protocol) feature as described in Section 6.2.1.
 

**Note:** *The "Real Time Clock" option does not appear in the Web Browser Interface's System Parameters menu, and is instead, accessed via the "Real Time Clock" link in the General Parameters fly-out menu.*
- **Invalid Access Lockout:** If desired, this feature can be used to temporarily disable Console Port access, SSH access, Telnet access and/or Web access to the VMR/NPS command mode after a user specified number of unsuccessful login attempts are made. For more information, please refer to Section 6.2.2. (Default = Off.)
 

**Note:** *The "Invalid Access Lockout" item does not appear in the Web Browser Interface's System Parameters menu, and is instead, accessed via the link in the General Parameters fly-out menu.*
- **Temperature Format:** Determines whether the temperature is displayed as Fahrenheit or Celsius. (Default = Fahrenheit.)

- **Temperature Calibration:** Used to calibrate the unit's internal temperature sensing abilities. To calibrate the temperature, place a thermometer inside your equipment rack, in a location that usually experiences the highest temperature. After a few minutes, take a reading from the thermometer, and then key the reading into the configuration menu. In the Web Browser Interface, the temperature is entered at the System Parameters menu, in the Temperature Calibration field; in the Text Interface, the temperature is entered in a submenu of the System Parameters menu, accessed via the Temperature Calibration item. (Default = undefined.)
- **Log Configuration:** Configures the Audit Log, Alarm Log, Temperature Log and Current Metering Log. For more information on the VMR/NPS's event logging functions, please refer to Section 6.2.3. (Defaults: Audit Log = On without Syslog, Alarm Log = On without Syslog, Temperature Log = On, Current Metering Log = On.)

**Notes:**

- *The Current Log is not available on NPS units; NPS units do not support current monitoring.*
- *The Temperature Log is not available on VMR units; instead, temperature values for the VMR unit can be displayed in the Text Interface via the Current Metering Log or in the Web Browser Interface via the Current Metering Status Screen.*
- *The Audit Log will create a record of all port connection/disconnection and login/logout activity at the VMR/NPS unit.*
- *The Alarm Log will create a record of each instance where the Invalid Access Alarm is triggered or cleared at the VMR/NPS unit.*
- *The Temperature Log will create a record of ambient rack temperature over time.*
- **Callback Security:** Enables / configures the Callback Security Function as described in Section 6.2.4. In order for this feature to function, a Callback number must also be defined for each desired user account as described in Section 6.4. (Default = On, Callback, Without Password Prompt.)

**Notes:**

- *In the Text Interface, Callback Security Parameters are defined via a submenu of the Systems Parameters Menu, which is accessed via the Callback Security item.*
- *In the Web Browser Interface, Callback Security Parameters are defined via the "Callback Security" link in the General Parameters fly-out menu.*
- **Front Panel Buttons:** This item can be used to disable all front panel button functions. (Default = On.)
- **Modem Phone Number / IP Address:** If an optional external modem is connected to the the VMR/NPS, this parameter can be used to record the phone number. When the VMR/NPS is used in conjunction with the WMU Enterprise Management Solution, the WMU will retrieve the phone defined here for use when contacting the unit via dial-up. (Default = undefined)

- **Scripting Options:** Provides access to parameters that are used to set up the VRM/NPS unit for running various scripts as described in Section 6.2.6.

**Notes:**

- *The functions provided by the Scripting Options menu are intended for use in applications where scripts are employed to control VMR/NPS operation. Improper use of Scripting Options menu functions can cause the VMR/NPS unit to become unresponsive. Prior to attempting to use the functions provided by the Scripting Options menu, please contact WTI Technical Support as described in Appendix C in this User's Guide.*
- *In the Text Interface, the Scripting Options submenu is accessed via item 12. To access the Scripting Options parameters via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear, then click on the "Scripting Options" link.*
- **Power Configuration:** (VMR Only) In the Web Browser Interface, the Voltage Calibration parameter, Power Factor parameter and Power Efficiency parameter are defined via the System Parameters Menu. In the Text Interface, these parameters reside in a separate submenu, which is accessed via the Power Configuration option. For more information on Power Configuration, please refer to Section 6.2.5.  
**Note:** *The Power Configuration option is not available on NPS units.*
- **EnergyWise Configuration:** Defines parameters that are needed in order for the VMR/NPS to serve as an element in a Cisco® EnergyWise™ network. This item allows the following parameters to be defined. (Default = Off.)  
**Note:** *In the Web Browser Interface, EnergyWise parameters are defined via the "EnergyWise" link in the General Parameters fly-out menu.*
  - ◆ **Enable:** Enables/disables the VMR/NPS unit's ability to participate in a Cisco Energywise network. (Default = Off)
  - ◆ **Domain:** The Energywise Domain Name; up to eighty characters long. (Default = Undefined.)
  - ◆ **Secret:** A password that is used to authenticate each element in a Cisco Energywise network. The Secret parameter can be up to eighty characters long. (Default = Undefined.)
- **Asset Tag:** Allows a descriptive tag or tracking number to be assigned to the VMR/NPS unit. Once defined, the Asset Tag can be displayed via the Product Status Screen in the Web Interface or via the /J\* command in the Text Interface. (Default = Undefined)

- **Login Banner:** Allows definition of a banner/message that will be displayed when a valid username and password are entered during log in. The Login Banner can be used to post legal warning regarding unauthorized access to the unit or to display other user-defined information or instructions. (Default = Undefined)

**Notes:**

- *Although the Login Banner will be displayed when the VMR/NPS is accessed via both the Text Interface and Web Browser Interface, the Login Banner can only be defined via the Text Interface.*
- *The Login Banner can be up to 1024 characters long.*
- *The Login Banner text must begin with the `<banner>` command and end with the `</banner>` command.*
- *Banner text can be copied and pasted from a text editor, or sent in from a file.*
- *For best results, the individual text lines in the Login Banner should be less than 80 characters wide.*

### 6.2.1. The Real Time Clock and Calendar

The Real Time Clock menu is used to set the VMR/NPS internal clock and calendar. The configuration menu for the Real Time Clock offers the following options:

- **Date:** Sets the Month, Date, Year and day of the week for the VMR/NPS real-time clock/calendar.
- **Time:** Sets the Hour, Minute and Second for the VMR/NPS real time clock/calendar. Key in the time using the 24-hour (military) format.
- **Time Zone:** Sets the time zone, relative to Greenwich Mean Time. Note that the Time Zone setting will function differently, depending upon whether or not the NTP feature is enabled and properly configured. (Default = GMT (No DST).)
  - ◆ **NTP Enabled:** The Time Zone setting is used to adjust the Greenwich Mean Time value (received from the NTP server) in order to determine the precise local time for the selected time zone.
  - ◆ **NTP Disabled:** If NTP is disabled, or if the VMR/NPS is not able to access the NTP server, then status screens and activity logs will list the selected Time Zone and current Real Time Clock value, but will not apply the correction factor to the displayed Real Time Clock value.
- **NTP Enable:** When enabled, the VMR/NPS will contact an NTP server (defined via the NTP Address prompts) once a day, and update its clock based on the NTP server time and selected Time Zone. (Default = Off.)

**Notes:**

- *The VMR/NPS will also contact the NTP server and update the time whenever you change NTP parameters.*
- *To cause VMR/NPS to immediately contact the NTP server at any time, make certain that the NTP feature is enabled and configured, then type `/F` and press **[Enter]**. When the System Parameters menu appears, press **[Esc]**. The VMR/NPS will save parameters and then attempt to contact the server, as specified by currently defined NTP parameters.*

- **Primary NTP Address:** Defines the IP address or domain name (up to 64 characters long) for the primary NTP server. (Default = undefined.)

**Notes:**

- *In order to use domain names for web addresses, DNS parameters must first be defined as described in Section 6.8.4.*
- *The Web Browser Interface includes two separate fields that are allowed to define both an IPv4 protocol and IPv6 protocol format Primary NTP Address and Secondary NTP Address.*
- *When the Primary NTP Address and Secondary NTP Address are defined via the Text Interface, the VMR/NPS will display a prompt that instructs the user to select IPv4 or IPv6 protocol.*
- *The VMR/NPS allows parameters for both IPv4 and IPv6 protocols to be defined and saved.*

- **Secondary NTP Address:** Defines the IP address or domain name (up to 64 characters long) for the secondary, fallback NTP Server. (Default = undefined.)

**Notes:**

- *In order to use domain names for web addresses, DNS parameters must first be defined as described in Section 6.8.4.*
- *The Web Browser Interface includes two separate fields that are allowed to define both an IPv4 protocol and IPv6 protocol format Primary NTP Address and Secondary NTP Address.*
- *When the Primary NTP Address and Secondary NTP Address are defined via the Text Interface, the VMR/NPS will display a prompt that instructs the user to select IPv4 or IPv6 protocol.*
- *The VMR/NPS allows parameters for both IPv4 and IPv6 protocols to be defined and saved.*
- **NTP Timeout:** The amount of time in seconds, that will elapse between each attempt to contact the NTP server. When the initial attempt is unsuccessful, the VMR/NPS will retry the connection four times. If neither the primary nor secondary NTP server responds, the VMR/NPS will wait 24 hours before attempting to contact the NTP server again. (Default = 3 Seconds.)
- **Test NTP Servers:** Allows you to ping the IP addresses or domain names defined via the Primary and Secondary NTP Address prompts, or to ping a new address or domain defined via the Test NTP Servers submenu in order to check that a valid IP address or domain name has been entered.

**Notes:**

- *In order for the Test NTP Servers feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Test NTP Servers option, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

### 6.2.2. The Invalid Access Lockout Feature

When properly configured and enabled, the Invalid Access Lockout feature can watch all login attempts made via SSH connection, Telnet connection, web browser or the serial SetUp Port. If the counter for any of these exceeds the user-defined threshold for maximum invalid attempts, then the corresponding port or protocol will be automatically disabled for the length of time specified by the Lockout Duration parameter.

When Invalid Access Attempt monitoring is enabled for the serial SetUp Port, the VMR/NPS will count invalid access attempts at the serial SetUp Port. If the number of invalid access attempts exceeds the defined Lockout Attempts trigger value, the VMR/NPS will lock the serial SetUp Port for the defined Lockout Duration period. When Invalid Access Attempt monitoring for SSH, Telnet or Web are selected, a lockout will be triggered when the number of invalid access attempts during the defined Lockout Duration period exceeds the defined Hit Count for the protocol. For example, if the SSH Hit Count is set at 10 and the SSH Lockout Duration period is set at 120 seconds, then if over 10 invalid access attempts are detected within 120 seconds, the VMR/NPS will then lock out the MAC address that generated the excessive attempts for 120 seconds.

Note that when an Invalid Access Lockout occurs, you can either wait for the Lockout Duration period to elapse (after which, the VMR/NPS will automatically reactivate the port or protocol), or you can issue the /UL command (type /UL and press [Enter]) via the Text Interface to instantly unlock all VMR/NPS logical network ports and communication protocols.

#### Notes:

- *When the Serial Port Invalid Access Lockout Alarm has been enabled as described in Section 8.6, the VMR/NPS can also provide notification via email, Syslog Message, and/or SNMP trap whenever an Invalid Access Lockout occurs at the serial SetUp Port.*
- *If the Network Port has been locked by the Invalid Access Lockout feature, it will still respond to the ping command (providing that the ping command has not been disabled at the Network Port.)*

The Invalid Access Lockout configuration menus allow you to select the following parameters:

- **Serial Port Protection:** Enables/Disables the Invalid Access Lockout function for the serial SetUp Port and selects lockout parameters. When this item is enabled and excessive Invalid Access attempts are detected at the SetUp Port, the SetUp Port will be locked until the user-defined Lockout Duration period elapses, or until the /UL command is issued.
- **Serial Port Protection:** Enables/Disables the Invalid Access Lockout feature for the serial SetUp Port. (Default = Off.)
- **Lockout Attempts:** The number of invalid attempts that must occur in order to trigger the Invalid Access Lockout feature at the serial SetUp Port. (Default = 9.)
- **Lockout Duration:** This option selects the length of time that the serial SetUp Port will remain locked when Invalid Access Lockout occurs. If the duration is set at "Infinite", then ports will remain locked until the /UL command is issued. (Default = 30 Minutes.)

- **SSH Protection:** Enables/Disables and configures the Invalid Access function for SSH connections. When this item is enabled and excessive Invalid Access Attempts via SSH are detected, then the VMR/NPS will lock out the offending MAC address for the user-defined SSH Lockout Duration Period or until the /UL command is issued. Note that for SSH protection, the lockout trigger is a function of the SSH Hit Count parameter and the SSH Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for SSH connections. (Default = Off.)
- **SSH Hit Count:** The number of invalid attempts that must occur during the length of time specified by the SSH Lockout Duration period in order to trigger the Invalid Access Lockout feature for SSH protocol. For example, if the SSH Hit Count parameter is set to 10 and the SSH Lockout Duration parameter is set to 30 minutes, then the VMR/NPS will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20.)
- **SSH Lockout Duration:** This option selects both the length of time that an SSH Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When an SSH Lockout occurs, the offending MAC address will be prevented from establishing an SSH connection to the VMR/NPS for the defined SSH Lockout Duration period. (Default = 2 Seconds.)
- **Telnet Protection:** Enables/Disables and configures the Invalid Access function for Telnet connections. When this item is enabled and excessive Invalid Access Attempts via Telnet are detected, then the VMR/NPS will lock out the offending MAC address for the user-defined Telnet Lockout Duration Period or until the /UL command is issued. Note that for Telnet protection, the lockout trigger is a function of the Telnet Hit Count parameter and the Telnet Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for Telnet connections. (Default = Off.)
- **Telnet Hit Count:** The number of invalid attempts that must occur during the length of time specified by the Telnet Lockout Duration period in order to trigger the Invalid Access Lockout feature for the Telnet protocol. For example, if the Telnet Hit Count parameter is set to 10 and the Telnet Lockout Duration parameter is set to 30 minutes, then the VMR/NPS will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20.)
- **Telnet Lockout Duration:** This option selects both the length of time that a Telnet Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When a Telnet Lockout occurs, the offending MAC address will be prevented from establishing a Telnet connection to the VMR/NPS for the defined Telnet Lockout Duration period. (Default = 2 Seconds.)



- **Web Protection:** Enables/Disables and configures the Invalid Access function for Web connections. When this item is enabled and excessive Invalid Access Attempts via Web are detected, then the VMR/NPS will lock out the offending MAC address for the user-defined Web Lockout Duration Period or until the /UL command is issued. Note that for Web protection, the lockout trigger is a function of the Web Hit Count parameter and the Web Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for web connections. (Default = Off.)
- **Web Hit Count:** The number of invalid attempts that must occur during the length of time specified by the Web Lockout Duration period in order to trigger the Invalid Access Lockout feature for Web access. For example, if the Web Hit Count parameter is set to 10 and the Web Lockout Duration parameter is set to 30 minutes, then the VMR/NPS will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20.)
- **Web Lockout Duration:** This option selects both the length of time that a Web Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When a Web Lockout occurs, the offending MAC address will be prevented from establishing a Web connection to the VMR/NPS for the defined Telnet Lockout Duration period. (Default = 2 Seconds.)

### 6.2.3. Log Configuration

This feature allows you to create records of command activity, alarm actions, temperature readings and current and power consumption for the VMR/NPS unit. The Log features are enabled and configured via the System Parameters Menu.

- **Audit Log:** Creates a record of all power switching at the VMR/NPS unit, including reboots and switching caused by Load Shedding, Load Shedding Recovery, Ping No Answer Reboots and Scheduled Reboots. Each Log record includes a description of the activity that caused the power switching, the username for the account that initiated the power switching or reboot and the time and date that the power switching or reboot occurred. In addition to power switching activity, the Audit Log will also include login/logout activity for each user account.
- **Alarm Log:** Creates a record of all Alarm Activity at the VMR/NPS unit. When an alarm is triggered, the VMR/NPS will generate a record that lists the time and date of the alarm, the name of the Alarm triggered, and a description of the Alarm.
- **Temperature Log:** (NPS Only) The Temperature Log provides a record of temperature levels over time at the NPS unit. Each Log record will include the time and date, and the temperature reading.
- **Current Metering Log:** (VMR Only) Provides a record of current consumption. Log records include the time and date, current and voltage readings and temperature readings. Current Metering Log data can be downloaded in ASCII, CSV or XML format.

#### Notes:

- *Current and Power Metering functions are not available on NPS units.*
- *In VMR units, temperature data is included in the Current History Log. In NPS Units, a separate Temperature Log is included to display temperature data.*

#### 6.2.3.1. Audit Log and Alarm Log Configuration Options

The Log Configuration options in the System Parameters menu allows you to enable/disable and configure the Audit Log and Alarm Log. The Audit Log and Alarm Log both offer the following parameters:

- **Off:** The Log is disabled, and command activity and/or alarm events will not be logged.
- **On - With Syslog:** The Log is enabled, and power switching, login/logout activity and/or alarm events will be logged. The VMR/NPS will generate a Syslog Message every time a Log record is created.
- **On - Without Syslog:** The Log is enabled, and power switching, login/logout activity and/or alarm events will be logged, but the VMR/NPS will *not* generate a Syslog Message every time a Log record is created. (Default Setting.)

#### Notes:

- *In order for the Audit Log or Alarm Log to generate Syslog Messages, Syslog Parameters must first be defined as described in Section 11.*
- *The Audit Log will truncate usernames that are longer than 22 characters, and display two dots (..) in place of the remaining characters.*

### 6.2.3.2. The Temperature Log (NPS Units Only)

The System Parameters menu allows you to either enable or disable the Temperature Log. When the Temperature Log is disabled, NPS units will not log temperature readings. In the default state, the Temperature Log is enabled.

**Note:** *The Temperature Log is not available on VMR units; instead, temperature values for the VMR unit can be displayed in the Text Interface via the Current Metering Log or in the Web Browser Interface via the Current Metering Status Screen.*

### 6.2.3.3. Reading, Downloading and Erasing Logs

To read or download the status logs, proceed as follows:

- **Text Interface:** Type `/L` and press **[Enter]** to access the Display Log menu. Select the desired option, key in the appropriate number, press **[Enter]** and then follow the instructions in the "Display Logs" submenu. In the text interface, the Display Logs menu is used to download or display the Audit Log and Alarm Log as well as the Current Metering Log (VMR only), Power Metering Log (VMR only) and Temperature Log (NPS only.)
- **Web Browser Interface:** Move the cursor over the "Current Metering," "Power Metering" or "Logs" link. When the flyout menu appears, click on the desired option and then follow the instructions in the resulting submenu.

**Notes:**

- *You can also display current readings via the Current Metering function (VMR units only.) In the Text Interface, type `/M` and then press **[Enter]**.*
- *NPS units do not support current metering functions.*

Proceed as follows to download, display or erase logged data:

- **Audit Log and Alarm Log:** The Audit Log and Alarm Log can be displayed or downloaded via either the Text Interface or Web Browser Interface. When the Audit Log or Alarm Log are displayed via the Text Interface, the VMR/NPS will also offer the option to erase Audit Log or Alarm Log data.
- **Temperature Log:** (NPS Only) The Temperature Log can be displayed or downloaded via either the Text Interface or Web Browser Interface. When the Temperature Log is selected via the Text Interface, the VMR/NPS will also offer the option to erase Temperature Log data.

- **Current Metering Log and Power Metering Log:** (VMR Only) The Current Metering Log and Power Metering Log can be displayed or downloaded via either the Text Interface or Web Browser Interface. When the Current Metering Log is selected via the Text Interface, the VMR/NPS will also offer the option to erase Current Metering Log data.

**Notes:**

- *Current and Power Metering functions are not available on NPS units.*
- *In VMR units, temperature data is included in the Current History Log. In NPS Units, there is a separate Temperature Log.*
- *When the Current Metering Log is erased, the Power Metering Log and Temperature Log will also be erased (VMR Units only.)*
- *The VMR/NPS dedicates a fixed amount of internal memory for log records, and if log records are allowed to accumulate until memory is filled, data will eventually "wrap around," and older data will be overwritten by newer data.*
- *Note that once records have been erased, they cannot be recovered.*

#### 6.2.3.4. Current Metering Log Display Options (VMR Only)

When the Current Metering Log (or Current History) is displayed, the VMR offers the option to display Current Metering data for either the entire unit or branch or for an individual plug. In addition, the Web Browser Interface also allows you to view Current Metering data for either plug groups or individually selected plugs, and also allows you to display Live current metering data, or data from the past day, week, month or year.

#### 6.2.3.5. Power Metering Log Display Options (VMR Only)

When the Power Metering Log (or Power History) is displayed, the VMR offers the option to display Power Metering data for a user specified date range, for either the entire unit or branch or for an individual plug. In addition, the Web Browser Interface also allows you to view Power Metering data for either plug groups or individually selected plugs, and also you to display Live power metering data, or data from the past day, week, month or year.

#### 6.2.4. Callback Security

The Callback function provides an additional layer of security when callers attempt to access command mode via modem. When this function is properly configured, modem users will not be granted immediate access to command mode upon entering a valid password; instead, the unit will disconnect, and dial a user-defined number before allowing access via that number. If desired, users may also be required to re-enter the password *after* the VMR/NPS dials back.

In order for Callback Security to function properly, you must first enable and configure the feature via the System Parameters menu as described in this section, and then define a callback number for each desired user account as described in Section 6.4.

To access the Callback Security menu via the Text Interface, type `/F` and press **[Enter]** and then select the Callback Security option. To access the Callback Security menu via the Web Browser Interface, place the cursor over the General Parameters link, wait for the flyout menu to appear, and then Click on the "Callback Security" link. In both the Text Interface and Web Browser Interface, the Callback Security Menu offers the following options:

- **Callback Enable:** This prompt offers five different configuration options for the Callback Security feature: (Default = On - Callback (Without Password Prompt))
  - ◆ **Off:** All Callback Security is disabled.
  - ◆ **On - Callback (Without Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the login prompt will *not* be displayed when the user's modem answers. If the account *does not* include a Callback Number, that user will be granted immediate access.
  - ◆ **On - Callback (With Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the login prompt *will* be displayed when the user's modem answers (accounts that include a Callback Number will be required to re-enter their username/password when their modem answers.) If the account *does not* include a Callback Number, then that user will be granted immediate access.
  - ◆ **On - Callback ONLY (Without Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the username/password prompt will *not* be displayed when the user's modem answers. Accounts that *do not* include a Callback Number will *not* be able to access command mode via modem.
  - ◆ **On - Callback ONLY (With Password Prompt):** Callbacks will be performed for accounts that include a Callback Number, and the username/password prompt *will* be displayed when the user's modem answers (users will be required to re-enter their username/password when their modem answers.) Accounts that *do not* include a Callback Number will *not* be able to access command mode via modem.

- **Callback Attempts:** The number of times that the VMR/NPS will attempt to contact the Callback number. (Default = 3 attempts.)
- **Callback Delay:** The amount of time that the VMR/NPS will wait between Callback attempts. (Default = 30 seconds.)

**Notes:**

- *After configuring and enabling Callback Security, you must then define a callback phone number for each desired user account (as described in Section 6.4) in order for this feature to function properly.*
- *When using the "On - Callback (With Password Prompt)" option, it is important to remember that accounts that do not include a callback number will be allowed to access command mode without callback verification.*

**6.2.5. Power Source Configuration (VMR Only)**

The Power Configuration menu allows you to adjust power measurements in order to obtain a more accurate determination of how much "real power" is being used by devices connected to the VMR. Real Power is determined by the following equation:

$$\text{Real Power} = \frac{(\text{Voltage} * \text{Amps}) * \text{Power Factor}}{\text{Power Efficiency}}$$

To define Power Configuration parameters, access the command mode using an account that permits access to Administrator level commands and then activate the System Parameters Menu.

**Notes:**

- *Current and Power Metering functions are not available on NPS units.*
- *In the Text Interface, power source configuration parameters are defined via the Power Configuration menu.*
- *In the Web Browser Interface, power source configuration parameters are selected via the System Parameters menu.*

The following Power Source Configuration parameters are available:

- **Voltage Calibration:** This option is used to calibrate the voltage readout on the VMR front panel. To calibrate the voltage, first determine the approximate voltage and then select the Voltage Calibration option and key in the correct voltage. In the Web Browser Interface, the voltage is entered at the System Parameters menu in the Voltage Calibration field. In the Text Interface, the voltage is entered in a submenu of the System Parameters menu. (Default = undefined.)
- **Power Factor:** Can be any value from 0.1 to 1.00. (Default = 1.00.)
- **Power Efficiency:** Can be any whole number from 1% to 100%. (Default = 100%.)

### 6.2.6. Scripting Options

The Scripting Options submenu provides access to parameters that are used to set up the VMR/NPS unit for running various scripts.

#### Notes:

- *The functions provided by the Scripting Options menu are intended for use in applications where scripts are employed to control VMR/NPS operation. Improper use of Scripting Options menu functions can cause the VMR/NPS unit to become unresponsive. Prior to attempting to use the functions provided by the Scripting Options menu, please contact WTI Technical Support as described in Appendix C in this User's Guide.*
- *To access Scripting Options parameters via the Text Interface, first type /E and press [Enter] to display the System Parameters Menu, then key in the number for the Scripting Options item and press [Enter].*
- *To access the Scripting Options parameters via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear, then click on the "Scripting Options" link.*

The Scripting Options menu allows the following parameters to be defined:

- **Command Confirmation:** Enables/Disables the Command Confirmation feature. When enabled, a "Sure" prompt will be displayed before power switching and reboot commands are executed. When disabled, commands will be executed without further prompting. (Default = On.)
- **Automated Mode:** When enabled, the VMR/NPS will execute switching and reboot commands without displaying a confirmation prompt, status screen or confirmation messages. For more information, please refer to Section 6.2.6.1 or Section 5.4. (Default = Off.)

**Note:** *When the Automated Mode is enabled, security functions are suppressed, and users are able to access configuration menus and control plugs without entering a password. If security is a concern and the Automated Mode is required, it is recommended to use the IP Tables feature (Section 6.3.2) to restrict access.*

- **Command Prompt:** Allows the Text Interface command prompt to be set to either MPC, IPS, NPS, NBB, VMR, CCM, RPC or the currently defined Site ID Message. (Default for VMR units = VMR; Default for NPS units = NPS.)

- **IPS Mode:** This parameter sets up the VMR/NPS for use with command scripts that were written for WTI's IPS Series Remote Reboot Switches. When the IPS Mode is enabled, the "IPS" command prompt will be displayed in the Text Mode, User Accounts will not allow definition of a Username, and only the "password" prompt will be displayed when logging into the unit (IPS Mode units will not display a "username" prompt.) (Default = Off.)
  - The "IPS" command prompt will be displayed in the Text Mode.
  - Providing that no Administrator level user accounts are defined, the VMR/NPS will not display the username or password prompts upon login to command mode.
  - If one or more Administrator level user accounts have been defined, then the VMR/NPS will only display the password prompt upon login to command mode. If all Administrator level user accounts (aside from the default "super" account) are deleted, then the VMR/NPS will return to the status where no username or password prompts are displayed upon login to command mode.
- **Emergency Shutoff:** Enables/disables the Emergency Shutoff Feature. The Emergency Shutoff function can be used to immediately shut off all specified power outlets on a VMR/NPS Series unit in case of emergency. For more information, please refer to Section 5.7. (Default = Off)
- **Emergency Shutoff Auto Recovery:** Enables/Disables the Emergency Shutoff Auto Recovery feature. When enabled, following an Emergency Shutoff, all plugs will return to the On/Off status that was selected prior to the Emergency Shutoff. (Default = Off)
- **Single Plug Boot Delay Enable:** When this parameter is enabled and reboot cycle is initiated, the VMR/NPS will pause for the currently defined Boot/Sequence Delay value before executing the next reboot command. Note that the Boot/Sequence Delay value is defined via the Plug Parameters menu, as described in Section 6.7. (Default = Off.)
- **U-Boot Plugs Enable:** When enabled, after a power interruption, the VMR/NPS will switch on all power outlets before the VMR/NPS operating system has finished loading. This allows power to be reapplied to connected devices such as servers and routers as quickly as possible after a power interruption. (Default = Off)
- **Voltage Loss Delay Options:** Determines how VMR/NPS Series Units with Dual Power Inlets will react when power to one inlet is lost. The Voltage Loss Delay Options allow the unit to automatically turn off outlets and delay the Lost Voltage Alarm when power to one inlet is lost.
  - **Turn Plugs Off Enable:** When enabled, after power to one inlet is lost, the unit will wait for the defined Voltage Loss Delay period and then switch Off all outlets on the branch that was supported by the inlet that has lost power. (Default = Off)
  - **Voltage Loss Delay:** Determines how long the unit will pause before generating a Lost Voltage Alarm and switching off the outlets after power to one of the inlets is lost. (Default = 12 Seconds)



- **Reverse DNS:** Determines the manner in which ARP requests are handled. When enabled (On,) the unit will check an external DNS in order to resolve domain names. When disabled (Off,) the unit will not check an external DNS when resolving domain names. (Default = On)
- **Port 1 Mode Override:** In order to ensure local access to VMR/NPS command functions, normally Serial Port 1 can only be configured as a Passive Mode Port or Any-to-Any Mode Port. When the Port 1 Mode Override option is enabled, Serial Port 1 can be configured as a Buffer Mode Port, Modem Mode Port or Modem PPP Mode Port. (Default = Off)

**Note:** *Configuring Serial Port 1 as a Buffer Mode Port can disable local access to VMR/NPS command functions via serial port.*

- **Keep Alive:** In cases where Linux regularly times out and disrupts network communication with the unit, this parameter can be used to keep the network connection active. (Default = 7,200 Seconds)

#### 6.2.6.1. Automated Mode

The Automated Mode allows the VMR/NPS to execute switching and reboot commands, without displaying menus or generating response messages. Automated Mode is designed to allow the VMR/NPS to be controlled by a device which can generate commands to control power switching functions without human intervention.

When Automated Mode is enabled, power switching and reboot commands are executed without a confirmation prompt and without command response messages; the only reply to these commands is the command prompt, which is re-displayed when each command is completed.

Although Automated Mode can be enabled using either the Web Browser Interface or Text Interface, Automated Mode is designed primarily for users who wish to send ASCII commands to the VMR/NPS without operator intervention, and therefore does not specifically apply to the Web Browser Interface. When Automated Mode is enabled, the Web Browser Interface can still be used to invoke switching and reboot commands.

#### **Notes:**

- *When the Automated Mode is enabled, password prompts will not be displayed at login, and you will be able to access Administrator Level command functions (including the configuration menus) and control plugs without entering a password.*
- *If you need to enable the Automated Mode, but want to restrict network access to configuration menus, it is strongly recommended to enable and configure the IP Security Function as described in Section 6.8.2.*

To enable/disable the Automated Mode, go to the System Parameters menu (see Section 6.2.) and then set the “Automated Mode” option to “On”. When Automated Mode is enabled, VMR/NPS functions will change as follows:

1. **All Password Security Suppressed:** When a user attempts to access command mode, the password prompt will not be displayed at either the Setup Port or Network Port. Unless specifically restricted by the IP Security Function, all users will be allowed to access both switching and configuration functions, and all commands will be immediately accepted without the requirement to enter a password.
2. **Status Screen Suppressed:** The plug status screen will not be automatically displayed after commands are successfully executed. Note however, that the /S command can still be invoked to display the status screen as needed.
3. **“Sure?” Prompt Suppressed:** All commands are executed without prompting for user confirmation.
4. **Error Messages Suppressed:** Most error messages will be suppressed. Note however, that an error message will still be generated if commands are invoked using invalid formats or arguments.

All other status display and configuration commands will still function as normal.

## 6.3. User Accounts

Each time you attempt to access command mode, you will be prompted to enter a username and password. The username/password entered at login determine which outlet(s) you will be allowed to control and what type of commands you will be allowed to invoke. Each username/password combination is defined within a "user account."

The VMR/NPS allows up to 128 user accounts; each account includes a username, password, security level, plug access rights, service access rights and an optional callback number.

### 6.3.1. Command Access Levels

In order to restrict access to important command functions, the VMR/NPS allows you to set the command access level for each user account. The VMR/NPS offers four access levels: Administrator, SuperUser, User and View Only. Command privileges for each account are set using the Add User or Modify User menus.

Each access level grants permission to use a different selection of commands; lower access levels are restricted from invoking configuration commands, while Administrators are granted access to all commands. The four different access levels are listed below:

- **Administrator:** Administrators are allowed to invoke all configuration and power switching commands, can view all status screens, and can always direct switching commands to all VMR/NPS switched outlets.
- **SuperUser:** SuperUsers are allowed to invoke all power switching commands and view all status screens. SuperUsers can view configuration menus, but are not allowed to change configuration parameters. SuperUsers are granted access to all VMR/NPS outlets.
- **User:** Users are allowed to invoke power switching commands and view all status screens, but can only apply commands to outlets that they are specifically granted access to. In addition, Users are not allowed to view configuration menus or change configuration parameters.
- **ViewOnly:** Accounts with ViewOnly access, are allowed to view Status Menus, but are not allowed to invoke switching commands, and cannot view configuration menus or change parameters. ViewOnly accounts can display the Plug Status screen, but can only view the status of plugs that are allowed by the account.

Section 17.2 summarizes command access for all four access levels.

In the default state, the VMR/NPS includes one predefined account that provides access to Administrator commands and allows control of all VMR/NPS switched power outlets. The default username for this account is "**super**" (lowercase, no quotation marks), and the password for the account is also "**super**".

#### Notes:

- *In order to ensure security, it is recommended that when initially setting up the unit, a new user account with Administrator access should be created, and the "super" account should then be deleted.*
- *If the VMR/NPS is reset to default parameters, all user accounts will be cleared, and the default "super" account will be restored.*

### 6.3.2. Granting Plug Access

Each account can be granted access to a different selection of power outlets (plugs) and plug groups. When accounts are created, the Plug Access parameter and the Plug Group Access parameter in the Add User menu or Modify User menu are used to grant or deny access to each plug or plug group. In addition, each access level also restricts the plugs and plug groups that the account will be allowed to access:

- **Administrator:** Administrator level accounts are always allowed to control all plugs and plug groups. Plug access cannot be disabled for Administrator level accounts.
- **SuperUser:** SuperUser accounts allow access to all plugs and plug groups. Plug access cannot be disabled for SuperUser accounts.
- **User:** User level accounts are only allowed to issue switching commands to the plugs and plug groups that have been specifically permitted via the "Plug Access" parameter in the Add User and Modify User menus.
- **ViewOnly:** ViewOnly level accounts are not allowed to issue switching commands. ViewOnly accounts can display the On/Off state of plugs and plug groups, but are limited to the plugs and plug groups specified by the account.

### 6.3.3. Granting Port Access

The Port Access parameter is used to grant or deny access to the VMR/NPS RJ45 Setup Port. Normally, the Setup port is used for connection to a local control device or an external modem.

The command access level will also determine which ports the account will be allowed to access, as summarized below:

- **Administrator and SuperUser:** Accounts with Administrator or SuperUser level command access are always allowed to connect to the Setup Port. Port access cannot be disabled for Administrator and SuperUser level accounts.
- **User:** User level accounts are only allowed to connect to the Setup Port when port access has been specifically enabled for the account.
- **ViewOnly:** Accounts with ViewOnly access are not allowed to create connections to the Setup Port.

## 6.4. Managing User Accounts

The User Directory function is employed to create new accounts, display parameters for existing accounts, modify accounts and delete accounts. Up to 128 different user accounts can be created. The "User Directory" function is only available when you have logged into command mode using an account that permits Administrator commands.

In both the Text Interface and the Web Browser Interface, the User Directory menu offers the following functions:

- **View User Directory:** Displays currently defined parameters for any VMR/NPS user account as described in Section 6.4.1.
- **Add Username:** Creates new user accounts, and allows you to assign a username, password, command level, plug access plug group access, service access and callback number, as described in Section 6.4.2.
- **Modify User Directory:** This option is used to edit or change account information, as described in Section 6.4.3.
- **Delete User:** Clears user accounts, as described in Section 6.4.4.

**Note:** *After you have finished selecting or editing user account parameters, make certain to save the new account information before proceeding. In the Web Browser Interface, click on the "Add User" button to save parameters; in the Text Interface, press the [Esc] key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 6.4.1. Viewing User Accounts

The "View User Directory" option allows you to view details about each account. The View User option will not display actual passwords, and instead, the password field will read "defined". The View User Accounts function is only available when you have accessed command mode using a password that permits Administrator Level commands.

### 6.4.2. Adding User Accounts

The "Add Username" option allows you to create new accounts. Note that the Add User function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Add User Menu can define the following parameters for each new account:

**Note:** *After you have finished selecting or editing account parameters, make certain to save the new account information before proceeding. In the Web Browser Interface, click on the "Add User" button to save parameters; in the Text Interface, press the [Esc] key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

- **Username:** Up to 32 characters long, and cannot include non-printable characters. Duplicate usernames are not allowed. (Default = undefined.)
- **Password:** Five to sixteen characters long, and cannot include non-printable characters. Note that passwords are case sensitive. (Default = undefined.)

- **Authorization Keys:** This item can be used to assign an SSH Authorization Key to the user account, view assigned authorization keys or delete assigned authorization keys. When a valid authorization key is assigned to a given user, that user will be able to access VMR/NPS command mode without entering a password. When assigning an authorization key, the VMR/NPS offers the option to define a name for the key and upload a key from the user's server. (Default = undefined)
- **Access Level:** Determines which commands this account will be allowed to access. This option can set the access level for this account to "Administrator", "SuperUser", "User" or "ViewOnly." For more information on Command Access Levels, please refer to Section 6.3.1 and Section 17.2. (Default = User.)
- **Port Access:** Determines whether or not the account will be allowed to connect to the serial Setup Port. (Defaults; Administrator and SuperUser = Always Enabled, User = Disabled.)

**Note:** *ViewOnly level accounts cannot be granted access to the Setup Port.*

- **Plug Access:** Determines which outlet(s) this account will be allowed to control. (Defaults; Administrator and SuperUser = All Plugs On, User = All Plugs Off, ViewOnly = All Plugs Off.)

**Notes:**

- *Administrator and SuperUser level accounts always have access to all plugs.*
  - *User level accounts will only have access to the plugs that are defined via the "Plug Access" parameter.*
  - *ViewOnly accounts are allowed to display the Plug Status Screen, but are limited to the plugs specified by the account. ViewOnly accounts are not allowed to invoke switching and reboot commands.*
- **Plug Group Access:** Determines which plug groups this account will be allowed to control. For more information on Plug Groups, please refer to Section 6.5. (Defaults; Administrator and SuperUser = All Plug Groups On, User = All Plug Groups Off, ViewOnly = All Plug Groups Off.)

**Notes:**

- *In order to use this feature, Plug Groups must first be defined as described in Section 6.5.*
- *Administrator and SuperUser level accounts will always have access to all plug groups.*
- *User Level accounts will only have access to the plug groups that are defined via the Plug Group Access parameter.*
- *ViewOnly accounts are allowed to display the On/Off status of plug groups via the Plug Status Screen, but are limited to the plug groups specified by the account. ViewOnly accounts are not allowed to invoke switching and reboot commands.*

- **Service Access:** Determines whether this account will be able to access command mode via Serial Port, Telnet/SSH or Web and whether or not the account will be allowed to initiate outbound connections. For example, if Telnet/SSH Access is disabled for this account, then this account will not be able to access command mode via Telnet or SSH. (Default = Serial Port = On, Telnet/SSH = On, Web = On, Outbound Access = Off.)

**Note:** *The Service Access Parameter is only used to select permitted access services for an individual user account. To separately enable/disable all SSH or Telnet Access for the VMR/NPS unit, please refer to Section 6.8.*

- **Current/Power Metering:** (VMR Only) Enables/Disables current and power metering for this account. When disabled, this account will not be able to view current or power readings or display current or power history. Note that in order for accounts to be able to display these logs, Current and Power Metering must be enabled via the Systems Parameters menu as described in Section 6.2. (Default = On.)

**Note:** *Current and Power Metering functions are not available on NPS units.*

- **Callback Phone Number:** Assigns a number that will be called when this account attempts to access command mode via modem, and the Callback Security Function has been enabled as described in Section 6.2.4. (Default = undefined.)

**Notes:**

- *If the Callback Number is not defined, then Callbacks will not be performed for this user.*
- *If the Callback Number is not defined for a given user, and the Callback Security feature is configured to use either of the "On - Callback" options, then this user will be granted immediate access to command mode via modem.*
- *If the Callback Number is not defined for a given user, and the Callback Security feature is configured to use the "On - Callback ONLY" option, then this user will not be able to access command mode via Modem.*
- *When using the "On - Callback (With Password Prompt)" option, it is important to remember that accounts that do not include a callback number will be allowed to access command mode without callback verification.*

### 6.4.3. Modifying User Accounts

The "Edit User Directory" function allows you to edit existing accounts in order to change parameters, plug access rights or Administrator Command capability. Note that the Edit/Modify User function is only available when you have accessed command mode using a password that permits Administrator Level commands. Once you have accessed the Modify Users menu, use the menu options to redefine parameters in the same manner employed for the Add User menu, as discussed in Section 6.4.2.

**Note:** *After you have finished changing parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify User" button to save parameters; in the Text Interface, press the [Esc] key several times until the VMR/NPS displays the "Saving Configuration" message.*

### 6.4.4. Deleting User Accounts

This function is used to delete individual user accounts. Note that the Delete User function is only available when you have accessed command mode using a password that permits Administrator Level commands.

**Notes:**

- Deleted accounts cannot be automatically restored.
- The VMR/NPS allows you to delete the default "super" account, which is included to permit initial access to command mode. Before deleting the "super" account, make certain to create another account that permits Administrator Access. If you do not retain at least one account with Administrator Access, you will not be able to invoke Administrator level commands.



## 6.5. The Plug Group Directory

The Plug Group Directory allows you to designate "groups" of plugs that are dedicated to a similar function, and will most likely be switched or rebooted all at the same time or controlled by the same type of user account.

For example, an individual equipment rack might include an assortment of devices that belong to different departments or clients. In order to simplify the process of granting plug access rights to the accounts that will control power to these devices, you could assign all of the plugs for the devices belonging to Department A to a Plug Group named "Dept\_A", and all of the plugs for devices belonging to Department B to a Plug Group named "Dept\_B". When user accounts are defined later, this would allow you to quickly grant access rights for all of the plugs for the devices belonging to Department A to the appropriate user accounts, by merely granting access to the Dept\_A Plug Group, rather than by selecting the specific, individual plugs for each user account.

Likewise, Plug Groups allow you to direct On/Off/Boot commands to a series of plugs, without addressing each plug individually. Given the example above, you could quickly reboot all plugs for Department A, by either including the "Dept\_A" Plug Group name in a /BOOT command line via the Text Interface, or by using the Plug Group Control menu in the Web Browser Interface.

The Plug Group Directory function is only available when you have logged into command mode using an account that permits Administrator commands. In both the Text Interface and the Web Browser Interface, the Plug Group Directory menu offers the following functions:

- **View Plug Group Directory:** Displays currently defined plug access rights for any VMR/NPS Plug Group as described in Section 6.5.1.
- **Add Plug Group to Directory:** Creates new Plug Groups, and allows you to assign plug access rights to each group as described in Section 6.5.2.
- **Modify Plug Group Directory:** This option is used to edit or change plug access rights for each Plug Group, as described in Section 6.5.3.
- **Delete Plug Group from Directory:** Clears Plug Groups that are no longer needed, as described in Section 6.5.4.

### 6.5.1. Viewing Plug Groups

The "View Plug Group Directory" option allows you to view the configuration of each Plug Group. Note that the View Plug Group Directory function is only available when you have accessed command mode using a password that permits Administrator Level commands. In the Web Browser Interface, the Plug Group Directory can be viewed by clicking on the link on the left hand side of the page. In the Text Interface, the Plug Group Directory can be viewed by typing /G and pressing **[Enter]** and then selecting the option from the resulting submenu.

### 6.5.2. Adding Plug Groups

The "Add Plug Group to Directory" option allows you to create new Plug Groups and assign plug access rights to each group. The Add Plug Group function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Add Plug Group Menu can be used to define the following parameters for each new account:

- **Plug Group Name:** Assigns a name to the Plug Group. (Default = undefined.)
- **Plug Access:** Determines which plugs this Plug Group will be allowed to control. (Default = undefined.)

#### **Notes:**

- *In the Text Interface, Plug Access is configured by selecting item 2 and then selecting the desired plugs from the resulting submenu.*
- *In the Web Browser Interface, Plug Access is configured by selecting the desired plugs from a list of all plugs in the Add Plug Group menu.*
- *After you have finished defining or editing Plug Group parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Plug Group" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 6.5.3. Modifying Plug Groups

The "Modify Plug Group" function allows you to edit existing Plug Groups in order to change plug access rights. Note that this function is only available when you have accessed command mode using a password that permits Administrator Level commands. Once you have accessed the Modify Plug Group menu, use the menu options to redefine parameters in the same manner that is used for the Add Plug Group menu, as discussed in Section 6.5.2.

**Note:** *After you have finished changing or editing parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify Plug Groups" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 6.5.4. Deleting Plug Groups

This function is used to delete individual Plug Groups. Note that this function is only available when you have accessed command mode using a password that permits Administrator Level commands.

**Note:** *Deleted Plug Groups cannot be automatically restored.*

## 6.6. Defining Plug Parameters

The Plug Parameters Menu is used to define Plug Names, boot/sequence delay times and Power Up Default values for each VMR/NPS Switched AC Outlets. Note that this function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Plug Parameters Menu allows you to define the following parameters:

- **Plug Name:** (Up to 16 Characters, Default = undefined.)

**Note:** *Plug Names must begin with either a lower case alphabetic letter or upper case alphabetic letter. Plug Names cannot begin with a number character or symbol character.*

- **Boot/Seq. Delay:** When more than one plug is switched On or a reboot cycle is initiated, the Boot/Sequence delay determines how much time will elapse before the next plug is switched On. When the Boot/Sequence Delay is applied, the VMR/NPS will wait for the user-defined delay period before switching On the next plug. When Reboot cycles and switching actions are initiated, the Boot/Sequence Delay will be applied as follows: (Default = 0.5 Second.)
  - ◆ **Reboot Cycle Delay:** During a reboot cycle, the VMR/NPS will first switch all selected plugs "Off" (with a 0.5 second pause between each "Off" operation), and then begin to switch selected plugs back On again, pausing for the user-defined Boot/Sequence Delay before switching On the next plug. For example, if the Boot/Sequence Delay for Plug 3 is ten seconds, then the VMR/NPS will pause for ten seconds before proceeding to the next plug.
  - ◆ **"On" Sequence Delay:** When two or more plugs are switched On, the VMR/NPS will pause for the user-defined Boot/Sequence Delay before switching the next plug.
- **Power Up Default:** Determines how this plug will react when the Default command (/DPL) is invoked, or after power to the unit has been interrupted and then restored. After the default command is invoked, or power is restored, the VMR/NPS will automatically switch each plug On or Off as specified by the Power-Up Default. (Default = On).

**Note:**

- *If you have accessed command mode using an account that permits Administrator or SuperUser level commands, then the Default command will be applied to all switched plugs.*
- *If you have accessed command mode via an User Level account, then the Default command will only be applied to plugs allowed by your account.*
- *The Default command is not available to ViewOnly level accounts.*
- **Boot Priority:** When commands are applied to two or more plugs, the Boot Priority parameter determines the order in which the plugs will be switched On. The Plug that has been assigned a Boot Priority of "1" will always be switched on first, followed by the plug that has been assigned the Boot Priority of "2", and so forth. When you assign a boot priority to any given plug, then all subsequent plugs will have their priority lowered by one. For more information on the Boot Priority parameter, please refer to Section 6.6.1. (Default = All plugs prioritized according to Plug Number)

### 6.6.1. The Boot Priority Parameter

Normally, when an "On" or "Reboot" command is invoked, the VMR/NPS will switch on its plugs in their default, numeric order. Although in many cases, the default, numeric order will work fine, there are other cases where an individual device (such as a router) must be switched on first, in order to support a second device that will be switched on later.

The Boot Priority Parameter simplifies the process of setting the order in which plugs are switched On, by assigning a priority number to each plug, rather than by requiring the user to make certain that devices are always connected to the VMR/NPS in a set order. Likewise, when new devices are added to your equipment rack, the Boot Priority Parameter eliminates the need to unplug all existing devices and then rearrange the plugs connected to the VMR/NPS (and re-define plug parameters) to ensure that they are switched on in the desired order.

**Notes:**

- *No two plugs can be assigned the same Boot Priority number.*
- *When a higher Boot Priority is assigned to any given plug, all subsequent plugs will have their boot priorities lowered by a factor of 1.*
- *The Boot Priority is also displayed on the Plug Status Screen.*

#### 6.6.1.1. Example 1: Change Plug A3 to Priority 1

In the Example shown in Figure 6.1, we start out with all Plugs set to their default Boot Priorities, with Plug A1 first, Plug A2 second and so forth.

Next, the Boot Priority for Plug A3 is changed to Priority 1. This means that Plug A3 will now be switched On first after a reboot, and that Plug A1 will now be switched On second, Plug A2 will be third, etc..

Note that when the Boot Priority for Plug A3 is set to 1, the Boot Priorities for all plugs that were previously Booted before plug A1 are now lowered by a factor of one.

BEFORE (Plug No.)	Priority	(Assign Plug A3 to Priority 1)	AFTER (Plug No.)	Priority
(A1)	1		(A1)	2
(A2)	2		(A2)	3
(A3)	3	→ (1) →	(A3)	1
(A4)	4		(A4)	4
(A5)	5		(A5)	5
(A6)	6		(A6)	6

Figure 6.1: Boot Priority Example 1

6.6.1.2. Example 2: Change Plug A5 to Priority 2

In the second Example shown in Figure 6.2, we start out with Boot Priorities for the plugs set as they were at the end of Example 1; Plug A3 is first, Plug A1 is second, Plug A2 is third, Plug A4 is fourth, and Plug A6 is sixth.

Next, the Boot Priority for Plug A5 is changed to Priority 2. This means that Plug A3 will continue to be switched on first after a reboot, but now Plug A5 will be switched on second, Plug A3 will be third, Plug A2 will be fourth, Plug A4 will be fifth and Plug A6 will still be sixth.

Once again, note that when the Boot Priority for Plug A5 is set to 2, the Boot Priorities for all plugs that were previously Booted before plug A5 are now lowered by a factor of one

<b>BEFORE</b> <b>(Plug No.) Priority</b>	<b>(Assign Plug A5 to Priority 2)</b>	<b>AFTER</b> <b>(Plug No.) Priority</b>
(A1) 2		(A1) 3
(A2) 3		(A2) 4
(A3) 1		(A3) 1
(A4) 4		(A4) 5
(A5) 5	→ (2) →	(A5) (2)
(A6) 6		(A6) 6

Figure 6.2: Boot Priority Example 2

## 6.7. Serial Port Configuration

The Serial Port Configuration menus allow you to select parameters for the VMR/NPS serial Setup Port. The Serial Port can be configured for connection to a local PC or external, dial-up Modem. The Serial Port Configuration menu (Port Parameters) can be used to set communications parameters, disable Administrator level commands at the serial Setup Port and also select a number of other Setup Port Parameters.

**Note:** *If you are configuring the VMR/NPS via modem, modem parameters will not be changed until after you exit command mode and disconnect from the unit.*

### 6.7.1. The Serial Port Configuration Menu

To access the Serial Port Configuration menu via the Text Interface, type /P and then press [Enter]. To configure the Serial Ports via the Web Browser Interface, click the "Serial Port Configuration" link on the left hand of the screen.

The Serial Port Configuration menu allows the following parameters to be defined. Note that all of these parameters are available via both the Text Interface and Web Browser Interface, and that parameters selected via one interface are also applied to the other.

#### Communication Settings:

- **Baud Rate:** Any standard rate from 300 bps to 230 kbps. (Default = 9600 bps).
- **Bits/Parity:** (Default = 8-None).
- **Stop Bits:** (Default = 1).
- **Handshake Mode:** XON/XOFF, RTS/CTS (hardware), Both, or None. (Default = RTS/CTS).

#### General Parameters:

- **Administrator Mode:** In WTI console server products, this parameter is used to permit or deny port access to Administrator level accounts. In VMR/NPS products, Administrator access to the serial port cannot be disabled.
- **Logoff Character:** The Logoff Character determines the command(s) or character(s) that must be issued at this port in order to disconnect this port from another port. Note that the Logoff Character does not apply to Direct Connections. (Default = ^X.)
- **Sequence Disconnect:** Enables/Disables and configures the disconnect command. This item offers the option to disable the Sequence Disconnect, select a one character format or a three character format. (Default = One Character.)
- **Inactivity Timeout:** Enables and selects the Timeout Period for this port. If enabled, the Setup Port will disconnect when no additional data activity is detected for the duration of the timeout period. (Default = 5 Minutes.)
- **Command Echo:** Enables or Disables command echo at the Setup Port. When disabled, commands that are sent to the Setup Port will still be invoked, but the actual keystrokes will not be displayed on your monitor. (Default = On.)

- **Accept Break:** Determines whether the port will accept breaks received from the attached device. When enabled, breaks received at the port will be passed to any port that this port is connected to. When disabled, breaks will be refused at this port. (Default = On.)

**Port Mode Parameters:**

- **Port Name:** Allows you to assign a name to the Setup Port. (Default = undefined.)
- **Port Mode:** Selects the port mode for the Serial port. The port mode can be set to Normal Mode, Modem Mode or Modem PPP Mode. (Default = Normal Mode)

Depending on the Port Mode selected, the VMR/NPS will display additional prompts listed below. In the Text Interface, these parameters are accessible via a submenu, which will only be active when the appropriate port mode is selected. In the Web Browser Interface, fields will be "grayed out" unless the corresponding port mode is selected.

- ◆ **Normal Mode:** Allows communication with a local PC and permits access to command mode. When the Normal Mode is selected, the following mode-specific parameter can also be defined:
  - **DTR Output:** Determines how DTR will react when the port disconnects. DTR can be held low, held high, or pulsed for 0.5 seconds and then held high. (Default = Pulse.)
- ◆ **Modem Mode:** Permits access to command mode and simplifies connection to an external modem. Modem Mode ports can perform all functions normally available in Normal Mode, but Modem Mode also allows definition of the following, additional parameters:

**Note:** *When communicating with the VMR/NPS via modem, these parameters will not be changed until after you exit command mode and disconnect.*

- **Modem Reset String:** Redefines the modem reset string. The Reset String can be sent prior to the Initialization string. (Default = **ATZ.**)
- **Modem Initialization String:** Defines a command string that can be sent to initialize a modem to settings required by your application. (Default = **AT&C1&D2S0=1&B1&H1&R2**)
- **Modem Hang-Up String:** Although the VMR/NPS will pulse the DTR line to hang-up an attached modem, the Hang-Up string is often useful for controlling modems that do not use the DTR line. (Default = undefined.)
- **Reset/No Dialtone Interval:** Determines how often the Reset String will be sent to the modem at this port and also sets the trigger value for the No Dialtone Alarm. For more information on the No Dialtone Alarm, please refer to Section 8.10. (Default = 15 Minutes)
- **No Dialtone Alarm Enable:** When this item is "On" the No Dialtone Alarm can be enabled as described in Section 8.10. When the No Dialtone Alarm is enabled and properly configured, the VMR/NPS can provide notification if the unit detects that a phone line connected to a modem installed at this port is dead. (Default = Off.)

- **Reset/No Dialtone Scaler:** Determines the number of Periodic Modem Reset sequences that must occur in order to initiate a No Dialtone Check. If this parameter is set to "0," then the No Dialtone Alarm will not function. When both this parameter and the Reset/No Dialtone Interval are set to a value from 1 to 99 and the No Dialtone Alarm is enabled, the VMR/NPS will initiate a No Dialtone Check after a time period equal to the defined Reset/No Dialtone Interval value multiplied by the Reset/No Dialtone Scaler value. (Default = 16)
- ◆ **Modem PPP Mode:** Allows data that is normally sent via ethernet to be sent via phone line. When Modem PPP Mode is selected, the following modem-related parameters will be available:

**Note:** *When communicating with the VMR/NPS via modem, these parameters will not be changed until after you exit command mode and disconnect.*

- **Reset String:** Redefines the modem reset string. The Reset String can be sent prior to the Initialization string. (Default = **ATZ**.)
- **Initialization String:** Defines a command string that is used to initialize the modem to settings required for PPP communication (Default = **ATQ0V1E1S0=0&C1&D2**)
- **Hang-Up String:** Although the VMR/NPS will pulse the DTR line to hang-up an attached modem, the Hang-Up string is often useful for controlling modems that do not use the DTR line. (Default = undefined.)
- **Reset/No Dialtone Interval:** Determines how often the Reset String will be sent to the modem at this port and also sets the trigger value for the No Dialtone Alarm. For more information on the No Dialtone Alarm, please refer to Section 8.10. (Default = 15 Minutes)
- **No Dialtone Enable:** When this item is "On" the No Dialtone Alarm can be enabled as described in Section 8.10. When the No Dialtone Alarm is enabled, the VMR/NPS can provide notification if the unit detects that a phone line connected to a modem installed at this port is dead. (Default = Off.)
- **Reset/No Dialtone Scaler:** Determines the number of Periodic Modem Reset sequences that must occur in order to initiate a No Dialtone Check. If this parameter is set to "0," then the No Dialtone Alarm will not function. When both this parameter and the Reset/No Dialtone Interval are set to a value from 1 to 99 and the No Dialtone Alarm is enabled, the VMR/NPS will initiate a No Dialtone Check after a time period equal to the defined Reset/No Dialtone Interval value multiplied by the Reset/No Dialtone Scaler value. (Default = 16)
- **Periodic Reset Location:** The IP address or URL for the website that will be used to keep the PPP connection alive when not in use. The VMR/NPS will regularly ping the selected IP address or URL in order to keep the connection alive. (Default = undefined)

**Notes:**

- *In order to select a domain name as the Periodic Reset Location, you must first define the Domain Name Servers as described in Section 6.8.4.*
- *The IP Address, P-t-P and Subnet Mask parameters cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication is started..*



- **PPP Phone Number:** The phone number for the line that will be used for PPP communication. (Default = undefined)
- **User Name:** The user name for the ISP account that will be used for PPP communication. (Default = undefined)
- **Password:** The password for the ISP account that will be used for PPP communication (Default = undefined)
- **IP Address:** The temporary IP address that will be assigned to the PPP communication session by the ISP. Note that this item cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication session is started. (Default = undefined)
- **P-t-P:** This item cannot be defined by the user and will be automatically set by the ISP when a PPP communication session is started. (Default = undefined)
- **Subnet Mask:** This item cannot be defined by the user and will be automatically set by the ISP when a PPP communication session is started. (Default = undefined)

## 6.8. Network Configuration

The Network Parameters Menus are used to select parameters and options for the Network Port and also allow you to implement IP Security features, which can restrict access based on the user's IP Address.

Although the Web Browser Interface and Text Interface allow definition of essentially the same parameters, parameters are arranged differently in the two interfaces. In the Text Interface, most network parameters are defined via one menu which is accessed using the /N command. In the Web Browser Interface, network parameters are divided into separate menus which are accessed via the Network Configuration flyout menu.

### Notes:

- *Settings for network parameters depend on the configuration of your network. Please contact your network administrator for appropriate settings.*
- *The Network Parameters Menu selects parameters for all 16 logical Network Ports.*
- *The IP Address, Subnet Address and Gateway Address cannot be changed via the Web Browser Interface. In order to change these parameters, you must access the unit via the Text Interface.*
- *When a new IP Address is selected, or the status of the DHCP feature is changed, the unit will disconnect and reconfigure itself with the new values when you exit the Network Parameters Menu. When configuring the unit, make certain your DHCP server is set up to assign a known, fixed IP address in order to simplify reconnection to the unit after the new address has been assigned. DHCP Parameters cannot be changed via the Web Browser Interface.*
- *The Network Parameters menu is only available when you have logged into command mode using an account and port that permit Administrator level commands (Supervisor Mode enabled.)*

### **The Network Configuration Menus:**

The Network Configuration menus allow you to define both IPv4 parameters and IPv6 parameters for the Ethernet Port. Although there are slight differences in the manner in which the Web Interface and Text Interface Network are organized, both interfaces provide access to essentially the same set of network parameters (with a few noted exceptions.)

Since the network configuration menus must allow definition of network parameters for two different IP protocols, parameters have been divided into two different submenus. These submenus are accessed via the Network Selection menu.

To access the Network Selection menu, proceed as follows:

- **Text Interface:**  
Type **/n\*** and then press **[Enter]** to display the Network Selection menu. At the Network Selection menu, key in the number for the desired protocol and then press **[Enter]**.
- **Web Browser Interface:** Click on the Network Configuration link on the left hand side of the screen to display the Network Selection menu. When the Network Selection menu appears, click on the desired protocol. Alternately, the Network Configuration link's flyout menu can also be used to select the desired protocol.

The Network Selection menu offers access to two Network Configuration submenus:

- **Port Eth0, IPv4 Protocol** (Plus Shared Parameters)
- **Port Eth0, IPv6 Protocol**

Note that the VMR/NPS's Network Configuration Menus are used to define parameters that are shared by all VMR/NPS both IP protocols, plus parameters that are specific to only one IP protocol. Since the majority of these shared parameters are concentrated in the Eth0/IPv4 submenu, it is recommended that when defining network parameters, to first define the parameters found in the Shared (Eth0, IPv4,) submenu, and then proceed to the submenu for IPv6 protocol.

### 6.8.1. Network Port Parameters

**Note:** *The IP Address, Subnet Mask, Subnet Prefix, Gateway Address and DHCP status cannot be changed via the Web Browser Interface. In order to change these parameters, you must access the VMR/NPS via the Text Interface.*

- **IP Address:** (Defaults: IPv4 = 192.168.168.168; IPv6 = undefined)
- **Subnet Mask:** (IPv4 Only; Default = 255.255.255.0)
- **Subnet Prefix:** (IPv6 Only; Default = undefined)
- **Gateway Address:** (Default = undefined.)
- **DHCP:** Enables/Disables Dynamic Host Configuration Protocol. When this option is "On", the VMR/NPS will perform a DHCP request. Note that in the Text Interface, the MAC address for the VMR/NPS is listed on the Network Status Screen. (Default = Off.)

**Note:** *Prior to configuring this feature via Telnet/SSH or Web, make certain that your DHCP server is set up to assign a known, fixed IP address. You will need this new IP address in order to reestablish a network connection with the VMR/NPS unit.*

- **IP Tables:** This parameter can be used to restrict network access to the VMR/NPS command mode as described in Section 6.8.2. (Default = Off)
- **Static Route:** Provides access to a submenu that is used to enable and define Static Route functions as described in Section 6.8.3. (Default = Off)
- **DNS Services:** Provides access to a submenu that is used to define DNS services and DDNS services as described in Section 6.8.4. (Default = undefined)
- **Negotiation:** This parameter can be used to solve synchronization problems when the VMR/NPS unit negotiates communication parameters with another device. (Default = Auto)

#### Notes:

- *If the other device is set for automatic negotiation, then the VMR/NPS's Negotiation parameter should also be set to Auto.*
- *If the other device is not set for automatic negotiation, then the VMR/NPS's Negotiation parameter should be set to match the other device (e.g., "100/Full.)*
- **Administrator Mode:** Permits/denies port access to accounts that allow Administrator or SuperUser level commands. When enabled (Permit), the port will be allowed to invoke Administrator and SuperUser level commands, providing they are issued by an account that permits them. If disabled (Deny), then accounts that permit Administrator and SuperUser level commands will not be allowed to access command mode via this port. (Default = Permit)
- **Logoff Character:** Defines the Logoff Character for this port. This determines which command(s) must be issued at this port in order to disconnect from a second port. (Default = ^x ([Ctrl] plus [X]).)

**Note:** *The Sequence Disconnect parameter can be used to pick a one character or a three character logoff sequence.*

- **Sequence Disconnect:** Enables/Disables and configures the Resident Disconnect command. Offers the option to either disable the Sequence Disconnect, or select a one character, or three character command format. (Default = One Character).

**Notes:**

- *The One Character Disconnect is intended for situations where the destination port should **not** receive the disconnect command. When the Three Character format is selected, the disconnect sequence **will** pass through to the destination port prior to breaking the connection.*
- *When Three Character format is selected, the Resident Disconnect uses the format "[Enter]LLL[Enter]", where L is the selected Logoff Character.*
- **Inactivity Timeout:** Enables and selects the Inactivity Timeout period for the Network Port. If enabled, and the port does not receive or transmit data for the specified time period, the port will disconnect. (Default = 5 Minutes).
- **Command Echo:** Enables or Disables the command echo for the Network Port. (Default = On).
- **Accept Break:** Determines whether the port will accept breaks received from the attached device, and pass them along to a connected port. When enabled, breaks received at this port will be passed to any port this port is connected to, and sent to the device connected to the other port. When disabled, breaks will be refused at this port. (Default = On.)
- **Telnet Access:** Enables/disables Telnet access. When Telnet Access is "Off," users will not be allowed to establish a Telnet connection to the unit. Note that in the Text Interface, this item also provides access to the "Telnet Port" and "Maximum per Source" parameters. (Default = On.)

**Note:** *In the Text Interface, the Telnet Access submenu also allows you to select the Telnet Port and set the Max Per Source value. In the Web Browser Interface, these parameters are set via the Shared Network Parameters menu.*
- **Telnet Port:** Selects the TCP/IP port number that will be used for Telnet connections. In the Text Interface, this item is defined via a submenu, displayed when the Telnet Access parameter is selected. (Default = 23.)

**Note:** *In the Text Interface, the Telnet Port number is defined via a submenu, which is displayed when the Telnet Access parameter is selected. In the Web Browser Interface, the Telnet Port parameter is set via the Shared Network Parameters menu.*
- **Max. Per Source:** The maximum number of Telnet sessions that will be allowed per user MAC address. (Default = 4.)

**Notes:**

- *In the Text Interface, the "Per Source" parameter is defined via the Telnet Access submenu in the Network Parameters menu.*
- *After changing the "Max Per Source" parameter, you must log out of all pre-existing Telnet sessions in order for the new maximum value to be applied.*

- **SSH Access:** Enables/disables SSH communication. (Default = On.)

**Note:** *In the Text Interface, the SSH Access submenu also allows you to select the SSH Port and other parameters. In the Web Browser Interface, some of these parameters are set via the Shared Network Parameters menu.*

- **SSH Port:** Selects the TCP/IP port number that will be used for SSH connections.

**Note:** *In the Text Interface, this option is defined via the SSH Access submenu. (Default = 22.)*

- **SSH Security Level:** (Text Interface Only) Sets the SSH Security Level to either Normal or High. (Default = Normal.)

**Notes:**

- *In the Text Interface, the SSH Security Level is defined via the SSH Access submenu.*
- *The SSH Security Level parameter is not available via the Web Browser Interface.*
- **SSH View Port Enable:** (Text Interface Only) Allows monitoring of Serial Port activity. (Default = Off)

**Notes:**

- *In the Text Interface, the SSH View Port Enable parameter is defined via the SSH Access submenu.*
- *The SSH View Port Enable parameter is not available via the Web Browser Interface.*
- **SSH View Port Bidirection:** (Text Interface Only) Allows monitoring of bidirectional Serial Port Activity. (Default = Off)

**Notes:**

- *In the Text Interface, the SSH View Port Bidirection parameter is defined via the SSH Access submenu.*
- *The SSH View Port Bidirection parameter is not available via the Web Browser Interface.*

- **Web Access:** Enables/disables the Web Browser Interface. When disabled, users will not be allowed to communicate with the unit via the Web Browser Interface. (Default = Off.)

**Notes:**

- *In the Text Interface, additional Web Access configuration parameters are accessed via a submenu which is displayed when the Web Access parameter is selected.*
- *In the Web Browser Interface, Web Access parameters are accessed via the Web Access menu.*
- *When the Web Access parameter is accessed via the Text Interface, the resulting submenu will also allow you to select SSL/TLS (encryption) parameters as described in Section 14.*

- **HTTP Port:** Selects the TCP/IP port number that will be used for Web Access. (Default = 80.)

**Notes:**

- *In the Text Interface, the HTTP Port parameter is accessed via the Web Access submenu.*
  - *In the Web Browser Interface, the HTTP Port parameter is accessed via the Web Access menu.*
- **HTTPS Access:** Enables/disables HTTPS communication. For instructions on setting up SSL encryption, please refer to Section 14. (Default = On.)

**Notes:**

- *In the Text Interface, the HTTPS Access parameter is accessed via a Web Access submenu.*
  - *In the Web Browser Interface, the HTTPS Access parameter is accessed via the Web Access menu.*
- **HTTPS Port:** Selects the TCP/IP port number that will be used for HTTPS connections. (Default = 443.)

**Note:** *In the Text Interface, HTTP and HTTPS parameters are defined via the Web Access submenu. The resulting Web Access submenu will also allow you to select SSL/TLS (encryption) parameters as described in Section 14.*

- **Harden Web Security:** When the Harden Web Security feature is On (default,) only the high and medium cypher suites for SSLv3 and TLSv1 will be enabled. When the Harden Web Security feature is Off, all SSL protocols will be enabled, allowing compatibility with older browsers. (Default = On.)

**Notes:**

- *In the Text Interface, this option is enabled/disabled via the Web Access submenu.*
  - *In the Web Browser Interface, the Harden Web Security parameter is accessed via the Web Access menu.*
- **TLS Mode:** Selects TLSv1 or TLSv1.1. Although TLSv1.1 provides better security, the default settings of most browsers do not support TLSv1.1. For more information, please refer to Section 14.5. (Default = TLSv1)

**Notes:**

- *In the Text Interface, the TLS Mode parameter is located in the Web Access submenu.*
- *In the Web Browser Interface, the TLS Mode parameter is defined via the Web Access menu.*

- **Trace Method:** Enables/disables the Web Trace Method. (Default = Off)

**Notes:**

- *In the Text Interface, the Trace Method parameter is accessed via the Web Access submenu.*
- *In the Web Browser Interface, the Trace Method parameter is accessed via the Web Access menu.*
- **SYSLOG Addresses:** Defines the IP addresses for the Syslog Daemon(s) that will receive log records generated by the VMR/NPS. Allows definition of IP addresses for both a primary Syslog Daemon and an optional secondary Syslog Daemon. SYSLOG Addresses can be entered in either IPv4 or IPv6 format, or in domain name format (up to 64 characters.) For more information, please refer to Section 11. (Default = undefined.)

**Notes:**

- *The Syslog Address submenu in the Text Interface and the Network Parameters submenu in the Web Browser Interface both include a Ping Test function that can be used to ping the user-selected Syslog IP Addresses in order to verify that valid IP addresses have been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined Syslog Addresses in order to make certain that the IP addresses are responding.*
- **SNMP Access:** Displays a submenu which is used to define SNMP Access parameters as described in Section 6.8.5.
- **SNMP Trap Parameters:** Displays a submenu which is used to define SNMP Trap parameters as described in Section 6.8.6.
- **LDAP:** Displays a submenu which is used to define LDAP parameters as described in Section 6.8.7.
- **TACACS:** Displays a submenu which is used to define TACACS parameters as described in Section 6.8.8.
- **RADIUS:** Displays a submenu which is used to define RADIUS parameters as described in Section 6.8.9.
- **Ping Access:** Configures the VMR/NPS's response to ping commands. Ping Access can be set to block all ping commands, allow all ping commands or only accept ping commands from user specified IP addresses (Limited.) When the "Limited" option is selected, up to four permitted IP address can be defined via the submenu. Note that disabling Ping Access at the Network Port will not effect the operation of the Ping-No-Access Alarm. (Default = Allow All)



- **Multiple Logins:** (Text Interface Only) If the VMR/NPS is installed in an environment that *does not* include communication via an open network (local communication only), then the Multiple Logins parameter can be used to determine whether or not multiple users will be able to communicate with the unit at the same time. If this parameter is set to "Off" then only one user will be allowed to communicate with the unit at a time. (Default = On)
- **Email Messaging:** Displays a submenu which is used to define Email Messaging parameters as described in Section 6.8.10.
- **Raw Socket Access:** Enables/disables Raw Socket Protocol access to the Network Port via Direct Connect and selects the port number for Raw Socket Access. This item can be used to enable or disable Raw Socket Protocol access and select either port 23 or port 3001 for use for Raw Socket connections. (Default = Off.)

**Notes:**

- *The Raw Socket Access option is often helpful for users who encounter network problems when attempting to communicate with the VMR/NPS using a script that was previously written for our legacy IPS product line.*
- *If the "On (23)" option is selected, you must either disable Telnet Port 23 or use the Telnet Access option to select a port other than Port 23.*
- *When the Raw Socket Access option is enabled, you must connect to the VMR/NPS using the port number selected for Raw Socket Access. For example, if the VMR/NPS IP address is "1.2.3.4", and port 3001 has been selected for Raw Socket Access, in order to establish a Raw Socket connection to the VMR/NPS's Network Port, then on a UNIX system, the connection command would be: \$ telnet 1.2.3.4 3001 [Enter].*

### 6.8.2. IP Tables

The IP Tables allow the VMR/NPS to restrict unauthorized IPv4 or IPv6 format IP addresses from establishing inbound connections to the unit. If you wish to restrict access to the VMR/NPS unit, you can employ the IP Tables menu to define a firewall which determines which IP addresses will be allowed to access the VMR/NPS command mode and which IP addresses will be denied. To define the firewall, proceed as follows:

1. Use the Text Interface or Web Browser interface to access the IP Tables menu as described in Section 6.8.
2. When the IP Tables menu is displayed, use Linux syntax to determine which IP address(es) will be allowed access and which IP address(es) will be denied. In most cases, the IP Tables should allow access to administrators and deny access to everybody else.

### 6.8.3. Static Route

The Static Route menu allows you to define Linux routing commands that will be automatically executed each time that a user accesses command mode via the corresponding Network Port or optional Cellular Modem Port.

### 6.8.4. DNS Services

The DNS option is used to define DNS and DDNS parameters. In the Network Configuration menu, the DNS option can be used to access either the DNS Parameters menu or the DDNS parameters menu.

#### 6.8.4.1. DNS Parameters

The DNS Parameters menu is used to select IPv4 or IPv6 format IP addresses for Domain Name Servers. When web and network addresses are entered, the Domain Name Server interprets domain names (e.g., www.wti.com), and translates them into IP addresses. Note that if you don't define at least one DNS server, then IP addresses must be used, rather than domain names. Note that parameters defined via this menu will be applied to both IPv4 and IPv6 communication.

The Domain Name Server menu includes a Ping Test feature that allows you to ping the IP addresses for each user-defined domain name server in order to check that a valid IP address has been entered.

**Note:** *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*

#### 6.8.4.2. DDNS Parameters

The DDNS Parameters menu is used to select parameters and define hosts for Dynamic DNS services. The DDNS Parameters menu includes the following parameters::

- **Services:** This item is used to set the service type to either Dyn or None. (Default = None)
- **Host Name:** The IP Address for the DDNS Service. (Default = undefined)
- **Username:** (Default = undefined)
- **Password:** (Default = undefined)
- **Maximum Update Times:** Determines how often the VMR/NPS will ping the DDNS host address. (Default = Every 1 Hour)

#### 6.8.5. SNMP Access Parameters

These menus are used to select access parameters for the SNMP feature. In the Text Interface, the SNMP Access Parameters menu is accessed via the Network Configuration menu. In the Web Browser Interface, the SNMP Access Parameters menu is accessed via the flyout menus under the Network Configuration link.

##### Notes:

- *After you have configured SNMP Access Parameters, you will then be able to manage the VMR/NPS's User Directory and display unit status via SNMP, as described in Section 13.*
- *In the Text Interface, SNMP Access Parameters are defined via two separate menus that are accessed via either the `/N` command (IPv4) or the `/N6` command (IPv6.)*
- *In the Web Browser interface, both IPv4 and IPv6 SNMP Access Parameters are defined via a single menu. When defining IPv6 parameters, make certain that the IPv6 checkbox in the SNMP Access Parameters menu is checked.*

The SNMP Access Parameters menu allows the following parameters to be defined:

- **Enable:** Enables/disables SNMP Polling. (Default = Off.)  
**Note:** *This item only applies to external SNMP polling of the VMR/NPS; it does not effect the ability of the VMR/NPS to send SNMP traps.*
- **Version:** Determines which SNMP Version the VMR/NPS will respond to. For example, if this item is set to V3, then clients who attempt to contact the VMR/NPS using SNMPv2 will not be allowed to connect. (Default = V1/V2 Only.)
- **Read Only:** Enables/Disables the "Read Only Mode", which controls the ability to access configuration functions and invoke switching commands. When Enabled ("Yes"), you will not be able to change configuration parameters or invoke other commands when you contact the VMR/NPS via SNMP. (Default = No.)

**Note:** *In order to define user names for the VMR/NPS via your SNMP client, the Read Only feature must be disabled. When the Read Only feature is enabled, you will not be able to issue configuration commands to the VMR/NPS unit via SNMP.*

- **Authentication / Privacy:** Configures the Authentication and Privacy features for SNMPv3 communication. The Authentication / Privacy parameter offers two options, which function as follows:
  1. **Auth/noPriv:** An SNMPv3 username and password will be required at log in, but encryption will not be used. (Default Setting.)
  2. **Auth/Priv:** An SNMPv3 username and password will be required at log in, and all messages will be sent using encryption.

**Notes:**

- *The Authentication / Privacy item is not available when the Version parameter is set to V1/V2.*
- *If the Version Parameter is set to V1/V2/V3 (all) and Authentication / Privacy parameter is set to "Auth/Priv", then only V3 data will be encrypted.*
- *The VMR/NPS supports DES encryption, but does not currently support the AES protocol.*
- *The VMR/NPS does not support "noAuth/noPriv" for SNMPv3 communication.*
- **SNMPv3 User Name:** Sets the User Name for SNMPv3. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined.)
- **SNMPv3 Password:** Sets the password for SNMPv3. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined.)
- **SNMPv3 Password Confirm:** This prompt is used to confirm the SNMPv3 password that was entered at the prompt above. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined.)
- **Authentication Protocol:** This parameter determines which authentication protocol will be used. The VMR/NPS supports both MD5 and SHA1 authentication. (Default = MD5.)

**Notes:**

- *The Authentication Protocol that is selected for the VMR/NPS must match the protocol that your SNMP client will use when querying the VMR/NPS unit.*
- *The Authentication Protocol option is not available when the Version parameter is set to V1/V2*
- **Privacy Protocol:** (SNMPv3 Only) Selects AES or DES encryption support. (Default = DES)  
**Note:** *SNMPv2 does not support encryption.*
- **System Name:** (Default = undefined)
- **SNMP Contact:** (Default = undefined.)
- **SNMP Location:** (Default = undefined.)
- **Read Only Community:** Note that this parameter is not available when the SNMP Version is set to V3. (Default = Public.)
- **Read/Write Community:** Note that this parameter is not available when the SNMP Version is set to V3. (Default = Public.)

### 6.8.6. SNMP Trap Parameters

These menus are used to select parameters that will be used when SNMP traps are sent. For more information on SNMP Traps, please refer to Section 12. In the Text Interface, the SNMP Trap Parameters menu is accessed via the Network Configuration menu. In the Web Browser Interface, the SNMP Trap Parameters menu is accessed via the flyout menus under the Network Configuration link. The SNMP Trap Parameters menu allows the following parameters to be defined:

**Notes:**

- *In the Text Interface, SNMP Trap parameters are defined via two separate menus that are accessed via either the /N command or the /N\* command.*
- *In the web browser interface, SNMP Trap parameters are defined via two separate submenus that are accessed via the IPv4 or IPv6 flyout menus, under the Network Parameters link.*
- **SNMP Managers 1 through 4:** The IP Addresses for the SNMP Managers. For more information, please refer to Section 12. (Default = Undefined)  
**Note:** *In order to enable the SNMP Trap feature, you must define at least one SNMP Manager.*
- **Trap Community:** (Default = Public)
- **Trap Version:** The assigned security level for SNMP traps. (Default = V1)
- **V3 Trap Engine ID:** The V3 SNMP agent's unique identifier. (Default = undefined)
- **Ping Test:** Allows you to ping the IP addresses or domain names defined via the SNMP Manager 1 and SNMP Manager 2 prompts in order to check that a valid IP address or domain name has been entered.

**Notes:**

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined SNMP Managers in order to make certain that the IP addresses are responding.*

### 6.8.7. LDAP Parameters

The VMR/NPS supports LDAP (Lightweight Directory Access Protocol,) which allows authentication via the "Active Directory" network Directory Service. When LDAP is enabled and properly configured, command access rights can be granted to new users without the need to define individual new accounts at each VMR/NPS unit, and existing users can also be removed without the need to delete the account from each VMR/NPS unit. This type of authentication also allows administrators to assign users to LDAP groups, and then specify which plugs the members of each group will be allowed to control at each VMR/NPS unit.

In order to apply the LDAP feature, you must first define User Names and associated Passwords and group membership via your LDAP server, and then access the VMR/NPS command mode to configure LDAP settings and define port access rights and command access rights for each group specified at the LDAP server.

#### Notes:

- *Plug access rights are not defined at the LDAP server. They are defined via the LDAP Group configuration menu on each VMR/NPS unit and are specific to that VMR/NPS unit alone.*
- *When LDAP is enabled, LDAP authentication will supersede any passwords and access rights that have been defined via the VMR/NPS user directory.*
- *If no LDAP groups are defined on a given VMR/NPS unit, then access rights will be determined as specified by the "default" LDAP group.*
- *The "default" LDAP group cannot be deleted.*

The LDAP Parameters Menu allows you to define the following parameters:

- **Enable:** Enables/disables LDAP authentication. (Default = Off)
- **Primary Host IPv4:** Defines the IP address or domain name for the primary LDAP server when IPv4 protocol is used to communicate with the VMR/NPS unit. (Default = undefined)
- **Primary Host IPv6:** Defines the IP address or domain name for the primary LDAP server when IPv6 protocol is used to communicate with the VMR/NPS unit. (Default = undefined)
- **Secondary Host IPv4:** Defines the IP address or domain name for the secondary (fallback) LDAP server when IPv4 protocol is used. (Default = undefined)
- **Secondary Host IPv6:** Defines the IP address or domain name for the secondary (fallback) LDAP server when IPv6 protocol is used. (Default = undefined)
- **LDAP Port:** Defines the port that will be used to communicate with the LDAP server. (Default = 389)
- **TLS/SSL:** Enables/Disables TLS/SSL encryption. Note that when TLS/SSL encryption is enabled, the LDAP Port should be set to 636. (Default = Off)
- **Bind Type:** Sets the LDAP bind request password type. In the Text Interface, when the Bind Type is set to "Kerberos," the LDAP menu will include an additional prompt used to select Kerberos parameters. (Default = Simple)

- **Search Bind DN:** The username that will be allowed to search the LDAP directory. (Default = undefined)
- **Search Bind Password:** The Password for the user who is allowed to search the LDAP directory. (Default = undefined)
- **User Search Base DN:** The directory location for user searches. (Default = undefined)
- **User Search Filter:** Selects the attribute that lists the user name. Note that this attribute should always end with "=%s" (no quotes.) (Default = undefined)
- **Group Membership Attribute:** Selects the attribute that list group membership(s). (Default = undefined)
- **Group Membership Value Type:** (Default = DN)
- **Fallback:** Enables/Disables the LDAP fallback feature. When enabled, the VMR/NPS will revert to it's own internal user directory if no defined users are found via the LDAP server. In this case, port access rights will then be granted as specified in the default LDAP group. (Default = Off)
- **Kerberos Setup:** Kerberos is a network authentication protocol, which provides a secure means of identity verification for users who are communicating via a non-secure network. In the Text Interface, Kerberos parameters are selected via a submenu that is only available when Kerberos is selected as Bind Type. In the Web Browser Interface, Kerberos parameters are defined via the main LDAP Parameters menu. The following parameters are available:
  - ◆ **Port:** (Default = 88.)
  - ◆ **Realm:** (Default = Undefined.)
  - ◆ **Key Distribution Centers (KDC1 through KDC5):** (Default = Undefined.)
  - ◆ **Domain Realms 1 through 5:** (Default = Undefined.)
- **LDAP Group Setup:** Provides access to a submenu, which is used to define LDAP Groups as described in the Sections 6.8.7.1 through 6.8.7.4.
- **Debug:** This option is used to assist WTI Technical Support personnel with the diagnosis of LDAP issues. (Default = Off)
- **Ping Test:** Allows you to ping IP addresses or domain names that have been defined via the LDAP Parameters menus in order to check that a valid IP address or domain name has been entered.

**Notes:**

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

#### 6.8.7.1. Adding LDAP Groups

Once you have defined users and passwords via your LDAP server, and assigned users to LDAP Groups, you must then grant command and port access rights to each LDAP Group at each individual VMR/NPS unit. In order to Add an LDAP Group, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Add LDAP Group menu allows the following to be defined:

- **Group Name:** Note that this name must match the LDAP Group names that you have assigned to users at your LDAP server. (Default = undefined.)
- **Access Level:** Sets the command access level to either Administrator, SuperUser, User or ViewOnly. For more information on Access Levels, please refer to Section 6.3.1. (Default = User.)
- **Port Access:** Enables/disables this LDAP Group's access to the serial Setup Port. (Default = undefined.)
- **Plug Access:** Determine which plugs members of this group will be allowed to control. (Default = undefined.)
- **Plug Group Access:** Determines which plug groups the members of this LDAP Group will be allowed to control. (Default = undefined.)
- **Service Access:** Selects access methods for this LDAP Group. Determines whether members of this LDAP Group will be allowed to access command mode via Serial Port, Telnet/SSH, Web and/or to establish outbound connections. Also enables/disables Outbound Telnet. (Default; Serial Port = On, Telnet/SSH = On, Outbound Access = Off.)
- **Current/Power Metering:** (VMR Only) Determines whether or not members of this LDAP Group will be allowed to view current, voltage and temperature readings.

**Notes:**

- *Current and Power Metering functions are not available on NPS units.*
- *After you have defined LDAP Group parameters, make certain to save changes before proceeding. In the Web Browser Interface, click on the "Add LDAP Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the VMR/NPS displays the "Saving Configuration" message.*

#### 6.8.7.2 Viewing LDAP Groups

If you need to examine an existing LDAP group definition, the "View LDAP Groups" function can be used to review the group's parameters and Plug Access Settings.



### 6.8.7.3. Modifying LDAP Groups

If you want to modify an existing LDAP Group in order to change parameters or plug access rights, the "Modify LDAP Group" function can be used to reconfigure group parameters. To Modify an existing LDAP Group, you must access the VMR/NPS command mode using a password that permits access to Administrator Level commands. Once you have accessed the Modify LDAP Group menu, use the menu options to redefine parameters in the same manner that is used for the Add LDAP Group menu, as discussed in Section 6.8.7.1.

**Note:** *After you have finished modifying LDAP Group parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify LDAP Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 6.8.7.4. Deleting LDAP Groups

The Delete LDAP Group function is used to delete LDAP Groups that are no longer in use. In order to delete an existing LDAP Group, you must access the VMR/NPS command mode using a password that permits access to Administrator Level commands.

### 6.8.8. TACACS Parameters

The TACACS Configuration Menus offer the following options:

- **Enable:** Enables/disables the TACACS feature at the Network Port. (Default = Off)
- **Primary Address:** Defines the IP address or domain name (up to 64 characters) for your primary TACACS server. (Default = undefined)
- **Secondary Address:** Defines the IP address or domain name (up to 64 characters) for your secondary, fallback TACACS server (if present.) (Default = undefined)
- **Secret Word:** Defines the shared TACACS Secret Word for both TACACS servers. (Default = undefined.)
- **Fallback Timer:** Determines how long the VMR/NPS will continue to attempt to contact the primary TACACS Server before falling back to the secondary TACACS Server. (Default = 15 Seconds)
- **Fallback Local:** Determines whether or not the VMR/NPS will fallback to its own password/username directory when an authentication attempt fails. When enabled, the VMR/NPS will first attempt to authenticate the password by checking the TACACS Server; if this fails, the VMR/NPS will then attempt to authenticate the password by checking its own internal username directory. This parameter offers three options:
  - ◆ **Off:** Fallback Local is disabled (Default)
  - ◆ **On (All Failures):** Fallback Local is enabled, and the unit will fallback to its own internal user directory when it cannot contact the TACACS Server, or when a password or username does not match the TACACS Server.
  - ◆ **On (Transport Failure):** Fallback Local is enabled, but the unit will only fallback to its own internal user directory when it cannot contact the TACACS Server.
- **Authentication Port:** The port number for the TACACS function. (Default = 49)
- **Default User Access:** When enabled, this parameter allows TACACS users to access the unit without first defining a TACACS user account on the VMR/NPS. When new TACACS users access the unit, they will inherit the default access parameters that are defined via the items listed below: (Default = On)
  - **Enable:** Enables/disables the Default User Access function. (Default = On)
  - **Access Level:** Determines the default Access Level setting for new TACACS users. This option can set the default access level for new TACACS users to "Administrator", "SuperUser", "User" or "ViewOnly." For more information on Command Access Levels, please refer to Section 6.3.1 and Section 17.2. (Default = User)

- **Port Access:** Determines the default Port Access setting for new TACACS users. The Port Access setting determines whether or not the account will be allowed to connect to the serial Setup Port. (Defaults; Administrator and SuperUser = Always Enabled, User = Disabled)

**Note:** *ViewOnly level accounts cannot be granted access to the Setup Port.*

- **Plug Access:** Determines the default Plug Access setting for new TACACS users. (Defaults; Administrator and SuperUser = All Plugs On, User = All Plugs Off, ViewOnly = All Plugs Off)

**Notes:**

- *Administrator and SuperUser level accounts always have access to all plugs.*
- *User level accounts will only have access to the plugs that are defined via the "Plug Access" parameter.*
- *ViewOnly accounts are not allowed to invoke switching and reboot commands.*

- **Plug Group Access:** Determines the default Plug Group Access setting for new TACACS users. For more information on Plug Groups, please refer to Section 6.5. (Defaults; Administrator and SuperUser = All Plug Groups On, User = All Plug Groups Off, ViewOnly = All Plug Groups Off.)

**Notes:**

- *In order to use this feature, you must first define at least one Plug Group as described in Section 6.5.*
- *Administrator and SuperUser level accounts will always have access to all plug groups.*
- *User Level accounts will only have access to the plug groups that are defined via the Plug Group Access parameter.*
- *ViewOnly accounts are not allowed to invoke switching and reboot commands.*

- **Service Access:** Selects the default Service Access setting for new TACACS users. Determines whether each account will be able to access command mode via Serial Port, Telnet/SSH or Web. In addition, the Service Access setting also determines whether each account will be able to employ the Outbound Access function. (Default = Serial Port = On, Telnet/SSH = On, Web = On, Outbound Access = Off.)

**Note:** *If Outbound Access has been disabled via the Network Parameters menu, then the Service Access parameter will not be allowed to grant Outbound Access to new TACACS users.*

- **Current/Power Metering:** (VMR Only) Selects the default enable/disable status for the Current/Power Metering setting. When Current/Power Metering is disabled, an account will not be able to view current or power readings or display current or power history. Note that in order for accounts to be able to display these logs, Current and Power Metering must be enabled via the Systems Parameters menu as described in Section 6.2. (Default = Off.)

**Note:** *Current and Power Metering functions are not available on NPS units.*

- **Ping Test (Ping TACACS Servers):** Allows you to ping IP addresses or domain names that have been defined via the TACACS Parameters menus in order to check that a valid IP address or domain name has been entered.

**Notes:**

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

### 6.8.9. RADIUS Parameters

**Notes:**

- *In the Text Interface, the IPv4 and IPv6 RADIUS Parameters menus are accessed via the Network Configuration menu as described in Section 6.8.*
- *In the Web Browser Interface, both IPv4 and IPv6 parameters are defined via a single RADIUS Parameters menu, which is accessed via the flyout menus under the Network Configuration link.*

The RADIUS Configuration Menus offer the following options:

- **Enable:** Enables/Disables the RADIUS feature at the Network Port. (Default = Off)
- **Primary Host:** Defines the IP address or domain name for your primary RADIUS server. (Default = undefined.)
- **Primary Secret Word:** Defines the RADIUS Secret Word for the primary RADIUS server. (Default = undefined)
- **Secondary Host:** Defines the IP address or domain name for your secondary, fallback RADIUS server. (Default = undefined)
- **Secondary Secret Word:** Defines the RADIUS Secret Word for the secondary RADIUS server. (Default = undefined)
- **Fallback Timer:** Determines how long the VMR/NPS will continue to attempt to contact the primary RADIUS Server before falling back to the secondary RADIUS Server. (Default = 3 Seconds)
- **Fallback Local:** Determines whether or not the VMR/NPS will fallback to its own password/username directory when an authentication attempt fails. When enabled, the VMR/NPS will first attempt to authenticate the password by checking the RADIUS Server; if this fails, the VMR/NPS will then attempt to authenticate the password by checking its own internal username directory. This parameter offers three options:
  - ◆ **Off:** Fallback Local is disabled (Default.)
  - ◆ **On (All Failures):** Fallback Local is enabled, and the unit will fallback to its own internal user directory when it cannot contact the Radius Server, or when a password or username does not match the Radius Server.
  - ◆ **On (Transport Failure):** Fallback Local is enabled, but the unit will only fallback to its own internal user directory when it cannot contact the Radius Server.
- **Retries:** Determines how many times the VMR/NPS will attempt to contact the RADIUS server. Note that the retries parameter applies to both the Primary RADIUS Server and the Secondary RADIUS Server. (Default = 3)
- **Authentication Port:** The Authentication Port number for the RADIUS function. (Default = 1812)

- **Accounting Port:** The Accounting Port number for the RADIUS function. (Default = 1813)
- **Debug:** (Text Interface Only) When enabled, the VMR/NPS will put RADIUS debug information into Syslog. (Default = Off)
- **One Time Auth:** This feature should be enabled when using Two Factor Authentication with the One Time Password scheme enabled. When enabled, the One Time Password will be valid for the time specified under the OneTime Auth Timer parameter. (Default = Off)
- **One Time Auth Timer:** When the OneTime Auth parameter is enabled, this parameter determines how long (in minutes) the One Time Password will be valid. (Default = 5 Minutes)
- **Ping Test:** Allows you to ping IP addresses or domain names that have been defined via the RADIUS Parameters menus in order to check that a valid IP address or domain name has been entered.

**Notes:**

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

**6.8.9.1. Dictionary Support for RADIUS**

The RADIUS dictionary file can allow you to define users and assign command access rights and plug access rights from a central location. The RADIUS dictionary file, "dictionary.wti" is included on the CDROM along with this user's guide. To install the dictionary file on your RADIUS server, please refer to the documentation provided with your server; some servers will require the dictionary file to reside in a specific directory location, others will require the dictionary file to be appended to an existing RADIUS dictionary file. The WTI RADIUS dictionary file provides the following commands: .

- **WTI-Super** - Sets the command access level for the user. This command provides the following arguments:

0 = ViewOnly  
 1 = User  
 2 = SuperUser  
 3 = Administrator

For example, to set the access level to "SuperUser", the command line would be:

**WTI-Super="2"**

- **WTI-Plug-Access** - Determines which plug(s) the user will be allowed to access. This command provides an argument that consists of a character string, with one character for each the VMR/NPS's switched outlets. The following options are available:

0 = Off (Deny Access)  
1 = On (Allow Access)

For example, to allow access to Plugs 2 and 4, the command line would be:

**WTI-Plug-Access="0101"**

- **WTI-Group-Access** - Determines which plug group(s) the user will be allowed to access. The argument for this command includes a character for each, defined plug group. The first character in the string is used to represent the first plug group defined, and the last character in the string represents the last plug group defined. The following options are available for each plug group:

0 = Off (Deny Access)  
1 = On (Allow Access)

For example, to allow access to the first three defined plug groups out of a total of six defined plug groups, the command line would be:

**WTI-Group-Access="111000"**

**Example:**

The following command could be used to set the command access level to "User", allow access to Serial Ports 1, 3, 5 and 7 and Plugs 1 and 2, and also allow access to the first two of five defined plug groups:

```
tom Auth-Type:=Local, User-Password=="tom1"  
  Login-Service=Telnet,  
  Login-TCP-Port=Telnet,  
  User-Name="HARRY-tom",  
  WTI-Super="1",  
  WTI-Plug-Access="11000000",  
  WTI-Group-Access="11000",
```

### 6.8.10. Email Messaging Parameters

The Email Messaging menu is used to define parameters for email messages that the VMR/NPS can send to notify you when an alarm is triggered. To define email message parameters, you must access the VMR/NPS Command Mode using a password that permits access to Administrator Level commands. The Email Messaging menu offers the following options:

- **Enable:** Enables/Disables the Email Messaging feature. When disabled, the VMR/NPS will not be able to send email messages when an alarm is generated. (Default = Off)
- **SMTP Server:** This prompt is used to define the address of your SMTP Email server. (Default = undefined)
- **Port Number:** Selects the TCP/IP port number that will be used for email connections. (Default = 25)
- **Domain:** The domain name for your email server. (Default = undefined)  
**Note:** *In order to use domain names, you must first define Domain Name Server parameters as described in Section 6.8.4.*
- **User Name:** The User Name that will be entered when logging into your email server. (Default = undefined)
- **Password:** The password that will be used when logging into your email server. (Default = undefined)
- **Auth Type:** The Authentication type; the VMR/NPS allows you to select None, Plain, Login, or CRAM-MD5 Authentication. (Default = None)
- **From Name:** The name that will appear in the "From" field in email sent by the VMR/NPS. (Default = undefined)
- **From Address:** The email address that will appear in the "From" field in email sent by the VMR/NPS. (Default = undefined)
- **To Address:** The address(es) that will receive email messages generated by the VMR/NPS. Note that up to three "To" addresses may be defined, and that when Alarm Configuration parameters are selected as described in Section 8, you may then designate one, two or all three of these addresses as recipients for email messages that are generated by the alarms. (Default = undefined)
- **Send Test Email:** Sends a test email, using the parameters that are currently defined for the Email configuration menu.



## 6.9. Save User Selected Parameters

It is strongly recommended to save all user-defined parameters to a file as described in Section 15. This will allow quick recovery in the event of accidental deletion or reconfiguration of port parameters.

When changing configuration parameters via the Text Interface, make certain that the VMR/NPS has saved the newly defined parameters before exiting from command mode. To save parameters, press the **[Esc]** key several times until you have exited from all configuration menus and the VMR/NPS displays the "Saving Configuration" menu and the cursor returns to the command prompt. If newly defined configuration parameters are not saved prior to exiting from command mode, then the VMR/NPS will revert to the previously saved configuration after you exit from command mode.

### 6.9.1. Restore Configuration

If you make a mistake while configuring the VMR/NPS unit, and wish to return to the previously saved parameters, the Text Interface's "Reboot System" command (**/I**) offers the option to reinitialize the unit using previously backed up parameters. This allows you to reset the unit to previously saved parameters, even after you have changed parameters and saved them.

#### Notes:

- *The VMR/NPS will automatically backup saved parameters once a day, shortly after Midnight. This configuration backup file will contain only the most recently saved VMR/NPS parameters, and will be overwritten by the next night's daily backup.*
- *When the **/I** command is invoked, a submenu will be displayed which offers several Reboot options. Option 5 is used to restore the configuration backup file. The date shown next to option 5 indicates the date that you last changed and saved unit parameters.*
- *If the daily automatic configuration backup has been triggered since the configuration error was made, and the previously saved configuration has been overwritten by newer, incorrect parameters, then this function will not be able to restore the previously saved (correct) parameters.*

To restore the previously saved configuration, proceed as follows:

1. Access command mode via the Text Interface, using a username/password that permits access to Administrator level commands (see Section 5.1.1.)
2. At the VMR/NPS command prompt, type **/I** and press **[Enter]**. The VMR/NPS will display a submenu that offers several different reboot options.
3. At the submenu, choose Item 5 (Reboot & Restore Last Known Working Configuration). Key in the number for the desired option, and then press **[Enter]**.
4. The VMR/NPS will reboot and previously saved parameters will be restored.

## 7. Reboot Options

In addition to performing reboot cycles in response to commands, the VMR/NPS can also be configured to automatically reboot outlets when an attached device does not respond to a Ping command (Ping-No-Answer Reboot) or according to a user defined schedule (Scheduled Reboot.)

- **Ping-No-Answer Reboot:** When the Ping-No-Answer feature is enabled, the VMR/NPS will Ping a user selected IP address at regular intervals. If the IP address does not respond to the Ping command, the VMR/NPS will reboot one or more user selected outlet(s). Typically, this feature is used to reboot devices when they cease to respond to the Ping command.
- **Scheduled Reboot:** A scheduled reboot is used to initiate a reboot cycle at a user selected time and day of the week. When properly configured and enabled, the VMR/NPS will reboot one or more outlets on a daily or weekly basis. The Scheduled Reboot feature can also be used to switch outlet(s) Off at a user selected time, and then switch them back On again at a later, user selected time.

This section describes the procedure for configuring and enabling Ping-No-Answer Reboots and Scheduled Reboots.

**Note:** *When defining parameters via the Text Interface, make certain to press the [Esc] key to completely exit from the configuration menus and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message is displayed.*

## 7.1. Ping-No-Answer Reboot

A Ping-No-Answer Reboot can be used to reboot one or more outlets when an attached device does not respond to a Ping Command. In addition, the Ping-No-Answer Reboot feature can also be configured to send an email, Syslog Message or SNMP Trap to notify you whenever a Ping-No-Answer Reboot occurs. Please refer to Section 8.5 for instructions on setting up email alarm notification for Ping-No-Answer reboots.

To set up a Ping-No-Answer Reboot, you must access command mode using a password that permits Administrator level commands. In the Text Interface, the Ping-No-Answer configuration menu is accessed via the Reboot Options menu (/RB). In the Web Browser Interface, the Ping-No-Answer configuration menu is accessed via the Reboot Options link. The Ping-No-Answer configuration menu can be used to Add, Modify, View or Delete Ping-No-Answer Reboot functions.

**Note:** *In order for the Ping-No-Answer Reboot feature to work properly, your network and/or firewall, as well as the device at the target IP address must be configured to allow ping commands.*

### 7.1.1. Adding Ping-No-Answer Reboots

Up to 54 Ping-No-Answer Reboots can be defined. The Add Ping-No-Answer menu is used to define the following parameters for each new Ping-No-Answer Reboot:

- **IP Address or Domain Name:** The IP address or Domain Name for the device that you wish to Ping. When the device at this address fails to respond to the Ping command, the VMR/NPS will reboot the selected outlets. (Default = undefined)

**Notes:**

- *In order to use domain names, DNS Server parameters must first be defined as described in Section 6.8.4.*
- *In the Text Interface, a submenu will be displayed that allows the user to choose either IPv4 protocol or IPv6 protocol.*
- *In the Web Browser Interface, the Add Ping-No-Answer Reboot menu includes a menu item that is used to select IPv4 protocol or IPv6 protocol.*
- **Protocol:** (Web Interface Only) Allows definition of an IPv4 format IP Address or an IPv6 format IP Address. Note that if desired, both an IPv4 and an IPv6 format IP Address may be defined. (Default = IPv4)
- **Ping Interval:** Determines how often the Ping command will be sent to the selected IP Address. The Ping Interval can be any whole number, from 1 to 3,600 seconds. (Default = 60 Seconds)  
**Note:** *If the Ping Interval is set lower than 20 seconds, it is recommended to define the "IP Address or Domain Name" parameter using an IP Address rather than a Domain Name. This ensures more reliable results in the event that the Domain Name Server is unavailable.*
- **Interval After Failed Ping:** Determines how often the Ping command will be sent after a previous Ping command receives no response. (Default = 10 Seconds)

- **Ping Delay After PNA Action:** Determines how long the VMR/NPS will wait to send additional Ping commands, after a Ping-No-Answer Reboot has been initiated. Typically, this option is used to allow time for a device to fully "wake up" after a Ping-No-Answer Reboot before attempting to Ping the device again. (Default = 15 Minutes)
- **Consecutive Failures:** Determines how many consecutive failures of the Ping command must be detected in order to initiate a Ping-No-Answer Reboot. For example, if this value is set to "3", then after three consecutive Ping failures, a Ping-No-Answer Reboot will be performed. (Default = 5)
- **Reboot:** Enables/Disables the Ping-No-Answer Reboot function for the specified IP address. When this item is disabled, the VMR/NPS will not reboot the specified outlet(s) when a Ping-No-Answer is detected. However, the VMR/NPS can continue to notify you via Email, Syslog Message and/or SNMP Trap, providing that parameters for these functions have been defined as described in Section 6.8 and email notification for the Ping-No-Answer function has been enabled as described in Section 8.5. (Default = No)

**Notes:**

- *In order for Email/Text Message Notification to function, you must first define Email/Text Message parameters as described in Section 6.8.10.*
- *In order for Syslog Message Notification to function, you must first define a Syslog Address as described in Section 6.8.1.*
- *In order for SNMP Trap Notification to function, you must first define SNMP parameters as described in Section 6.8.6.*
- **PNA Action:** Determines how the VMR/NPS will react when the IP address fails to respond to a ping. The VMR/NPS can either continuously reboot the specified outlet(s) and send notification until the IP address responds and the Ping-No-Answer Reboot is cleared (Continuous Alarm/Reboot), or the VMR/NPS can reboot the specified outlet(s) and send notification only once each time the Ping-No-Answer Reboot is initially triggered (Single Alarm/Reboot.) (Default = Continuous Alarm/Reboot)
- **Plug Access:** Determines which outlet(s) will be rebooted when the IP address for this Ping-No-Answer operation does not respond to a Ping command. Note that in the Text Interface, Plug Access is defined via a separate submenu; in the Web Browser Interface, Plug Access is defined via a drop down menu, accessed by clicking on the "plus" sign in the "Configure Plug Access" field. (Default = undefined)
- **Plug Group Access:** Determines which Plug Group(s) the Ping-No-Answer Reboot for this IP Address will be applied to. Note that in the Text Interface, Plug Group Access is defined via a separate submenu; in the Web Browser Interface, Plug Group Access is defined via a drop down menu, which may be accessed by clicking on the "plus" sign. (Default = undefined)

- **Ping Test:** Sends a test Ping command to the IP Address defined for this Ping-No-Answer Reboot.

**Notes:**

- *In order for the Ping Test function to work properly, your network and/or firewall as well as the device at the target IP address must be configured to allow ping commands.*
- *After you have finished defining or editing Ping-No-Answer Reboot parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Ping No Answer" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the MPC displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### **7.1.2. Viewing Ping-No-Answer Reboot Profiles**

After you have defined one or more Ping-No-Answer Reboot profiles, you can review the parameters selected for each profile using the View Ping-No-Answer feature. In order to view the configuration of an existing Ping-No-Answer profile, you must access command mode using a password that allows Administrator level commands and then use the Ping-No-Answer menu's "View/Modify Ping-No-Answer" function.

### **7.1.3. Modifying Ping-No-Answer Reboot Profiles**

After you have defined a Ping-No-Answer profile, you can modify the configuration of the profile using the Modify Ping-No-Answer feature. In order to modify the configuration of an existing Ping-No-Answer profile, you must access the command mode using a password that allows Administrator level commands and then use the Ping-No-Answer menu's "View/Modify Ping-No-Answer" function.

The VMR/NPS will display a screen which allows you to modify parameters for the selected Ping-No-Answer Reboot Profile. Note that this screen functions identically to the Add Ping-No-Answer Reboot menu, as discussed in Section 7.1.1.

**Note:** *After you have finished defining or editing Ping-No-Answer Reboot parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Change Ping No Answer" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### **7.1.4. Deleting Ping-No-Answer Reboot Profiles**

After you have defined one or more Ping-No-Answer profiles, you can delete profiles that are no longer needed using the Delete Ping-No-Answer feature. In order to delete an existing Ping-No-Answer profile, you must access the command mode using a password that allows Administrator level commands and then use the Ping-No-Answer menu's "Delete Ping-No-Answer" function.

## 7.2. Scheduled Reboot

The Scheduled Reboot feature can be used to reboot one or more outlets according to a user-defined schedule, or to automatically turn outlets Off and then On according to a user defined schedule.

In order to configure a Scheduled Reboot, you must access command mode using a password that permits access to Administrator level commands. In the Text Interface, the Scheduled Reboot configuration menu is accessed via the Reboot Options menu (/RB). In the Web Browser Interface, the Scheduled Reboot configuration menu is accessed via the Reboot Options link. The Scheduled Reboot configuration menu can be used to Add, Modify, View or Delete Scheduled Reboot functions.

**Note:** *After you have finished defining or editing Scheduled Reboot parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Scheduled Reboot" button to save parameters; in the Text Interface, press the [Esc] key several times until the VMR/NPS displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 7.2.1. Adding Scheduled Reboots

The VMR/NPS allows up to 54 Scheduled Reboots to be defined. The Add Scheduled Reboot menu allows you to define the following parameters for each new Scheduled Reboot:

- **Scheduled Reboot Name:** Assigns a name to this Scheduled Reboot. (Default = undefined.)
- **Plug Action:** Determines whether the Scheduled Reboot will result in the outlet(s) being switched Off, or cycled Off and then On again (Reboot.) Note that when "Off" is selected, the "Day On" option and the "Time On" option can be used to select a time and day when the outlet(s) will be switched back On again. (Default = Off.)
- **Time:** Determines the time of the day that this Scheduled Reboot will occur on. (Default = 12:00.)
- **Day Access:** This prompt provides access to a submenu which is used to determine which day(s) of the week this Scheduled Reboot will be performed. The Day Access parameter can also be used to schedule a daily reboot; to schedule a daily reboot, use the Day Access submenu to select every day of the week. (Default = undefined.)

**Note:** *If you wish to Schedule the VMR/NPS to switch an outlet On at one time and then switch the outlet Off at another time, you must define two separate scheduled actions. The first action would be used to switch the outlet On, and the second action would be used to switch the outlet Off.*

- **Plug Access:** Determines which outlet(s) this Scheduled Reboot action will be applied to. In the Text Interface, outlets are selected by typing 9, pressing [Enter] and then following the instructions in the resulting submenu. In the Web Browser Interface, outlets are designated by clicking on the "plus" sign in the Plug Access field, and then selecting the desired outlets from the drop down menu. (Default = undefined.)
- **Plug Group Access:** Determines which Plug Group(s) this Scheduled Reboot action will be applied to. Note that in the Text Interface, Plug Group Access is defined via a separate submenu; in the Web Browser Interface, Plug Group Access is defined via a drop down menu, which may be accessed by clicking on the "plus" sign in the Plug Group Access field. (Default = undefined.)

### **7.2.2. Viewing Scheduled Reboot Actions**

After you have defined one or more Scheduled Reboots, you can review the parameters selected for each Reboot using the View Scheduled Reboot feature. In order to view the configuration of an existing Scheduled Reboot, you must access the command mode using a password that allows Administrator level commands and then use the Scheduled Reboot menu's "View/Modify Scheduled Reboot" function.

The VMR/NPS will display a screen which lists all defined parameters for the selected Scheduled Reboot action.

### **7.2.3. Modifying Scheduled Reboots**

After you have defined a Scheduled Reboot, you can edit the configuration of the Reboot action using the Modify Scheduled Reboot feature. In order to modify the configuration of an existing Scheduled Reboot action, you must access the command mode using a password that allows Administrator level commands and then use the Scheduled Reboot menu's "View/Modify Scheduled Reboot" function.

The VMR/NPS will display a screen which allows you to modify parameters for the selected Scheduled Reboot action. Note that this screen functions identically to the Add Scheduled Reboot menu, as discussed in Section 7.2.1.

### **7.2.4. Deleting Scheduled Reboots**

After you have defined one or more Scheduled Reboot actions, you can delete Reboot actions that are no longer needed using the Delete Scheduled Reboot feature. In order to delete an existing Scheduled Reboot, access the command mode using a password that allows Administrator level commands and then use the Scheduled Reboot menu's "Delete Scheduled Reboot" function.

## 8. Alarm Configuration

When properly configured, VMR and NPS units can monitor rack temperature, ping command response and other factors at network installation sites. In addition to the monitoring abilities listed above, VMR series units can also measure and record current, power and voltage conditions. Note however that NPS units do not support current consumption, power and voltage monitoring functions.

If user defined trigger levels for temperature are exceeded, the VMR/NPS can also perform load shedding; automatically shutting off user-designated power outlets in order to reduce the amount of heat generated in the rack. When temperatures return to acceptable levels, the VMR/NPS can then switch outlets back on again. The VMR (but not the NPS) can also perform load shedding when current consumption rises above user-defined threshold values. When any of the user-defined alarms are triggered, the VMR/NPS can send an alarm message to the proper personnel via Email, Syslog Message or SNMP trap.

This section describes the procedure for setting up the VMR/NPS to send alarm messages when critical situations are detected. For instructions regarding configuration of the Log function, please refer to Section 6.2.3.

### Notes:

- *Current and Power Monitoring features are not available on NPS units.*
- *In order to send alarm notification via email, email addresses and parameters must first be defined as described in Section 6.8.10. Email alarm notification will then be sent for all alarms that are enabled as described in this section.*
- *In order to send alarm notification via Syslog Message, a Syslog address must first be defined as described in Section 6.8.1. Once the Syslog address has been defined, Syslog Messages will be sent for every alarm that is discussed in this section, providing that the Trigger Enable parameter for the alarm has been set to "On."*
- *In order to send alarm notification via SNMP Trap, SNMP Trap parameters must first be defined as described in Section 6.8.6. Once SNMP Trap Parameters have been defined, SNMP Traps will be sent for every alarm that is discussed in this section, providing that the Trigger Enable parameter for the alarm has been set to "On."*
- *When defining parameters via the Text Interface, make certain to press the **[Esc]** key to completely exit from the configuration menu and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message is displayed.*

To configure the VMR/NPS Alarm functions, access the command mode using a password that allows Administrator level commands and then activate the Alarm Configuration menu (in the Text Interface, type `/AC` and press **[Enter]**; in the Web Browser Interface, click on the "Alarm Configuration" link.)



## 8.1. The Over Current Alarms (VMR Only)

The Over Current Alarms are designed to inform you when current consumption reaches or exceeds user-defined levels. Depending on the specific VMR model, VMR units can have up to four Over Current Alarms (two sets of two alarms):

- The Over Current Line (Initial) Alarm
- The Over Current Line (Critical) Alarm
- The Over Current Branch (Initial) Alarm
- The Over Current Branch (Critical) Alarm

### Notes:

- *Current and Power Monitoring features are not available on NPS units.*
- *The Line Alarms are not available on some VMR models.*
- *The parameters that are defined via the Over Current (Initial and Critical) Alarm Configuration menus will be applied to both Over Current Line Alarms and Over Current Branch Alarms.*
- *The VMR does not include separate configuration menus for the Line and Branch Overcurrent Alarms. Parameters that are defined via the Over Current Alarm configuration menus will be applied to both Branch and Line (if present) Alarms.*

The Line alarms monitor the load on the input line, and are only available on single input units, whereas the Branch alarms monitor the load on each branch circuit breaker.

The Initial alarms are used to provide notification when the level of current consumption reaches a point where you *might* want to investigate it, whereas the Critical alarms can provide notification when the level of current consumption approaches the maximum allowed level. The trigger levels for the Initial alarms are generally set lower than the trigger levels for the Critical alarms.

If the user-defined trigger levels for current load are exceeded, the VMR can automatically shut off power to non-essential devices ("Load Shedding") in order to decrease current load. After Load Shedding has taken place, the VMR can also restore power to the non-essential devices when current load drops to user-defined acceptable levels. For more information on Load Shedding, please refer to Section 8.1.1.

The Load Shedding feature can be configured to react in one manner when an Over Current Line Alarm is triggered, and in a different manner when an Over Current Branch Alarm is triggered. For example, Load Shedding may be configured in such a way that when the Line Alarm is triggered, plugs A1 and B1 are switched Off, but when a Branch Alarm is triggered, plugs A1 and A2 are switched Off.

### Notes:

- *In order for the VMR to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Over Current Alarms, access the VMR command mode using a password that permits Administrator Level commands, and then use the Alarm Configuration menu to select the desired alarm feature.

Note that the configuration menus for both Over Current Alarms offer essentially the same set of parameters, but the parameters defined for each alarm are separate. Therefore, parameters defined for a Critical Alarm will not be applied to an Initial Alarm and vice versa. The Current Alarm Configuration menus offer the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

**Notes:**

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Over Current Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then the triggers for all other VMR/NPS alarms will also be enabled.*
- **Alarm Set Threshold:** The trigger level for this alarm. When current load exceeds the Alarm Set Threshold, the VMR can send an alarm and/or begin load shedding (if enabled.) Note that the Alarm Set Threshold is entered as a percentage of maximum capacity and is applied to both Over Current Branch Alarm and Over Current Line Alarm (if present.) (Defaults: Initial = 80%; Critical = 90%.)
- **Alarm Clear Threshold:** Determines how low the current load must drop in order for the Alarm condition to be cancelled and for load shedding recovery (if enabled) to occur. The Alarm Clear Threshold is entered as a percentage of maximum capacity and is applied to both Over Current Branch Alarm and Over Current Line Alarm (if present.) (Defaults: Initial Alarms = 70%; Critical Alarms = 80%.)
- **Resend Delay:** Determines how long the VMR will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)
- **Notify Upon Clear:** When this item is enabled, the VMR will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR will first send notification when it detects that current consumption has exceeded the trigger value, and then send a second notification when it determines that the current consumption has fallen below the trigger value. (Default = On.)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)

**Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user selected email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by the alarm. (Defaults = "Alarm: Over Current (Initial)" or "Alarm: Over Current (Critical)")
- **Load Shedding:** Provides access to a submenu which is used to configure and enable the Load Shedding feature for the Over Current Alarm. When Load Shedding is enabled and properly configured, the VMR will switch user-selected plugs On or Off whenever the current load exceeds the Alarm Set Threshold value. If the Auto Recovery feature is enabled, the VMR can also return these user-selected plugs to their prior status when current load falls below the Alarm Clear Threshold value. For more information on the Load Shedding Feature and Auto Recovery, please refer to Section 8.1.1.

### 8.1.1. Over Current Alarms - Load Shedding and Auto Recovery

The Load Shedding feature is used to switch specific, user-defined, non-essential plugs On or Off whenever current load exceeds the Alarm Set Threshold value. This allows the VMR to automatically shut Off plugs in order to reduce current load when the load approaches user-defined critical levels. When the Auto Recovery feature is enabled, the VMR can also automatically "undo" the effects of the Load Shedding feature when current load again falls to a user-defined non-critical level.

The VMR also allows you to define separate Load Shedding/Recovery actions for an Over Current Branch Alarm and an Over Current Line Alarm. For example, if the Line Alarm is triggered, Load Shedding can switch Off Plugs A1 and B1, yet when the Branch "A" Alarm is triggered, the VMR can switch Off Plugs A1 and A2.

Together, the Load Shedding and Auto Recovery features allow the VMR to shut off power to non-essential devices when the current load is too high, and then switch those same non-essential devices back On again when the load falls to an acceptable level.

The Load Shedding Configuration Menus allow you to define the following parameters:

#### Notes:

- *Current and Power Monitoring features are not available on NPS units.*
- *The Line Alarms are not available on some VMR models.*
- *The Load Shedding Configuration Menus for all Over Current Alarms offer essentially the same set of parameters, but parameters defined for each alarm are separate and unique. For example, parameters defined for Over Current (Initial) Alarm Load Shedding will not be applied to Over Current (Critical) Alarm Load Shedding and vice versa.*
- *In the Web Browser Interface, the "Unit to Configure" and "Branch" parameters are found in the Over Current Alarm configuration menus.*
- *The "Unit to Configure," "Branch A," "Branch B" and "Line" parameters are used to determine which unit or branch the Load Shedding functions will be applied to.*

- **Line Input A:** Defines the Load Shedding actions that will be executed when an Over Current Branch Alarm is triggered at Line Input "A".
- **Line Input B:** Defines the Load Shedding actions that will be executed when an Over Current Branch Alarm is triggered at Line Input "B".
- **Fuse A1-A4:** Defines the Load Shedding actions that will be executed when an Over Current Branch Alarm is triggered at Fuses A1 through A4.
- **Fuse B1-B4:** Defines the Load Shedding actions that will be executed when an Over Current Branch Alarm is triggered at Fuses B1 through B4.

After selecting the branch or line, use the following parameters to configure Load Shedding functions for the desired branch or line.

- **Enable:** Enables/Disables Load Shedding for the corresponding alarm. When enabled, the VMR will switch the user specified plugs whenever current load exceeds the Alarm Set Threshold value. (Default = Disable.)
- **Plug State:** Determines whether the selected plugs/plug groups will be switched On or Off when Load Shedding is enabled and current load exceeds the user-defined Alarm Set Threshold. For example, if the Plug State is "Off", then plugs or plug groups will be switched Off when the Alarm Set Threshold is exceeded. (Default = Off.)
- **Auto Recovery:** Enables/Disables the Auto Recovery feature for the selected branch or line. When both Load Shedding and Auto Recovery are enabled, the VMR will return plugs to their former On/Off state after current load falls below the Alarm Clear Threshold value. This allows the VMR to "undo" the effects of Load Shedding after current load has returned to an acceptable level. (Default = Off.)
- **Plug Access:** Determines which Plug(s) will be switched when current load exceeds the Alarm Set Threshold and Load Shedding is triggered. For example, if plugs A1, A2 and A3 are selected, then these plugs will be switched On or Off whenever current load exceeds the Alarm Set Threshold. (Default = undefined.)
- **Plug Group Access:** Determines which Plug Group(s) will be switched when the Load Shedding feature is triggered. For example, if you have defined a Plug Group named "test", which includes Plugs B3, B4 and B5, and then selected the "test" Plug Group via the Plug Group Access parameter, then all of the plugs in the "test" Plug Group will be switched On or Off whenever the current load exceeds the Alarm Set Threshold. (Default = undefined.)

**Note:** *Plug Groups must first be defined (as described in Section 6.5) before they will be displayed in the Load Shedding menu's Plug Group Access submenu.*

After setting parameters for a given branch or line, you may also define additional parameters for other branches or lines (if present.) To set Load Shedding parameters for other branches or lines, return to the Alarm Configuration menu and then repeat the procedure described in Section 8.1.1.

## 8.2. The Over Temperature Alarms

The Over Temperature Alarms are designed to inform you when the temperature level inside your equipment rack reaches or exceeds certain user-defined levels. There are two separate Over Temperature Alarms; the Initial Threshold alarm and the Critical Threshold Alarm.

Typically, the Initial Threshold alarm is used to notify you when the temperature within your equipment rack reaches a point where you *might* want to investigate it, whereas the Critical Threshold alarm is used to notify you when the temperature approaches a level that may harm equipment or inhibit performance. The trigger for the Initial Threshold alarm is generally set lower than the Critical Threshold alarm.

If the user-defined trigger levels for temperature are exceeded, the VMR/NPS can automatically shut off power to non-essential devices ("Load Shedding") in order to reduce the amount of temperature that is being generated within the rack. In addition, the Load Shedding feature can also be used to switch On additional components, such as fans or cooling systems in order to dissipate the excess heat. After Load Shedding has taken place, the Load Shedding Recovery feature can be used to return plugs to their previous state after the temperature drops to an acceptable level.

### Notes:

- *In order for the unit to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the unit to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the unit to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Over Temperature Alarms, access the VMR/NPS command mode using a password that permits Administrator Level commands, and then use the Alarm Configuration menu to select the desired alarm feature.

Both the Initial Threshold menus and Critical Threshold menus offer essentially the same parameters, but the parameters defined for each alarm are separate. Therefore, parameters defined for the Critical Threshold Alarm will not be applied to the Initial Threshold Alarm and vice versa. Both the Over Temperature (Initial Threshold) alarm and the Over Temperature (Critical Threshold) alarm offer the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Over Temperature Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other VMR/NPS alarms will also be enabled.*

- **Alarm Set Threshold:** The trigger level for this alarm. When temperature exceeds the Alarm Set Threshold, the VMR/NPS can send an alarm (if enabled) and/or begin Load Shedding (if enabled.) For more information on Load Shedding for the Over Temperature Alarm, please refer to Section 8.2.1. (Initial Threshold: Default = 110°F or 43°C, Critical Threshold: Default = 120°F or 49°C.)

**Note:** *The Alarm Set Threshold value must be greater than the Alarm Clear Threshold value. The VMR/NPS will not allow you to define an Alarm Clear Threshold value that is higher than the Alarm Set Threshold.*

- **Alarm Clear Threshold:** Determines how low the temperature must drop in order for the Alarm condition to be cancelled and for Load Shedding (if enabled) to occur. For more information on Load Shedding for the Over Temperature Alarm, please refer to Section 8.2.1. (Initial Threshold: Default = 100°F or 38°C, Critical Threshold: Default = 110°F or 43°C.)

**Note:** *The System Parameters menu is used to set the temperature format for the VMR/NPS unit to either Fahrenheit or Celsius as described in Section 6.2.*

- **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send notification was unsuccessful. (Default = 60 Minutes.)
- **Notify Upon Clear:** When this item is enabled, the VMR/NPS will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR/NPS will send initial notification when it detects that the temperature has exceeded the trigger value, and then send a second notification when it determines that the temperature has fallen below the trigger value. (Default = On.)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses, defined via the "Email Messages" menu (see Section 6.8.10,) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)

**Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Over Temperature (Initial)" or "Alarm: Over Temperature (Critical)".)
- **Load Shedding:** Provides access to a submenu, which is used to configure and enable the Load Shedding feature for the Over Temperature alarms. When Load Shedding is enabled and properly configured, the VMR/NPS will switch specific, user-selected plugs On or Off whenever the temperature exceeds the Alarm Set Threshold value. If the Auto Recovery feature is enabled, the VMR/NPS can also return these user-selected plugs to their prior status, when the temperature falls below the Alarm Clear Threshold value. For more information on the Load Shedding Feature and Auto Recovery, please refer to Section 8.2.1.

### 8.2.1. Over Temperature Alarms - Load Shedding and Auto Recovery

For Over Temperature Alarms, the Load Shedding feature is used to switch specific, user-defined plugs On or Off whenever temperature exceeds the Alarm Set Threshold value. This allows the VMR/NPS to automatically shut off non-essential devices in order to reduce the temperature generated within the rack, or automatically switch On devices such as fans or cooling systems in order to dissipate heat. When the Auto Recovery feature is enabled, the VMR/NPS can also automatically "undo" the effects of the Load Shedding feature when the temperature again falls to a user-defined non-critical level.

**Note:** *Load Shedding Configuration Menus for both the Initial and Critical Over Temperature Alarms offer essentially the same set of parameters, but parameters defined for each alarm are separate and unique. For example, parameters defined for Over Temperature (Initial) Alarm Load Shedding will not be applied to Over Temperature (Critical) Alarm Load Shedding and vice versa.*

The Load Shedding Configuration menus allow you to defined the following parameters:

- **Configure Load Shedding for Unit:** In the Text Interface, this item is used to access the Load Shedding parameters listed below. In the Web Browser Interface, Load Shedding parameters are accessed via the "Load Shedding" button in the Temperature Alarm configuration menus.
- **Enable:** Enables/Disables Load Shedding for the Over Temperature Alarm. When enabled, the VMR/NPS will switch the user specified plugs whenever the temperature exceeds the Alarm Set Threshold value. (Default = Disable.)
- **Plug State:** Determines whether the selected plugs/plug groups will be switched On or Off when Load Shedding is enabled and temperature exceeds the user-defined Alarm Set Threshold. For example, if the Plug State is set to "Off", then the selected plugs/plug groups will be switched Off when the Alarm Set Threshold is exceeded. (Default = Off.)
- **Auto Recovery:** Enables/Disables the Auto Recovery feature for the selected unit. When both Load Shedding and Auto Recovery are enabled, the VMR/NPS will return plugs to their former On/Off state after the temperature falls below the Alarm Clear Threshold value. This allows the VMR/NPS to "undo" the effects of the Load Shedding feature after the temperature returned to an acceptable level. (Default = Off.)
- **Plug Access:** Determines which Plug(s) will be switched when the temperature exceeds the Alarm Set Threshold and Load Shedding is triggered. For example, if plugs A1, A2 and A3 are selected, these plugs will be switched On or Off whenever the temperature exceeds the Alarm Set Threshold. (Default = undefined.)
- **Plug Group Access:** Determines which Plug Group(s) will be switched when the Load Shedding feature is triggered. (Default = undefined.)

**Note:** *In order to define Plug Group Access, you must first define at least one Plug Group as described in Section 6.5.*

### 8.3. The Circuit Breaker Open Alarm

The Circuit Breaker Alarm is intended to provide notification in the event that one of the VMR/NPS's circuit breakers is opened. When a circuit breaker is open, the VMR/NPS can provide prompt notification via Email, Syslog Message or SNMP Trap.

**Notes:**

- *The Circuit Breaker Open Alarm is not applicable to some VMR models.*
- *In order for the VMR/NPS to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8. and Section 11.*
- *In order for the VMR/NPS to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Circuit Breaker Alarm, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Circuit Breaker Open Alarm Configuration Menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

**Note:**

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Circuit Breaker Open Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other VMR/NPS alarms will also be enabled.*
- **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)
- **Notify Upon Clear:** When this item is enabled, the unit will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the unit can send initial notification when it detects an open circuit breaker, and then send a second notification when it determines that the circuit breaker has been closed. (Default = On.)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)



- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)

**Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user selected email addresses.*

- **Subject:** Defines the text that will appear in the "Subject" field for email notification messages generated by this alarm. (Default = "Alarm: Circuit Breaker Open")

## 8.4. The Lost Voltage (Line In) Alarm

The Lost Voltage (Line In) Alarm can provide notification after the power supply to the VMR/NPS unit has been interrupted.

### Notes:

- *The Lost Voltage (Line In) alarm is only available on VMR/NPS units that include two input power lines.*
- *The Lost Voltage (Line In) alarm will provide notification when one of the available power supplies is lost or disconnected. This alarm will not function if all input power to the VMR/NPS unit is lost. To provide notification when all input power is lost and restored, please use the Power Cycle Alarm as described in Section 8.7.*
- *In order for the VMR/NPS to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR/NPS to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Lost Voltage (Line In) Alarm, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Lost Voltage Alarm Configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Lost Voltage Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then all other VMR/NPS alarms will also be enabled.*
- **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)
- **Notify Upon Clear:** When enabled, the VMR/NPS will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR/NPS will send initial notification when it detects that one of its power supplies has been lost or disconnected, and then send a second notification when it determines that power has been restored. (Default = On.)

- **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
  - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 5.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Lost Voltage (Line In)")

## 8.5. The Ping-No-Answer Alarm

The Ping-No-Answer Alarm is intended to provide notification when one of the IP addresses defined via the Ping-No-Answer Reboot feature (described in Section 7.1) fails to respond to a Ping command. When one of the user-defined IP addresses fails to answer a Ping command, the VMR/NPS can provide notification via Email, Syslog Message or SNMP Trap.

### Notes:

- *In order for the Ping-No-Answer Alarm to work properly, your network and/or firewall, as well as the device at the target IP address, must be configured to allow ping commands.*
- *In order for this alarm to function, IP Addresses for the Ping-No-Answer reboot feature must first be defined as described in Section 7.1.*
- *When a Ping-No-Answer condition is detected, the VMR/NPS can still reboot the user-selected outlet(s) as described in Section 7.1, and can also send an email, Syslog Message and/or SNMP trap as described in this section.*
- *In order for the VMR/NPS to provide Email alarm notification, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide Syslog Message notification, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR/NPS to provide SNMP Trap notification when this alarm is triggered, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Ping-No-Answer Alarm, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Ping-No-Answer alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

**Note:**

- *In order for this alarm to function, at least one target IP Address for the Ping No Answer Alarm must be defined as described in Section 7.1.1.*
  - *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
  - *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Ping-No-Answer Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other VMR/NPS alarms will also be enabled.*
  - **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)
  - **Notify Upon Clear:** When this item is enabled, the VMR/NPS will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR/NPS will send initial notification when it detects that a Ping command has failed, and then send a second notification when it determines that the IP address is again responding to the Ping command. (Default = On.)
  - **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
  - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages that are generated by this alarm. (Default = "Alarm: Ping-No-Answer")

## 8.6. The Serial Port Invalid Access Lockout Alarm

The Serial Port Invalid Access Lockout Alarm can provide notification when the VMR/NPS has locked the serial SetUp Port due to repeated, invalid attempts to access command mode. Normally, the Invalid Access Lockout feature (discussed in Section 6.2.2) can lock the serial SetUp Port whenever the unit detects that a user-defined threshold for invalid access attempts at the SetUp Port is exceeded. When a serial port lockout occurs, the unit can provide notification via Email, Syslog Message or SNMP Trap.

### Notes:

- *Note that Serial Port Invalid Access Lockout Alarm is only intended to provide notification when the Invalid Access Lockout feature has locked the serial SetUp Port. To apply the Invalid Access Lockout feature to the Network Port, please refer to Section 6.2.2.*
- *In order for this alarm to function, Invalid Access Lockout parameters for the serial port must first be configured and enabled as described in Section 6.2.2.*
- *If desired, the VMR/NPS can be configured to count Invalid Access attempts at the serial SetUp port, and provide notification when the counter exceeds a user defined trigger level, without actually locking the port in question. To do this, enable the Invalid Access Lockout Alarm as described here, but when you configure Invalid Access Lockout parameters as described in Section 6.2.2, set the Lockout Attempts and Lockout Duration as you would normally, and then set the "Lockout Enable" parameter to "Off."*
- *In order for the VMR/NPS to provide Email alarm notification, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide Syslog Message notification, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR/NPS to provide SNMP Trap notification when this alarm is triggered, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Serial Port Invalid Access Lockout Alarm, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Invalid Access Lockout alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Invalid Access Lockout Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then other VMR/NPS alarms will also be enabled.*

- **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)
  - **Notify Upon Clear:** When this item is enabled, the VMR/NPS will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR/NPS will send initial notification when it detects that an Invalid Access Lockout has occurred, and then send a second notification when it determines that the port has been unlocked. (Default = On.)
  - **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
  - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Invalid Access Lockout")

## 8.7. The Power Cycle Alarm

The Power Cycle Alarm can provide notification when all input power to the VMR/NPS unit is lost and then restored. When the power supply is lost and then restored, the VMR/NPS can provide notification via Email, Syslog Message or SNMP Trap.

### Notes:

- *This alarm will not function when only one power input line is disconnected. To provide notification when one power input line is lost or disconnected, please use the Lost Voltage (Line In) Alarm as described in Section 8.4.*
- *In order for the VMR/NPS to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR/NPS to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Power Cycle Alarm, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Power Cycle Alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

### Note:

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
  - *The Trigger Enable, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Power Cycle Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then other VMR/NPS alarms will also be enabled.*
  - **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
  - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Power Cycle")

## 8.8. The Plug Current Alarm (VMR Only)

The Plug Current Alarm allows you to monitor current consumption at each of the VMR's switched outlets and generate an alarm when current exceeds a user-defined "High" threshold or falls below a user-defined "Low" threshold. The Plug Current Alarm can also be applied to user-defined Plug Groups in order to generate an alarm when total current consumption for the given Plug Group rises too high or falls too low.

**Note:** *Current and Power Monitoring features are not available on NPS units.*

If desired, the Plug Current Alarm can also be configured to automatically shut off individual plugs or user-defined Plug Groups, whenever current consumption rises above a user-defined threshold value.

To configure the Plug Current Alarm, access the VMR command mode using a password that permits Administrator Level commands and then use the Alarm Configuration menu to select the desired alarm feature. The Plug Current Alarm allows the following parameters to be defined:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

**Note:**

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Plug Current Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other VMR/NPS alarms will also be enabled.*
- **Plug Hysteresis:** This parameter can be used to prevent the Plug Current Alarm from generating excessive "Alarm" and "Clear" messages when current consumption fluctuates back and forth across the trigger value. Basically, the Plug Hysteresis parameter allows you to define a margin at both the Low Threshold and High Threshold that the current level must cross in order to clear an alarm. (Default = 0.5 Amps)

Plug Hysteresis Example: Assume that the Low Threshold for Outlet A1 is set at 5 Amps, the High Threshold is set at 12 Amps and the Plug Hysteresis value is set at 1 Amp. When the current goes high or low, the VMR will respond as follows:

- **Low Alarm:** If the current drops below 5 Amps, the VMR will generate an Alarm. The Alarm will not be cleared until the current rises above 6 Amps (5 Amp Low Threshold + 1 Amp Hysteresis Value = 6 Amps.)
- **High Alarm:** If the current rises above 12 Amps, the VMR will generate an Alarm. The Alarm will not be cleared until the current drops below 11 Amps. (12 Amp High Threshold - 1 Amp Hysteresis Value = 11 Amps.)



- **Plug Thresholds:** Defines current consumption level(s) that will trigger alarm(s) at each switched outlet. The Plug Thresholds can be configured to trigger an alarm when current consumption rises above a user-defined "High" value and/or when current consumption falls below a user-defined "Low" value. This allows you to define a "normal" current range for each outlet, allowing the Plug Current Alarm to be triggered whenever current consumption strays outside of this range. (Default = undefined.)
- **Plug Group Thresholds:** Defines current consumption level(s) that will trigger alarm(s) for each user-defined Plug Group. The Plug Group Thresholds can be configured to trigger an alarm when total current consumption for a given Plug Group rises above a user-defined "High" value and/or when current consumption falls below a user-defined "Low" value. This allows you to define a "normal" current range for each Plug Group, allowing the Plug Current Alarm to be triggered whenever total current consumption for the Plug Group strays outside of this range. (Default = undefined.)

**Note:** *In order to define Plug Group Thresholds, you must first define at least one Plug Group as described in Section 6.5.*

- **Plug "Off" Low Alarm:** Allows you to configure the "Low" current alarm to suppress triggering when an outlet is purposely switched Off. When this feature is "On", the VMR will generate a Low alarm whenever current drops below the Low threshold value, even if the current drop is due to an outlet being purposely switched Off. When this feature is "Off", the VMR will not generate a Low alarm due to a current drop caused by an outlet being switched Off. (Default = On)

**Notes:**

- *The Plug "Off" Low Alarm feature will also be applied to Plug Groups.*
- *When the Plug "Off" Low Alarm feature is enabled (On), the VMR will always generate a Low current alarm when current drops below the Low threshold value, even when the current drop was caused by one or more outlets in the Plug Group being purposely switched Off.*
- *When the Plug "Off" Low Alarm feature is disabled (Off), the VMR will not generate a Low current Alarm when a current drop is caused by all outlets in the Plug Group being purposely switched Off.*
- **Resend Delay:** Determines how long the VMR will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)
- **Notify Upon Clear:** When this item is enabled, the VMR will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR will send initial notification when it detects that a current consumption has risen above the defined "High" trigger value, and then send a second notification when it determines that current consumption has fallen below the "Low" trigger value. (Default = On.)

- **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)

**Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Plug Current")
- **Plug Shedding:** Allows individual plugs to be automatically switched Off or left On when current consumption at the plug rises above the user-defined high Plug Threshold value. (Default = Leave On.)

**Note:** *In order to enable Plug Shedding, you must first set the high Plug Threshold value for each desired plug.*

- **Plug Group Shedding:** Allows user-defined Plug Groups to be automatically switched Off or left On when current consumption by the Plug Group rises above the user-defined high Plug Group Threshold high. (Default = Leave On.)

**Note:** *In order to enable Plug Group Shedding, you must first set the high Plug Group Threshold for each desired Plug Group.*

## 8.9. The Emergency Shutoff Alarm

The Emergency Shutoff Alarm can provide notification when the VMR/NPS Emergency Shutoff feature is triggered.

### Notes:

- *In order for the VMR/NPS to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR/NPS to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

To configure the Emergency Shutoff Alarm, you must access the VMR/NPS command mode using a password that permits Administrator Level commands. The Lost Voltage Alarm Configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify Upon Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the Lost Voltage Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other VMR/NPS alarms will also be enabled.*
- **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When enabled, the VMR/NPS will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR/NPS will send initial notification when it detects that the Emergency Shutoff function is initiated, and then send a second notification when the unit determines that power has been restored. (Default = On)

- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)  
  
**Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Emergency Shutoff")

## 8.10. The No Dialtone Alarm

The No Dialtone Alarm enables the VMR/NPS to monitor a telephone line connected to an external modem installed at the VMR/NPS Setup Port, and then provide notification if the VMR/NPS detects that the phone line is dead or no dialtone is present.

If the No Dialtone Alarm is enabled and the VMR/NPS determines that there is no dialtone signal, the No Dialtone Alarm can provide notification via email using a network connection. In the event that the VMR/NPS unit is not connected to a network cable, the VMR/NPS will also create an entry in the Alarm Log, indicating that the No Dialtone Alarm has been triggered.

### Notes:

- *In order for this alarm to function, the No Dialtone Alarm must first be enabled as described in Section 6.2. In addition, the Reset/No Dialtone Interval and the Reset/No Dialtone Scaler must both be set to a value from 1 to 99. If the Reset/No Dialtone Interval and/or the Reset/No Dialtone Scaler are set to 0 (zero,) the No Dialtone Alarm will not function. To enable the No Dialtone Alarm and define the Reset/No Dialtone Interval and the Reset/No Dialtone Scaler value, please refer to Section 6.7.1.*
- *In order for the VMR/NPS to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.8.10.*
- *In order for the VMR/NPS to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.8 and Section 11.*
- *In order for the VMR/NPS to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.8.6 and Section 12.*

The configuration menu for the No Dialtone Alarm allows the following parameters to be defined:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When disabled, this alarm will be suppressed. (Default = On.)

### Note:

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify Upon Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all VMR/NPS alarms. For example, if the No Dialtone Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other VMR/NPS alarms will also be enabled.*
- **Resend Delay:** Determines how long the VMR/NPS will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes.)

- **Notify Upon Clear:** When this item is enabled, the VMR/NPS will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the VMR/NPS will send initial notification when it detects that the dialtone for the external modem has been lost, and then send a second notification when it determines that the dialtone has been restored. (Default = On.)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On.)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.8.10) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On.)

**Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: No Dial Tone")

## 9. The Status Screens

The Status Screens are used to display status information about the switched outlets, Network Port, Plug Groups, Current and Power Metering and the Alarm Log and Audit Log. The Status Screens are available via both the Text Interface and Web Browser Interface.

### 9.1. Product Status

The Product Status Screen lists the model number, power rating, input line count, input line frequency and software version and other general information for your VMR/NPS unit. To display the Product Status Screen via the Text Interface, type `/J *` and then press **[Enter]**. To display the Product Status Screen via the Web Browser Interface, click on the "Product Status" link.

**Note:** *The Information provided by the Product Status Screen is intended mainly to assist WTI support personnel with the diagnosis of user equipment problems.*

### 9.2. The Network Status Screen

The Network Status screen shows activity at the VMR/NPS's 16 virtual network ports. To view the Network Status Screen, you must access command mode using a password that permits access to Administrator Level commands.

To display the Network Status Screen via the Text Interface, type `/SN` and press **[Enter]**. To display the Network Status Screen via the Web Browser Interface, click on the Network Status link.

### 9.3. The Plug Status Screen

The Plug Status screen shows the On/Off status of the VMR/NPS's switched outlets.

**Note:**

- *When the Plug Status Screen is viewed by an "Administrator" or "SuperUser" level account, all VMR/NPS plugs are listed. When the Plug Status Screen is viewed by a "User" or "ViewOnly" level account, the screen will list only the outlets that are allowed by that account.*
- *Section 6.6 describes the procedure for configuring the plug parameters that are listed in the Plug Status Screen.*

To display the Plug Status Screen via the Text Interface, type `/s` and press **[Enter]**. To display the Plug Status Screen via the Web Browser Interface, click on the "Plug Status" link. Note that when the `/s` command is invoked via the Text Interface, the command line can also include arguments that display On/Off status for an individual outlet, two or more specific outlets, or a range of outlets:

- `/s` Displays configuration details and ON/Off status for all switched outlets.
- `/s s` Displays On/Off status for an individual outlet, where *s* is the name or number of the desired outlet.
- `/s s+s` Displays On/Off status for two or more specific outlets, where *s* is the number or name of each desired outlet. A plus sign (+) is entered between each outlet number or name.
- `/s s:s` Displays On/Off status for a range of outlets, where *s* is the number or name of the outlet at the beginning and end of the range of desired outlets. A colon (:) is entered between the two outlet numbers or names that mark the beginning of the range and the end of the range.



## 9.4. The Plug Group Status Screen

The Plug Group Status screen shows the configuration details and On/Off status for the VMR/NPS's user-defined Plug Groups.

### Notes:

- *Current and Power Monitoring features are not available on NPS units.*
- *When the Plug Group Status Screen is viewed by an "Administrator" or "SuperUser" level account, all VMR/NPS plugs and plug groups are listed. When the Plug Status Screen is viewed by a "User" or "ViewOnly" level account, the screen will list only the plug groups that are allowed by that account.*
- *The procedure for defining parameters for individual plugs is described in Section 6.6. The procedure for defining Plug Groups is described in Section 6.5.*
- *In order to display the Plug Group Status screen, you must first define at least one Plug Group as described in Section 6.5.*

To display the Plug Group Status Screen via the Text Interface, type /SG and then press **[Enter]**. To display the Plug Group Status Screen via the Web Browser Interface, click on the "Plug Group Status" link and then select the desired Plug Group from the resulting submenu and click on the "Get Plug Group Status" button.

**Note:** *The SNMP Index item (Text Interface Only) lists the permanent reference number that the VMR/NPS assigns to each Plug Group. The SNMP Index number allows MIB commands to be addressed to a specific Plug Group. The SNMP Index number will not change when other Plug Groups are deleted or created.*

## 9.5. The Current Metering Status Screen

The Current Metering Status screen is primarily intended to be used to display up-to-date readings for Amps, Watts, Voltage and temperature for VMR Series unit. In NPS Series units, the Current Metering Status Screen will only include temperature and voltage information. To view the Current Metering Log screen, proceed as follows:

**Note:** *Although NPS Series units do not support current and power metering functions, the /M command can still be invoked on NPS Series units to display the Current Metering Status Screen. Note however, that when the Current Metering Status Screen is displayed on an NPS Series unit, only temperature and voltage values will be displayed and current and power values will be listed as zero (0.0.)*

In addition to displaying the Current Metering Status Screen, the /M command can also be used to display current, voltage and power readings for each switched outlet on VMR Series units. Note however, that when the /M command is invoked on NPS Series units, the resulting screen will only display voltage values; current and power values will not be included on NPS Series units. When the /M command is invoked, the command line can also include arguments that display the status of individual outlets, specific pairs of outlets or a range of outlets:

- /M** Displays the Current Metering Status Screen.
- /M s** Displays current, voltage and power readings for an individual plug or outlet, where *s* is the name or number of the desired outlet.
- /M s+s** Displays current, voltage and power readings for two or more specific outlets, where *s* is the number or name of each desired outlet. A plus sign (+) is entered between each outlet number or name.
- /M s:s** Displays current, voltage and power readings for a range of outlets, where *s* is the number or name of the outlet at the beginning and end of the range of desired outlets. A colon (:) is entered between the two outlet numbers or names that mark the beginning of the range and the end of the range.
- /M a** Displays current, voltage and power readings for Branch A.
- /M b** Displays current, voltage and power readings for Branch B.

### Notes:

- *When current, voltage and power readings are displayed for a single outlet, pair of outlets or range of outlets, readings for each outlet specified will be displayed as three values separated by commas. Current will be displayed first, then voltage, then power.*
- *When the /M command is invoked on an NPS Series unit, current and power readings will not be included. Instead, a zero will be displayed in place of current and power.*

To display the Current Metering Status Screen, proceed as follows:

- **Text Interface:** Type **/M** and press **[Enter]**.
- **Web Browser Interface (VMR Only):** Place the cursor over the "Current Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Current Metering Status" link.

## 9.6. The Current History Screen (VMR Only)

The Current History Screen displays current, voltage and temperature readings as a function of time. In the Web Browser Interface, the Current History can be displayed as a graph or downloaded in ASCII, CSV or XML format. In the Text Interface, the Current History can be displayed as straight ASCII data, or can be downloaded in CSV or XML format. To view the Current History Screen, access the VMR command mode, and proceed as follows:

**Note:** *The Current History Screen is not available on NPS units.*

**Text Interface:** Type `/L` and press **[Enter]** to access the "Display Logs" menu. From the "Display Logs" menu, enter the appropriate option number and then press **[Enter]** to display the Current Metering Log Menu. The Text Interface also offers the option to select the following display parameters:

- **Display Data Option:** Determines whether data will be displayed in "Unit" format (displays total current per branch) or "Plug" format (displays current consumption for each individual outlet.)
- **Display Current Metering Log:** Displays the Current Metering Log according to the currently selected Display Data Option.
- **Download Current Metering Log in CSV Format:** Downloads the Current Metering Log (as determined by the current Display Data Option) in CSV format.
- **Download Current Metering Log in XML Format:** Downloads the Current Metering Log (as determined by the current Display Data Option) in XML format.
- **Erase Current Metering Log:** Clears all Current Metering Log data. Note that when the Current Metering Log is erased, the Power Metering Log will also be erased.

**Web Browser Interface:** Place the cursor over the "Current Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Current History" link to display the Current Metering Log menu. At the Current Metering Log menu, you can display current history data as a graph, or download or display the log in ASCII, CSV or XML format. Current Metering Log data can be displayed or downloaded for specific plug(s) or plug group(s.) When the Current Metering Log is displayed as a graph, a date range can also be selected, allowing data to be displayed Live or for the previous Day, Week, Month or Year.

To save Current History data, access command mode using an account that permits Administrator level commands, and then proceed as follows:

- **Text Interface:** Type `/L` and press **[Enter]** to show the Display Logs menu. From the Display Logs menu, key in the number for the desired option and then press **[Enter]** to display the Current Metering Log menu, which allows you to either display the Current History log in ASCII format, download and save in CSV or XML format, or erase the Current History Log.
- **Web Browser Interface:** Place the cursor over the "Current Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the desired action and then select graph format, or display/download the Current History in ASCII, CSV or XML format.

## 9.7. The Power Range Status Screen (VMR Only)

The Power Range Status Screen can be used to display power consumption readings over a user-selected period of time, for the VMR unit as well as any optional remote VMR units that may be connected.

**Note:** *The Power Range Status Screen is not available on NPS units.*

To view the Power Range Status Screen, access the VMR command mode using an account that permits access to Administrator or SuperUser level commands and then proceed as follows:

### Text Interface:

1. Type **/L** and press **[Enter]** to access the "Display Logs" menu. From the Display Logs menu, type **4** and press **[Enter]** to display the Power Metering Log menu.
2. **Power Metering Log Menu:** The Power Metering Log Menu also allows you to either display Power Metering Data or download Power History Data.
  - a) **Display Data Option:** The Display Data Option determines whether the VMR will display total current consumption for each branch (Unit) or current consumption for each outlet (Plug).
  - b) **Display Power Metering:** Type **2** and press **[Enter]**. The VMR will display the Power Metering menu, which allows you to set a date range for the desired data and display the data selected.

### Web Browser Interface:

1. Place the cursor over the "Power Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Power Range" link to display the "Select Plugs" menu.
2. Select the desired plugs, then click the "Select Plugs" button to display the "List Power Range" menu.
3. Use the List Power Range menu to select the desired date range, and then click on the "Get Chart" button.

In the Text Interface, Power Metering data will be displayed in table format. In the Web Browser Interface, Power Metering data will be displayed in both table and graph format.

## 9.8. The Power History Screen (VMR Only)

The Power History Screen shows power consumption versus time. To view the Power History Screen, access the VMR command mode using an account that permits access to Administrator or SuperUser level commands, and then proceed as follows:

**Note:** *The Power History Screen is not available on NPS units.*

### Text Interface:

Type `/L` and press **[Enter]** to access the "Display Logs" menu. From the Display Logs menu, type `4` and press **[Enter]** to display the Power Metering Log menu.

The Power History menu offers the following options:

1. **Display Data Option:** The Display Data Option determines whether the VMR will display total current consumption for each branch (Unit) or current consumption for each outlet (Plug).
2. **Display Power Metering:** The Display Power Metering menu allows you to select the duration period (date) for the Power History screen and then display the resulting data.
3. **Download Power History:** The Download Power History Screen allows you to display Power History Data or download Power History data in CSV or XML format.

### Web Interface:

Place the cursor over the "Power Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Power History" link to display the Power History menu.

The Power History menu offers the options to display Power History as a graph, or display/download the Power History in ASCII, CSV or XML format; click on the link for the desired option. The VMR will display a screen that allows you to select all plugs, one or more plug groups, or up to four individual plugs. Check the box next to the desired option, then click on the "Select Plugs" button to display the Power History graph.

### Notes:

- *When the "Unit" Display Data Option is selected, the Power Metering Log will list power data for each branch circuit as well as the total for all VMR outlets.*
- *When the "Plugs" Display Data Option is selected, the Power Metering Log will list data for each individual VMR outlet as well as the total for all VMR outlets.*

### 9.9. The Port Diagnostics Screen

The Port Diagnostics Screen provides more detailed information about the VMR/NPS's Serial Port. To display the Port Diagnostics Screen, access the Text Interface command mode and type `/SD` **[Enter]**.

**Note:** *The Port Diagnostics Screen is only available via the Text Interface.*

### 9.10. Alias Status Screen

The Alias Status Screen lists user defined IP alias for the VMR/NPS's Serial Port.

**Note:** *The Alias Status Screen is only available via the Text Interface.*

To display the Alias Status Screen via the Text Interface, type `/SA` and press **[Enter]**.

### 9.11. The Alarm Status Screen

The Alarm Status Screen lists all available user-defined alarms and indicates whether or not each alarm has been triggered. The resulting screen will display "Yes" (or 1) for alarms that have been triggered or "No" (or 0) for alarms that have not been triggered. If desired, the `/AS` command line can also include an optional alarm argument that will cause the unit to display the status of one individual alarm. For a list of alarm arguments, please refer to Section 17.3.1.

### 9.12. The Serial Port Parameters Screen

The `/W` (Who) command displays more detailed information about the VMR/NPS's Serial Port. Rather than listing general connection information, the Port Parameters screen lists all defined parameters for the Serial port. To display the Serial Port Parameters Screen, type `/w` and press **[Enter]**.

The `/W` command uses the following format:

`/w xx` **[Enter]**

**Note:** *The Serial Port Parameters screen is only available via the Text Interface.*

## 9.13. The Event Logs

The Event Logs can be used to review recent user activity, alarm events and temperature trends that have been recorded by the VMR/NPS unit. In order to view, download or erase the event logs, you must access command mode using a password that permits Administrator or SuperUser level commands.

To access the Event Logs via the Text Interface, type `/L`, press **[Enter]** and then select the desired option from the resulting submenu. To access the Event Logs via the Web Browser Interface, place the cursor over the "Logs" link on the left hand side of the screen, wait for the flyout menu to appear, and then select the desired option.

**Note:** *Although both the Text Interface and Web Browser Interface allow you to display or download the Event Logs, the Event Logs can only be erased via the Text Interface.*

### 9.13.1. The Audit Log

The Audit Log provides a record of most command activity at the VMR/NPS unit, including port connections and disconnections, login and logout activity. Note however that the Audit Log does not include user information regarding access to configuration menus or status screens.

**Note:** *The Audit Log will also include power switching operations.*

### 9.13.2. The Alarm Log

The Alarm Log provides a record of all events that were initiated by a VMR/NPS alarm function. The Alarm Log will display the following information for each logged event:

## 10. SSH Encryption

In addition to standard Telnet protocol, the VMR/NPS also supports SSH connections, which provide secure, encrypted access via network. In order to communicate with the VMR/NPS using SSH protocol, your network node must include an appropriate SSH client.

Note that when the /K (Send SSH Key) command is invoked, the VMR/NPS can also provide you with a public SSH key, which can be used to streamline connection to the VMR/NPS when using SSH protocol.

Although you can establish an SSH connection to the unit *without* the public key, the public key provides validation for the VMR/NPS, and once this key is supplied to the SSH client, the client will no longer display a warning indicating that the VMR/NPS is not a recognized user when the client attempts to establish a connection.

The /K command uses the following format:

```
/K <k> [Enter]
```

Where **k** is an argument that determines which type of public key will be displayed, and the **k** argument offers the following options:

1. SSH1
2. SSH2 RSA
3. SSH2 DSA

For example, to obtain the public SSH key for an SSH2 RSA client, type /K 2 and then press **[Enter]**. Note that when capturing the SSH key, you can either configure your terminal application to receive the parameter file, or simply copy and paste the resulting SSH key.

### Notes:

- *Although the VMR/NPS does not support SSH1, the /K 1 command will still return a key for SSH1.*
- *When capturing the SSH key, you can either configure your terminal application to receive the parameter file, or simply copy and paste the resulting key.*



## 11. Syslog Messages

The Syslog feature can create log records of each Alarm Event. As these event records are created, they are sent to a Syslog Daemon, located at an IP address defined via the Network Parameters menu.

### 11.1. Configuration

If you wish to employ this feature, you must set the real-time clock and calendar via the System Parameters Menu, and define the IP address for the Syslog Daemon via the Network Port Configuration menu.

To configure the Syslog function, please proceed as follows:

1. **Access command mode:** Note that the following configuration menus are only available to accounts that permit Administrator level commands.
2. **System Parameters Menu:** Access the System Parameters Menu as described in Section 6.2, then set the following parameters:
  - a) **Set Clock and Calendar:** Set the Real Time Clock and Calendar and/or configure and enable the NTP server feature.
3. **Network Parameters Menu:** Access the Network Parameters Menu as described in Section 6.8, then set the following parameters:
  - a) **Syslog IP Address:** Determine the IP address for the device that will run the Syslog Daemon, then use the Network Port Configuration menu to define the IP Address for the Syslog Daemon.

#### Notes:

- *The Network Parameters Menu allows the definition of IP addresses for both a primary Syslog Daemon and an optional secondary Syslog Daemon.*
  - *The Syslog Address submenu in the Text Interface includes a Ping Test function that can be used to ping the user-selected Syslog IP Address to verify that a valid IP address has been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
4. **Syslog Daemon:** In order to capture messages sent by the VMR/NPS, a computer must be running a Syslog Daemon (set to UDP Port 514) at the IP address specified in Step 3 above.

Once the Syslog Address is defined, Syslog messages will be generated whenever one of the alarms discussed in Section 8 is triggered.

## 12. SNMP Traps

The SNMP Trap function allows the VMR/NPS to send Alarm Notification messages to two different SNMP managers, each time one of the Alarms discussed in Section 8 is triggered.

### Note:

- *The SNMP feature cannot be configured via the SNMP Manager.*
- *SNMP reading ability is limited to the System Group.*
- *The SNMP feature includes the ability to be polled by an SNMP Manager.*
- *Once SNMP Trap Parameters have been defined, SNMP Traps will be sent each time an Alarm is triggered. For more information on Alarm Configuration, please refer to Section 8.*

### 12.1. Configuration:

To configure the SNMP Trap function, proceed as follows:

1. Access command mode using an account that permits Administrator level commands.
2. **SNMP Trap Parameters:** Access the SNMP Trap Parameters Menu as described in Section 6.8.6. Set the following:
  - a) **SNMP Managers 1 and 2:** The address(es) that will receive SNMP Traps that are generated by one of the Alarms discussed in Section 8. Consult your network administrator to determine the IP address(es) for the SNMP Manager(s), then use the Network Parameters menu to set the IP address for each SNMP Manager. Note that it is not necessary to define both SNMP Managers.

### Notes:

- *To enable the SNMP Trap feature, you must define at least one SNMP Manager. SNMP Traps are automatically enabled when at least one SNMP Manager has been defined.*
  - *The SNMP Trap submenu includes a Ping Test function that can be used to ping the user-selected SNMP Managers to verify that a valid IP address has been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
  - *Addresses for SNMP Managers can be defined in either IPv4 or IPv6 format, as described in Section 6.8.6.*
- b) **Trap Community:** Consult your network administrator, and then use the Network Parameters menus to set the Trap Community.

Once SNMP Trap Parameters have been defined, the VMR/NPS will send an SNMP Trap each time an alarm is triggered.

## 13. Operation via SNMP

If SNMP Access Parameters have been defined as described in Section 6.8.5, then you will be able to manage user accounts, control power and reboot switching and display unit status via SNMP. This section describes the procedure for SNMP communication with the VMR/NPS unit, and lists some common commands that can be employed to manage users, control switching and reboot actions and display unit status.

**Note:** *SNMP Commands are not available when the IPS mode is active.*

### 13.1. VMR/NPS SNMP Agent

The VMR/NPS's SNMP Agent supports various configuration, control, status and event notification capabilities. Managed objects are described in WTI-MPC-VMR-MIB.txt, which can be found in the user's guide archive on the WTI web site at:

<http://www.wti.com/manuals.htm>

The WTI-MPC-VMR-MIB.txt document can be compiled for use with your SNMP client.

### 13.2. SNMPv3 Authentication and Encryption

The major limitations of SNMPv2 were the failure to include proper username/password login credentials (v2 only used a password type of login, i.e., community name) and the lack of support for encryption of transmitted data. SNMPv3 addresses both of these shortcomings.

For SNMPv3, the VMR/NPS supports two forms of Authentication/Privacy: Auth/noPriv which requires a username/password, but does not encrypt data going over the internet and Auth/Priv which requires a username/password AND encrypts the data going over the internet using DES or AES (in the case of the VMR/NPS, the default encryption format for SNMPv3 is DES.) For the Password protocol, the SRM supports either MD5 or SHA1.

### 13.3. Configuration via SNMP

VMR/NPS User accounts can be viewed, created, modified, and deleted via SNMP. User accounts are arranged in a table of 128 rows, and indexed 1-128. User account parameters, as seen through the SNMP, are summarized below.

**Note:** *Current and Power Monitoring features are not available on NPS units.*

- **userTable::userName** – 32 character username
- **userTable::userPasswd** – 16 character password
- **userTable::userAccessLevel** – Account access level.
  - 0 – View Access
  - 1 – User Access
  - 2 – Superuser Access
  - 3 – Administrator Access
- **userTable::userLocalAccess** – A string of 16 characters, with one character for each of the 16 possible plugs on the VMR/NPS unit. A '0' indicates that the account **does not** have access to the plug, and a '1' indicates that the user *does* have access to the plug.
- **userTable::userGroupAccess** – A string of 54 characters, with one character for each of the 54 possible plug groups in the system. '0' indicates that the account **cannot** access the group, and '1' indicates that the user *can* access the group.
- **userTable::userSerialAccess** – Access to the serial interface
  - 0 – No access
  - 1 – Access
- **userTable::userTelnetSshAccess** – Access to the Telnet/SSH interface.
  - 0 – No access
  - 1 - Access
- **userTable::userOutboundTelSshAccess** – Access to Outbound Telnet/SSH
  - 0 – No access
  - 1 - Access
- **userTable::userWebAccess** – Access to the Web interface.
  - 0 – No access
  - 1 - Access
- **userTable::userCurrentPowerMetering** – (VMR Only) Access to the systems current/power metering.
  - 0 – No access
  - 1 – Access
- **userTable::userCallbackNum** – 32 character callback number for account.
- **userTable::userSubmit** – Set to 1 to submit changes.

### **13.3.1. Viewing Users**

To view users, issue a GET request on any of the user parameters for the index corresponding to the desired user.

### **13.3.2. Adding Users**

For an empty index, issue a SET request on the desired parameters. Minimum requirement is a username and password to create a user, all other parameters will be set to defaults if not specified. To create the user, issue a SET request on the userSubmit object.

### **13.3.3. Modifying Users**

For the index corresponding to the user you wish to modify, issue a SET request on the desired parameters to be modified. Once complete, issue a SET request on the userSubmit object.

### **13.3.4. Deleting Users**

For the index corresponding to the user you wish to delete, issue a SET request on the username with a blank string. Once complete, issue a SET request on the userSubmit object.

## 13.4. Plug Control via SNMP

### 13.4.1. Plug Status/Control

ON, OFF, BOOT, and DEFAULT commands can be issued for plugs via SNMP. Plugs are arranged in a table of N rows, where N is the number of plugs in the system. Plug parameters are described below.

- **plugTable::plugID** – String indicating the plug's ID.
- **plugTable::plugName** – String indicating the plug's user-defined name.
- **plugTable::plugStatus** – Current state of the plug.
  - 0 – Plug is OFF
  - 1 – Plug is ON
- **plugTable::plugAction** – Action to be taken on plug.
  - 1 – Mark to turn ON (does not execute)
  - 2 – Mark to turn OFF (does not execute)
  - 3 – Mark to BOOT (does not execute)
  - 4 – Mark to DEFAULT (does not execute)
  - 5 – Mark to turn ON and execute plug actions
  - 6 – Mark to turn OFF and execute plug actions
  - 7 – Mark to BOOT and execute plug actions
  - 8 – Mark to DEFAULT and execute plug actions

Set **plugTable::plugAction** to desired action, as specified by values 1-4 above, for each plug index the action is to be applied to. For the last plug you wish to set before executing the commands, use values 5-8 instead, which will invoke the requested commands all at once.

- **plugTable::plugCurrent** – The current, in tenths of an Amp, that is being consumed by each switched outlet.
- **plugTable::plugPower** – The power, in Watts, that is being consumed by each switched outlet.

### 13.4.2. Plug Group Status/Control

ON, OFF, BOOT, and DEFAULT commands can be issued for plug groups via SNMP. Plug groups are arranged in a table of 54 rows, one row for each plug group in the system. Plug Group parameters are described below.

- **plugGroupTable::plugGroupName** – String indicating the plug groups name.
- **plugGroupTable::plugGroupAction** – Action to be taken on plug group
  - 1 – Mark to turn ON (does not execute)
  - 2 – Mark to turn OFF (does not execute)
  - 3 – Mark to BOOT (does not execute)
  - 4 – Mark to DEFAULT (does not execute)
  - 5 – Mark to turn ON and execute plug group actions
  - 6 – Mark to turn OFF and execute plug group actions
  - 7 – Mark to BOOT and execute plug group actions
  - 8 – Mark to DEFAULT and execute plug group actions

Set **plugGroupTable::plugGroupAction** to desired action, as specified by values 1-4 above, for each plug group index the action is to be applied to. For the last plug group you wish to set before executing the commands, use values 5-8 instead, which will invoke the requested commands all at once.

- **plugGroupTable::plugGroupCurrent** – The current, in tenths of an Amp, that is being consumed by each Plug Group.
- **plugGroupTable::plugGroupPower** – The power, in Watts, that is being consumed by each Plug Group.

## 13.5. Viewing VMR/NPS Status via SNMP

Status of various components of the VMR/NPS can be retrieved via SNMP.

### 13.5.1. System Status - Ethernet Port Mac Addresses

The Mac Address for the Ethernet Port can be displayed using the command below:

- `environmentUnitTable::environmentMacEth0` The Mac Address for Ethernet Port 0.

### 13.5.2. Plug Status

The status of each plug in the system can be retrieved using the command below.

- `plugTable::plugStatus` – The status of the plug.
  - 0 – Plug is OFF
  - 1 – Plug is ON
- `plugTable::plugName` - String indicating the plug's user-defined name.

### 13.5.3. Unit Environment Status

The environment status can be retrieved for various variables for all of the VMR/NPS units in the system. The `environmentUnitTable` contains four rows, one row for each unit in the system (LOCAL, AUX1, AUX2, AUX3.)

**Note:** *Current and Power Monitoring features are not available on NPS units.*

- `environmentUnitTable::environmentUnitName` – The unit (LOCAL.)
- `environmentUnitTable::environmentUnitTemperature` – The temperature of the given unit.
- `environmentUnitTable::environmentUnitCurrentA` – (VMR Only) Unit's total current for Branch A. Note that Current will be reported in tenths of an Amp (divide result by ten to determine value in Amps.)
- `environmentUnitTable::environmentUnitVoltageA` – (VMR Only) Unit voltage for Branch A
- `environmentUnitTable::environmentUnitPowerA` – (VMR Only) Power drawn by Branch A
- `environmentUnitTable::environmentUnitCurrentB` – (VMR Only) Unit's total current for Branch B. Note that Current will be reported in tenths of an Amp.
- `environmentUnitTable::environmentUnitVoltageB` – (VMR Only) Unit voltage for Branch B
- `environmentUnitTable::environmentUnitPowerB` – (VMR Only) Power drawn on Branch B
- `environmentMonthlyPowerLog` - (VMR Only) The monthly power usage log.



### 13.5.4. Alarm Status

The status of the VMR/NPS unit's alarm functions can be retrieved and displayed using the following commands:

**Notes:**

- *When an alarm status command returns a zero (0), this indicates that the alarm is inactive.*
- *When an alarm status command returns a one (1), this indicates that the alarm is active (triggered.)*
- **alarmTables::alarmOverCurrentInitial** - (VMR Series Units Only) Displays the status of the Over Current (Initial) Line Alarm.
- **alarmTables::alarmOverCurrentCritical** - (VMR Series Units Only) Displays the status of the Over Current (Critical) Line Alarm.
- **alarmTables::alarmOverTemperatureInitial** - Displays the status of the Over Temperature (Initial) Alarm.
- **alarmTables::alarmOverTemperatureCritical** - Displays the status of the Over Temperature (Critical) Alarm.
- **alarmTables::alarmCircuitBreakerOpen** - Displays the status of the Circuit Breaker Open Alarm.
- **alarmTables::alarmCommLoss** - Displays the status of the Lost Communication Alarm.
- **alarmTables::alarmPingNoAnswer** - Displays the status of the Ping-No-Answer Alarm.
- **alarmTables::alarmInvalidAccessLockout** - Displays the status of the Serial Port Invalid Access Lockout Alarm.
- **alarmTables::alarmPowerCycle** - Displays the status of the Power Cycle Alarm.
- **alarmTables::alarmPlugCurrent** - (VMR Series Units Only) Displays the status of the Plug Current Alarm.
- **alarmTables::alarmLostOptoVoltage** - (Dual Power Inlet Units Only) Displays the status of the Lost Voltage Alarm.
- **alarmTables::alarmNoDialtone** - Displays the status of the No Dialtone Alarm.
- **alarmTables::alarmEmergencyShutoff** - Displays the status of the Emergency Shut Off feature. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).

## 13.6. Sending Traps via SNMP

Traps that report various unit conditions can be sent to an SNMP Management Station from the VMR/NPS. The following traps are currently supported.

- **WarmStart** Trap – Trap indicating a warm start
- **ColdStart** Trap – Trap indicating a cold start
- **Test** Trap – Test trap invoked by user via the Text Interface (CLI.)

The VMR/NPS can send an SNMP trap to notify you when any of the available alarm functions have been triggered. In all cases except the Power Cycle Alarm, there will be one trap sent when the alarm is triggered, and a second trap sent when the alarm is cleared. For more information on alarm functions, please refer to Section 8.

- **Alarm** Trap – Trap indicating an alarm condition. A trap with a unique enterprise OID is defined for every possible alarm in the system, under which several specific trap-types are defined to indicate the setting or clearing of that particular alarm condition.
- **overCurrentInitialSetTrap** - (VMR Series Units Only) Indicates that the Over Current (Initial) Alarm has been triggered.
- **overCurrentInitialClearTrap** - (VMR Series Units Only) Indicates that the Over Current (Initial) Alarm has been cleared.
- **overCurrentCriticalSetTrap** - (VMR Series Units Only) Indicates that the Over Current (Critical) Alarm has been triggered.
- **overCurrentCriticalClearTrap** - (VMR Series Units Only) Indicates that the Over Current (Critical) Alarm has been cleared.
- **overTemperatureInitialSetTrap** - Indicates that the Over Temperature (Initial) Alarm has been triggered. The trap will also include a numerical value that indicates the current unit temperature.
- **overTemperatureInitialClearTrap** - Indicates that the Over Temperature (Initial) Alarm has been cleared.
- **overTemperatureCriticalSetTrap** - Indicates that the Over Temperature (Critical) Alarm has been triggered. The trap will also include a numerical value that indicates the current unit temperature.
- **overTemperatureCriticalClearTrap** - Indicates that the Over Temperature (Critical) Alarm has been cleared.
- **pingNoAnswerSetTrap** - Indicates that the Ping No Answer Alarm has been triggered. The trap will also include a numerical value that indicates the IP address of the device that failed to respond to the ping command.
- **pingNoAnswerClearTrap** - Indicates that the Ping No Answer Alarm has been cleared.
- **lockoutSetTrap** - Indicates that the Invalid Access Lockout Alarm has been triggered. The trap will also include a numerical value that indicates the number of the serial port where the lockout occurred.
- **lockoutClearTrap** - Indicates that the Invalid Access Lockout Alarm has been cleared.

- **powercycleSetTrap** - Indicates that the Power Cycle Alarm has been triggered (Note that there is no corresponding Clear Trap for the Power Cycle Alarm.)
- **plugCurrentSetTrap** - (VMR Series Units Only) Indicates that the Plug Current Alarm has been triggered.
- **plugCurrentClearTrap** - (VMR Series Units Only) Indicates that the Plug Current Alarm has been Cleared.
- **lostCommSetTrap** - Indicates that the Lost Communication Alarm has been triggered.
- **lostCommClearTrap** - Indicates that the Lost Communication Alarm has been cleared.
- **plugCurrentSetTrap** - Indicates that the Plug Current Alarm has been triggered.
- **plugCurrentClearTrap** - Indicates that the Plug Current Alarm has been cleared.
- **lostOptoVoltageSetTrap** - Indicates that the Lost Voltage Alarm has been triggered at a unit that includes opto sensors.
- **lostOptoVoltageClearTrap** - Indicates that the Lost Voltage Alarm has been cleared at a unit that includes opto sensors.
- **noDialtoneSetTrap** - Indicates that the No Dialtone Alarm has been triggered.
- **noDialtoneClearTrap** - Indicates that the No Dialtone Alarm has been cleared.
- **emergencyShutoffSetTrap** - Indicates that an emergency shut off has been implemented. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).
- **emergencyShutoffClearTrap** - Indicates that an emergency shut off has been cleared. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).

## 14. Creating Web Certificates

There are two different types of HTTPS security certificates: "Self Signed" certificates and "Signed" certificates.

**Note:** *SSL/TLS parameters cannot be defined via the Web Browser Interface. In order to set up SSL/TLS encryption, you must contact the VMR/NPS via the Text Interface.*

Self Signed certificates can be created by the VMR/NPS, without the need to go to an outside service. The principal disadvantage of Self Signed certificates, is that when you access the VMR/NPS command mode via the Web Browser Interface, the browser will display a message which warns that the connection might be unsafe. Note however, that even though this message is displayed, communication will still be encrypted, and the message is merely a warning that the VMR/NPS is not recognized and that you may not be connecting to the site that you intended.

Signed certificates must be created via an outside certificate authority (e.g., VeriSign<sup>®</sup>, Thawte<sup>™</sup>, etc.) and then uploaded to the VMR/NPS unit to verify the unit's identity. Once a signed certificate has been set up, you will then be able to access command mode without seeing the warning message that is displayed for a Self Signed certificate access.

```
WEB ACCESS: [eth0] IPv4/IPv6

HTTP:
1. Enable: On
2. Port: 80

HTTPS:
3. Enable: On
4. Port: 443

SSL Certificates:
5. Common Name:
6. State or Province:
7. Locality:
8. Country:
9. Email Address:
10. Organization Name:
11. Organizational Unit:
12. CSR Commands:
13. CRT Commands:
14. Harden Web Security: Medium
15. TLS Mode: TLSv1.1/TLSv1.2
16. TRACE Method: ON

Enter: #<CR> to change,
      <ESC> to return to previous menu ...
```

**Figure 14.1: Web Access Parameters (Text Interface Only)**

## 14.1. Creating a Self Signed Certificate

To create a Self Signed certificate, access the Text interface using a password that permits access to Administrator level commands and then proceed as follows:

1. Type `/N` and press **[Enter]** to display the Eth0/IPv4 (Shared) Network Parameters menu.
2. At the Eth0/IPv4 Network Parameters menu, type `23` and press **[Enter]** to display the Web Access menu (Figure 14.1.) Type `3` and press **[Enter]** and then follow the instructions in the resulting submenu to enable HTTPS access.
3. Next, use the Web Access menu to define the following parameters.

### Notes:

- *When configuring the VMR/NPS, make certain to define all of the following parameters. Although most SSL/TLS applications require only the Common Name, in the case of the VMR/NPS all of the following parameters are mandatory.*
- *If desired, any random text sequence can be entered in each of these fields.*
- **5. Common Name:** A domain name that will be used to identify the VMR/NPS unit. If you will use a Self Signed certificate, then this name can be any name that you choose, and there is no need to set up your domain name server to recognize this name. However, if you will use a Signed certificate, then your domain name server must be set up to recognize this name (e.g., service.yourcompanyname.com.)
- **6. State or Province:** The name of the state or province where the VMR/NPS unit will be located (e.g., California.)
- **7. Locality:** The city or town where the VMR/NPS unit will be located (e.g., Irvine.)
- **8. Country:** The two character country code for the nation where the VMR/NPS will be located (e.g., US.)
- **9. Email Address:** An email address, that can be used to contact the person responsible for the VMR/NPS (e.g., jsmith@yourcompany.com.)
- **10. Organizational Name:** The name of your company or organization (e.g., Yourcompanyname, Inc.)
- **11. Organizational Unit:** The name of your department or division.

4. After you have defined parameters 5 through 11, type 12 and press **[Enter]** to access the CSR Commands menu. From the CSR Commands Menu, type 1 and press **[Enter]** to generate a Certificate Signing Request. This will overwrite any existing certificate, and create a new Self Signed certificate.
  - a) The VMR/NPS will prompt you to create a password. Key in the desired password and then press **[Enter]**. When the VMR/NPS prompts you to verify the password, key it again and then press **[Enter]** once. After a brief pause, the VMR/NPS will return to the Web Access Menu, indicating that the CSR has been successfully created.
  - b) When the Web Access Menu is re-displayed, press **[Esc]** several times until you exit from the Network Parameters menu and the "Saving Configuration" message is displayed.
5. After the new configuration has been saved, test the Self Signed certificate by accessing the VMR/NPS via the Web Interface, using an HTTPS connection.
  - a) Before the connection is established, the VMR/NPS should display the warning message described previously. This indicates that the Self Signed certificate has been successfully created and saved.
  - b) The VMR/NPS will prompt you to enter a user name and password. After keying in your password, the main menu should be displayed, indicating that you have successfully accessed command mode.

## 14.2. Creating a Signed Certificate

To create a Signed certificate, and eliminate the warning message, first set up your domain name server to recognize the Common Name (item 5) that you will assign to the unit. Next, complete steps one through five as described in Section 14.1 and then proceed as follows:

1. **Capture the Newly Created Certificate:** Type 12 and press **[Enter]** to access the CSR Commands submenu.
  - a) At the CSR Commands submenu, type 2 and press **[Enter]** to select the Display CSR Key option.
  - b) The VMR/NPS will prompt you to configure your communications program to receive the certificate. Set up your communications program to receive a binary file, and then press **[Enter]** to capture the file and save it. This is the Code Signing Request that you will send to the outside security service (e.g., VeriSign, Thawte, etc.) in order to have them sign and activate the certificate.
2. **Obtain the Signed Certificate:** Send the captured certificate to the outside security service. Refer to the security service's web page for further instructions.

3. **Upload the Signed Certificate to the VMR/NPS:** After the "signed" certificate is returned from the certificate authority, return to the Web Access menu.
  - a) Access the VMR/NPS command mode via the Text Interface using an account that permits Administrator level commands as described previously, then type `/N` and press **[Enter]** to display the Eth0/IPv4 (Shared) Network Parameters menu.
  - b) At the Eth0/IPv4 (Shared) Network Parameters, type 23 and press **[Enter]** to display the Web Access menu.
  - c) From the Web Access menu, type 13 and press **[Enter]** to display the CRT Commands submenu.
  - d) At the CRT Commands submenu, type 1 and press **[Enter]** to select the Upload Signed CRT Certificate option.
  - e) Use your communications program to send the binary format Signed Certificate to the VMR/NPS unit. When the upload is complete, press **[Escape]** to exit from the CRT Commands submenu.
  - f) After you exit from the CRT Server Key submenu, press **[Escape]** several times until you have exited from the Network Parameters menu and the "Saving Configuration" message is displayed.
4. After the configuration has been saved, test the signed certificate by accessing the VMR/NPS via the Web Browser Interface, using an HTTPS connection. For example, if the common name has been defined as "service.wti.com", then you would enter "`https://service.wti.com`" in your web browser's address field. If the Signed Certificate has been properly created and uploaded, the warning message should no longer be displayed.

### 14.3. Downloading the Server Private Key

When configuring the VMR/NPS's SSL/TLS encryption feature (or setting up other security/authentication features), it is recommended to download and save the Server Private Key. To download the Server Private Key, access the Text interface using a password that permits access to Administrator level commands and then proceed as follows:

1. Type **/n** and press **[Enter]** to display the Eth0/IPv4 (Shared) Network Parameters menu.
2. At the Eth0/IPv4 (Shared) Network Parameters menu, type **23** and press **[Enter]** to display the Web Access menu (Figure 14.1.)
  - a) To download the Server Private Key from the VMR/NPS unit, make certain that SSL/TLS parameters have been defined as described in Section 14.1, then type **13** and press **[Enter]** to display the CRT Commands submenu.
  - b) At the CRT Commands submenu, type **2** and press **[Enter]** to display the Signed CRT Certificate Copy the resulting CRT certificate to a text file and save the text file on your hard drive.
3. To upload a previously saved CRT Certificate to the VMR/NPS unit, make certain that SSL/TLS parameters have been defined as described in Section 14.1, return to the Web Access menu as described in Steps 1 and 2 above, then type **13** and press **[Enter]** to display the CRT Commands Submenu.
  - a) At the CRT Commands submenu, type **1** and press **[Enter]** to select the Upload Signed CRT Certificate option.
  - b) Use your communications program to send the binary format Signed Certificate to the VMR/NPS unit. When the upload is complete, press **[Escape]** to exit from the CRT Commands submenu.
  - c) After you exit from the CRT Server Key submenu, press **[Escape]** several times until you have exited from the Network Parameters menu and the "Saving Configuration" message is displayed.

### 14.4. Harden Web Security

In the Web Access Menu, the Harden Web Security option allows you to disable SSLv3 and MEDIUM ciphers for incoming web connections.

### 14.5. TLS Mode

The TLS Mode parameter in the Web Access menu selects the TLS version(s) that the web server will accept from incoming web connections.



## 15. Saving and Restoring Configuration Parameters

Once the VMR/NPS is properly configured, parameters can be downloaded and saved as an ASCII text file. Later, if the configuration is accidentally altered, the saved parameters can be uploaded to automatically reconfigure the unit without the need to manually assign each parameter.

Saved parameters can also be uploaded to other identical VMR/NPS units, allowing rapid set-up when several identical units will be configured with the same parameters.

The "Save Parameters" procedure can be performed from any terminal emulation program (e.g., TeraTerm®, etc.) that allows downloading of ASCII files.

**Note:** *Configuration parameters can be downloaded and saved via either the Web Browser Interface or Text Interface. Saved configuration parameters can only be uploaded to the unit via the Text Interface.*

### 15.1. Sending Parameters to a File

#### 15.1.1. Downloading & Saving Parameters via Text Interface

1. Start your terminal emulation program and access the Text Interface command mode using an account that permits Administrator level commands.
2. When the command prompt appears, type `/U` and press **[Enter]**. The VMR/NPS will prompt you to configure your terminal emulation program to receive an ASCII download.
  - a) Set your terminal emulation program to receive an ASCII download, and then specify a name for a file that will receive the saved parameters (e.g. VMR.PAR).
  - b) Disable the Line Wrap function for your terminal emulation program. This will prevent command lines from being broken in two during transmission.
3. When the terminal emulation program is ready to receive the file, return to the VMR/NPS's Save Parameter File menu, and press **[Enter]** to proceed. VMR/NPS parameters will be saved on your hard drive in the file specified in Step 2 above.
4. The VMR/NPS will send a series of ASCII command lines which specify currently selected parameters. When the download is complete, press **[Enter]** to return to the command prompt.

### 15.1.2. Downloading & Saving Parameters via Web Browser Interface

The Web Browser Interface also includes a download function that can be used to save VMR/NPS parameters to an XML format file on your PC or laptop. To save parameters via the Web Browser Interface, proceed as follows:

**Notes:**

- *Although VMR/NPS parameters can be saved to a file via either the Text Interface or Web Browser Interface, saved parameters can only be restored via the Text Interface. The Restore Parameters function is not available via the Web Browser Interface.*
  - *This procedure may differ slightly, depending on the operating system and browser used. In some cases, your system may perform a security scan before proceeding with the download.*
1. Access the Web Browser Interface command mode using an account that permits Administrator level commands.
  2. When the Web Browser Interface appears, click on the "Download Unit Configuration" button on the left hand side of the screen.
  3. After a brief pause, your browser may display a prompt asking if you want to open or save the downloaded file. At this point, you can either select the "Save" option to save the parameters file to the download folder on your PC, or select "Save As" to pick a different location and/or filename for the saved parameters file.

## 15.2. Restoring Saved Parameters

This section describes the procedure for using your terminal emulation program to send saved parameters to the VMR/NPS.

**Note:** *The Restore Parameters feature is only available via the Text Interface.*

1. Start your terminal emulation program and access the VMR/NPS's Text Interface command mode using an account that permits Administrator level commands.
2. Configure your terminal emulation program to upload an ASCII text file.
3. Upload the ASCII text file with the saved VMR/NPS parameters. If necessary, key in the file name and directory path.
4. Your terminal emulation program will send the ASCII text file to the VMR/NPS. When the terminal program is finished with the upload, make certain to terminate the Upload mode.

**Note:** *If the VMR/NPS detects an error in the file, it will respond with the "Invalid Parameter" message. If an error message is received, carefully check the contents of the parameters file, correct the problem, and then repeat the Upload procedure.*

5. If the parameter upload is successful, the VMR/NPS will send a confirmation message, and then return to the command prompt. Type /s and press **[Enter]**, the Status Screen will be displayed. Check the Status Screen to make certain the unit has been configured with the saved parameters.

### 15.3. Restoring Previously Saved Parameters

If you make a mistake while configuring the VMR/NPS unit, and wish to return to the previously saved parameters, the Text Interface's "Reboot System" command (/I) offers the option to reinitialize the VMR/NPS unit using previously backed up parameters. This allows you to reset the unit to previously saved parameters, even after you have changed parameters and saved them.

**Notes:**

- *The VMR/NPS will automatically backup saved parameters once a day, shortly after Midnight. This configuration backup file will contain only the most recently saved VMR/NPS parameters, and will be overwritten by the next night's daily backup.*
- *When the /I command is invoked, a submenu will be displayed which offers several Reboot options. Option 5 is used to restore the configuration backup file. The date shown next to option 5 indicates the date that you last changed and saved unit parameters.*
- *If the daily automatic configuration backup has been triggered since the configuration error was made, and the previously saved configuration has been overwritten by newer, incorrect parameters, then this function will not be able to restore the previously saved (correct) parameters.*

To restore the previously saved configuration, proceed as follows:

1. Access command mode via the Text Interface, using a username/password that permits access to Administrator level commands (see Section 5.1.1.)
2. At the VMR/NPS command prompt, type /I and press **[Enter]**. The VMR/NPS will display a submenu that offers several different reboot options.
3. At the submenu, you may choose Item 5 (Reboot & Restore Last Known Working Configuration.) Type 5 and press **[Enter]**.

**Note:** *When invoking the /I command to restore configuration parameters, Item 5 is recommended.*

4. The VMR/NPS will reboot and previously saved parameters will be restored.

## 16. Upgrading VMR/NPS Firmware

When new, improved versions of the VMR/NPS firmware become available, either the Firmware Upgrade Utility (recommended) or the "Upgrade Firmware" function (Text Interface only) can be used to update the unit. The following section describes the procedure for updating the VMR/NPS unit using the Firmware Upgrade Utility or the Upgrade Firmware function.

### 16.1. WMU Enterprise Management Software (Recommended)

The preferred method for updating VMR/NPS units is via the WMU Enterprise Management Software that is included with the unit. The WMU software allows you to manage firmware updates for multiple WTI units from a single interface. For a description of the process for managing firmware updates via the WMU, please refer to the WMU user's guide, which can be downloaded from the WTI User's Guide Archive at:

<http://www.wti.com/t-product-manuals.aspx>

Note that in order to use the WMU software, the firmware version for the VMR/NPS must be at least v1.48 or higher. When upgrading older VMR/NPS units that feature pre v1.48 firmware, it is recommended to use the WTI Firmware Upgrade Utility. A zip file that contains the installation files and other documentation for the WTI Firmware Upgrade Utility can be downloaded from WTI's FTP server, located at:

[ftp://wtiftp.wti.com/pub/TechSupport/Firmware/Upgrade\\_UTILITY/](ftp://wtiftp.wti.com/pub/TechSupport/Firmware/Upgrade_UTILITY/)

Please refer to the documentation included in the zip file for further instructions.

### 16.2. The Upgrade Firmware Function (Alternate Method)

The Upgrade Firmware function provides an alternative method for updating the VMR firmware. Updates can be uploaded via FTP or SFTP protocols.

#### **Notes:**

- *The FTP/SFTP servers can only be started via the Text Interface.*
  - *All other ports will remain active during the firmware upgrade procedure.*
  - *If the upgrade includes new parameters or features not included in the previous firmware version, these new parameters will be set to their default values.*
  - *The upgrade procedure will require approximately 15 minutes.*
1. Obtain the update file. Firmware modifications can either be mailed to the customer, or downloaded from WTI. Place the upgrade CDR in your disk drive or copy the file to your hard drive.
  2. Access Text Interface command mode via Serial Port, Telnet or SSH client session, using a username/password and port that permit Administrator level commands.

3. When the command prompt appears, type `/U` and then press **[Enter]**. The VMR/NPS will display a screen which offers the following options:
  - a) **Start FTP/SFTP Servers Only (Do NOT default parameters):** To proceed with the upgrade, while retaining user-defined parameters, type 1 and press **[Enter]**. All existing parameter settings will be restored when the upgrade is complete.
  - b) **Start FTP/SFTP Servers & Default (Keep IP parameters & SSH Keys):** To proceed with the upgrade and default all user-defined parameters except for the IP Parameters and SSH Keys, type 2 and press **[Enter]**. When the upgrade is complete, all parameter settings except the IP Parameters and SSH Keys, will be reset to factory default values.
  - c) **Start FTP/SFTP Servers & Default (Default ALL parameters):** To proceed with the upgrade, and reset parameters to default settings, type 3 and press **[Enter]**. When the upgrade is complete, all parameters will be set to default values.
  - d) **Start FTP/SFTP Servers for Slip Stream Upgrade:** This option will upgrade only the WTI Management Utility, without updating the VMR/NPS's operating firmware. To update the WTI Management Utility only, type 4 and press **[Enter]**.

Note that after any of the above options is selected, the VMR/NPS will start the receiving servers and wait for an FTP/SFTP client to make a connection and upload a valid firmware binary image.

4. To proceed with the upgrade, select the desired option. The VMR/NPS will display a message that indicates that the unit is waiting for data. Leave the current Telnet/SSH client session connected at this time.
5. Open your FTP/SFTP application and (if you have not already done so,) login to the VMR/NPS unit, using a username and password that permit access to Administrator level commands.
6. Transfer the md5 format upgrade file to the VMR/NPS.
7. After the file transfer is complete, the VMR/NPS will install the upgrade file and then reboot itself and break all port connections. Note that it will take approximately 10 minutes to complete the installation process. The unit will remain accessible until it reboots.
  - a) Some FTP/SFTP applications may not automatically close when the file transfer is complete. If this is the case, you may close your FTP/SFTP client manually after it indicates that the file has been successfully transferred.
  - b) When the upgrade process is complete, the VMR/NPS will send a message to all currently connected network sessions, indicating that the VMR/NPS is going down for a reboot.

**Note:** Do not power down the VMR/NPS unit while it is in the process of installing the upgrade file. This can damage the unit's operating system.

8. If you have accessed the VMR/NPS via the Network Port, in order to start the FTP/SFTP servers, the VMR/NPS will break the network connection when the system is reinitialized.
  - If you initially selected "Start FTP/SFTP Servers and Save Parameters", you may then reestablish a connection with the VMR/NPS using your former IP address.
  - If you initially selected "Start FTP/SFTP Servers and Default Parameters", you must then login using the VMR/NPS's default IP address (Default = 192.168.168.168) or access command mode via Serial Port 1 or 2 or via Modem.

When firmware upgrades are available, WTI will provide the necessary files. At that time, an updated Users Guide or addendum will also be available.

## 17. Command Reference Guide

### 17.1. Command Conventions

Most commands described in this section conform to the following conventions:

- **Text Interface:** Commands discussed in this section, can only be invoked via the Text Interface. These commands *cannot* be invoked via the Web Browser Interface.
- **Slash Character:** Most VMR/NPS Text Interface commands begin with the Slash Character (/).
- **Apply Command to All Plugs:** When an asterisk is entered as the argument of the `/ON` (Switch Plugs On), `/OFF` (Switch Plugs Off) or `/BOOT` (Reboot Plugs) commands, the command will be applied to all plugs. For example, to reboot all allowed plugs, type `/BOOT * [Enter]`.
- **Command Queues:** If a switching or reboot command is directed to a plug that is already being switched or rebooted by a previous command, then the new command will be placed into a queue until the plug is ready to receive additional commands.
- **"Busy" Plugs:** If the "Status" column in the Plug Status Screen includes an asterisk, this means that the plug is currently busy, and is in the process of completing a previously issued command. If a new command is issued to a busy plug, then the new command will be placed into a queue to be executed later, when the plug is ready to receive additional commands.
- **Plug Name Wild Card:** It is not always necessary to enter the entire plug name. Plug names can be abbreviated in command lines by entering the first character(s) of the name followed by an asterisk (\*). For example, a plug named "SERVER" can be specified as "S\*". Note however, that this command would also be applied to any other plug name that begins with an "S".
- **Suppress Command Confirmation Prompt:** When the `/ON` (Switch Plug On), `/OFF` (Switch Plug Off), `/BOOT` (Reboot Plug) or `/DPL` (Default All Plugs) commands are invoked, the "Y" option can be included to override the Command Confirmation ("Sure?") prompt. For example, to reboot Plug A4 without displaying the Sure prompt, type `/BOOT A4 ,Y [Enter]`.
- **Enter Key:** Most commands are invoked by pressing `[Enter]`.
- **Configuration Menus:** To exit from a configuration menu, press `[Esc]`.

## 17.2. Command Summary

Function	Command Syntax	Command Access Level			
		Admin.	SuperUser	User	ViewOnly
<b>Display</b>					
Plug Status	/S [s] [Enter]	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>
Port Diagnostics	/SD [Enter]	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>
Port Parameters (Who)	/W [n] [Enter]	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>
Plug Group Status	/SG [Enter]	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>
Network Status	/SN [Enter]	X	X	X	X
Network Configuration Summary	/RN [Enter]	X	X	X	X
IP Alias Status	/SA [Enter]	X	X	X <sup>1</sup>	X <sup>1</sup>
Alarm Status	/AS [alarm] [Enter]	X			
Help Menu	/H [Enter]	X <sup>3</sup>	X <sup>3</sup>	X <sup>3</sup>	X <sup>3</sup>
Log Functions	/L [Enter]	X	X		
Current Metering	/M [Enter] <sup>4</sup>	X	X		
Site ID / Unit Information	/J [*] [Enter] <sup>5</sup>	X	X	X	X
<b>Control</b>					
Exit Command Mode	/x [Enter]	X	X	X	X
Boot Plug <i>n</i>	/BOOT <s>[, Y] [Enter] <sup>6</sup>	X	X	X	
Turn Plug <i>n</i> On	/ON <s>[, Y] [Enter] <sup>6</sup>	X	X	X	
Turn Plug <i>n</i> Off	/OFF <s>[, Y] [Enter] <sup>6</sup>	X	X	X	
Default All Plugs	/DPL[, Y] [Enter] <sup>6</sup>	X	X	X	
Connect to Port	/C [n] [Enter]	X	X	X	
Disconnect from Port	/D [n] [Enter] <sup>6</sup>	X	X	X	
Send Parameter File	/U [Enter]	X			
Send SSH Keys	/K <k> [Enter]	X			
Unlock Invalid Access	/UL [Enter]	X			
Outbound Telnet	/TELNET <ip> [port] [raw] [Enter]	X <sup>7</sup>	X <sup>7</sup>	X <sup>7</sup>	
Outbound SSH	/SSH <ip> -l <username> [Enter]	X <sup>7</sup>	X <sup>7</sup>		
<b>Configuration</b>					
System Parameters	/F [Enter]	X	<sup>8</sup>		
Serial Port Parameters	/P [n] [Enter]	X	<sup>8</sup>		
Plug Parameters	/PL [Enter]	X	<sup>8</sup>		
Plug Group Parameters	/G [Enter]	X	<sup>8</sup>		
Network Configuration - IPv4	/N [Enter]	X	<sup>8</sup>		
Network Selection - IPv4/IPv6	/N* [Enter]	X	<sup>8</sup>		
Reboot Options	/RB [Enter]	X	<sup>8</sup>		
Alarm Configuration	/AC [Enter]	X	<sup>8</sup>		
Reboot System	/I [Enter]	X	X		
Upgrade Firmware	/UF [Enter]	X			
Test Network Configuration	/TEST [Enter]	X			

- <sup>1</sup> In Administrator Mode and SuperUser Mode, all VMR/NPS outlets are displayed. In User Mode and ViewOnly Mode, the Plug Status Screen will only include the plugs that are allowed by your account.
- <sup>2</sup> In Administrator Mode, all Plugs/Plug Groups are displayed. In SuperUser Mode, User Mode and ViewOnly Mode, the status screen will only include the Plugs/Plug Groups allowed by the account.
- <sup>3</sup> In Administrator Mode, the Help Menus will list all VMR/NPS commands. In the SuperUser Mode, User Mode and ViewOnly Mode, the Help Menus will only list the commands that are allowed by the access level.
- <sup>4</sup> Current and Metering functions are not available on NPS units.
- <sup>5</sup> If the optional asterisk (\*) argument is included in the command line, this command will also show model numbers, current ratings and software versions for the VMR/NPS unit.
- <sup>6</sup> The " , x" argument can be included in the command line to suppress the command confirmation prompt.
- <sup>7</sup> In order to invoke this command, Outbound Telnet/SSH and Outbound Service Access must be enabled for your account.
- <sup>8</sup> In SuperUser Mode, configuration menus can be displayed, but parameters cannot be changed.



## 17.3. Command Set

This section provides information on all Text Interface commands.

### 17.3.1. Display Commands

#### **/S** Display Plug Status Screen

---

Displays the Plug Status Screen, which lists the current On/Off state, plug number, plug name, Boot/Sequence Delay value and Default On/Off value for each plug. For more information, please refer to Section 9.3. The /S command line can also include arguments that display On/Off status for an individual outlet, two or more specific outlets, or a range of several outlets:

- /s** Displays configuration details and On/Off status for all switched outlets.
- /s s** Displays On/Off status for an individual outlet, where *s* is the name or number of the desired outlet.
- /s s+s** Displays status information for two or more specific outlets, where *s* is the number or name of each desired outlet. A plus sign (+) is entered between each outlet number or name.
- /s s:s** Displays status information for a range of outlets, where *s* is the number or name of the outlet at the beginning and end of the range of desired outlets. A colon (:) is entered between the two outlet numbers or names that mark the beginning of the range and the end of the range.

**Notes:**

- *In Administrator Mode and SuperUser Mode, all outlets are displayed. In User Mode and ViewOnly Mode, the Plug Status Screen will only include the outlets allowed by your account.*
- *The VMR/NPS will return a "0" to indicate that the plug is Off, or a "1" to indicate that the plug is On.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /s [Enter]

#### **/SD** Display Port Diagnostics

---

Provides detailed information regarding the status of each port. When this command is issued by a User level or View Only level account, the resulting screen will only display parameters for the ports allowed by the account. For more information, please refer to Section 9.9.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sd [Enter]

**Response:** Displays Port Diagnostics Screen.

**/W Display Port Parameters (Who)**

---

Displays configuration information for the serial Setup Port, but does not allow parameters to be changed.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /w [x] [Enter]

Where **x** is the port number or name. To display parameters for the Network Port, enter an "N". If the "x" argument is omitted, parameters for your resident port will be displayed.

**/SG Display Plug Group Status Screen**

---

Displays the Plug Group Status Screen, which lists the available Plug Groups, the numbers of the plugs included in each Plug Group, the current On/Off state, the user-defined Boot/Sequence Delay value, and the Default On/Off value for each plug. For more information, please refer to Section 9.4.

**Note:** *In Administrator Mode all user defined Plug Groups are displayed. In SuperUser Mode, User Mode and ViewOnly Mode, the Plug Group Status Screen will only include the Plug Groups allowed by your account.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sg [Enter]

**/SN Display Network Status**

---

Displays the Network Status Screen, which lists active network connections to the VMR/NPS's Network Port. For more information, please refer to Section 9.2.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sn [Enter]

**/RN Network Configuration Summary**

---

Displays a screen that lists currently selected communication settings, LDAP status, RADIUS status, Email Messaging status, NTP status and PPP status.

**Availability:** Administrator, SuperUser, User ViewOnly

**Format:** /rn [Enter]

**/SA IP Alias Status**

---

Displays the Alias Status Screen, which lists currently selected port name, alias IP address and Direct Connect status for the VMR/NPS's serial port. For more information, please refer to Section 9.10.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /SA [Enter]

**/H Help**

---

Displays a Help Screen, which lists all available Text Interface commands along with a brief description of each command.

**Note:** *In the Administrator Mode, the Help Screen will list the entire VMR/NPS Text Interface command set. In SuperUser Mode, User Mode and ViewOnly Mode, the Help Screen will only list the commands that are allowed by the account's access level.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /H [Enter]

**/L Log Functions**

---

Provides access to a menu which allows you to display the Audit Log, Alarm Log Current Metering Log and Power Metering Log. For more information on Log Functions, please refer to Section 6.2.3 and Section 9.13.

**Note:** *Current and Power Metering functions are not available on NPS units.*

**Availability:** Administrator, SuperUser

**Format:** /L [Enter]

---

**/M Current Metering Status**

---

Displays the Current Metering Status Screen, which lists current, voltage and power readings, and also lists the trigger settings for the Over Temperature Alarm and the Over Current Alarm. For more information on Current Metering, please refer to Section 9.5. For more information on Alarm Configuration, please refer to Section 8.

**Note:** *Although NPS Series units do not support current and power metering functions, the /M command can still be invoked on NPS Series units to display the Current Metering Status Screen. Note however, that when the Current Metering Status Screen is displayed on an NPS Series unit, only temperature and voltage values will be displayed and current and power values will be listed as zero (0.0.)*

When the /M command is invoked, the command line can also include arguments that display the status of individual outlets, specific pairs of outlets or a range of outlets:

- /M** Displays the Current Metering Status Screen.
- /M s** Displays current, voltage and power readings for an individual plug or outlet, where *s* is the name or number of the desired outlet.
- /M s+s** Displays current, voltage and power readings for two or more specific outlets, where *s* is the number or name of each desired outlet. A plus sign (+) is entered between each outlet number or name.
- /M s:s** Displays current, voltage and power readings for a range of outlets, where *s* is the number or name of the outlet at the beginning and end of the range of desired outlets. A colon (:) is entered between the two outlet numbers or names that mark the beginning of the range and the end of the range.
- /M a** Displays current, voltage and power readings for Branch A.
- /M b** Displays current, voltage and power readings for Branch B.

**Notes:**

- *When current, voltage and power readings are displayed for a single outlet, pair of outlets or range of outlets, readings for each outlet specified will be displayed as three values separated by commas. Current will be displayed first, then voltage, then power.*
- *When the /M command is invoked on an NPS Series unit, current and power readings will not be included. Instead, a zero will be displayed in place of current and power.*

**Availability:** Administrator, SuperUser

**Format:** /M [Enter]

**/AS Alarm Status Screen**

Lists all available user-defined alarms and indicates whether or not each alarm has been triggered as described in Section 9.11. The resulting screen will display "Yes" (or 1) for alarms that have been triggered or "No" (or 0) for alarms that have not been triggered. If desired, the /AS command line can also include an optional alarm argument that will cause the unit to display the status of one individual alarm as shown in the table below:

Alarm Name	Alarm Argument
Over Current (Initial)	OCI
Over Current (Critical)	OCC
Over Temperature (Initial)	OTI
Over Temperature (Critical)	OTC
Open Circuit Breaker	CBO
Lost Communication with Unit	CL
Ping No Answer	PNA
Serial Port Invalid Access Lockout	LO
Power Cycle (Cold Boot)	CB
Plug Current	PC
Lost Voltage (Line In)	VL
No Dialtone	ND
Emergency Shutoff	ES

**Availability:** Administrator

**Format:** /AS [*a*alarm] [Enter]

Where *a*alarm is an optional argument, which can be used to display the status of an individual alarm as shown in the table above.

**/J Display Site ID / Unit Information**

Displays the user-defined Site I.D. message. If the optional asterisk (\*) argument is included in the command line, the command will also show model number, serial number, current rating and software version for the VMR/NPS unit.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /J [\*] [Enter]

Where \* (asterisk) is an optional command argument, that is used to display the model number, current rating and software version for the VMR/NPS unit.

### 17.3.2. Control Commands

#### **/X**      **Exit Command Mode**

---

Exits command mode. When issued at the Network Port, also ends the Telnet session.

**Note:** *If the /X command is invoked from within a configuration menu, recently defined parameters may not be saved. In order to make certain that parameters are saved, always press the [Esc] key to exit from all configuration menus and then wait until "Saving Configuration" message has been displayed and the cursor has returned to the command prompt before issuing the /X command.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /x [Enter]

#### **/C**      **Connect to Serial Port**

---

When the RJ-45 SetUp Port has been configured as a Normal Mode Port as described in Section 6.7, the /C command can be used to create a connection between the Network port and the serial SetUp Port.

**Notes:**

- *User level accounts can only connect to the SetUp Port when serial port access is specifically permitted by the account.*
- *To terminate a port connection, either type ^x ([Ctrl] plus [X]) or invoke the currently defined disconnect sequence.*

**Availability:** Administrator, SuperUser, User

**Format:** /c 1 [Enter]

---

**/BOOT Initiate Boot Cycle**

---

Initiates a boot cycle at the selected plug(s) or Plug Group(s). When a Boot cycle is performed, the VMR/NPS will first switch the selected plug(s) Off, then pause for the user-defined Boot/Sequence Delay Period, then switch the plug(s) back on. The /BOOT command can also be entered as /BO.

**Notes:**

- *When this command is invoked in Administrator Mode or SuperUser Mode, it can be applied to all VMR/NPS plugs and Plug Groups. When this command is invoked in User Mode, it can only be applied to the plugs and/or Plug Groups that have been enabled for the account.*
- *When the /BOOT command is used to reboot more than one plug, the Boot/Sequence Delay Periods will be applied as described in Section 6.6.1.*

**Availability:** Administrator, SuperUser, User

**Format:** /BOOT <s>[,Y] [Enter] or /BO <s> [Enter]

Where:

- s** The number or name of the plug(s) or Plug Group(s) that you intend to boot. To apply the command to several plugs, enter a plus sign (+) between each plug number. To apply the command to a range of plugs, enter the numbers for the first and last plugs in the range, separated by a colon character (:). To apply the command to all plugs allowed by your account, enter an asterisk character (\*).
- ,Y** (Optional) Suppresses the command confirmation prompt.

**Example:**

Assume that your account allows access to Plug A2 and Plug A3. To initiate a boot cycle at Plugs A2 and A3, without displaying the optional command confirmation prompt, invoke either of the following command lines:

**/BOOT A2+A3,Y [Enter] or /BO A2+A3,Y [Enter]**

---

**/ON Switch Plug(s) ON**

---

Switches selected plugs(s) or Plug Group(s) On, as described in Section 5.3. When the /ON command is used to switch more than one plug, Boot/Sequence Delay Period will be applied as described in Section 6.6.1.

**Notes:**

- *When this command is invoked in Administrator Mode or SuperUser Mode, it can be applied to all VMR/NPS plugs and Plug Groups. When this command is invoked in User Mode, it can only be applied to the plugs and/or Plug Groups that have been enabled for the account.*
- *When the /ON command is used to switch more than one plug, the Boot/Sequence Delay Periods will be applied as described in Section 6.6.*

Availability: Administrator, SuperUser, User

**Format:** /ON <s>[ ,Y] [Enter]

Where:

- s** The number or name of the plug(s) or Plug Group(s) that you intend to Switch On. To apply the command to several plugs, enter a plus sign (+) between each plug number. To apply the command to a range of plugs, enter the numbers for the first and last plugs in the range, separated by a colon character (:). To apply the command to all plugs allowed by your account, enter an asterisk character (\*).
- ,Y** (Optional) Suppresses the command confirmation prompt.

**Example:**

Assume that your account allows access to Plug A2 and Plug A3. To switch Plugs A2 and A3 On, without displaying the optional command confirmation prompt, invoke following command line:

**/ON A2+A3,Y [Enter]**



---

**/OFF Switch Plug(s) OFF**

---

Switches selected plugs(s) or Plug Group(s) Off, as described in Section 5.3. When the /OFF command is used to switch more than one plug, Boot/Sequence Delay Period will be applied as described in Section 6.6. The /OFF command can also be entered as /OF.

**Note:** *When this command is invoked in Administrator Mode or SuperUser Mode, it can be applied to all VMR/NPS plugs and Plug Groups. When invoked in User Mode, the command can only be applied to the plugs and/or Plug Groups that are enabled for the account.*

**Availability:** Administrator, SuperUser, User

**Format:** /OFF <s>[,Y] [Enter] or /OF <s>[,Y] [Enter]

Where:

- s The number or name of the plug(s) or Plug Group(s) that you intend to Switch Off. To apply the command to several plugs, enter a plus sign (+) between each plug number. To apply the command to a range of plugs, enter the numbers for the first and last plugs in the range, separated by a colon character (:). To apply the command to all plugs allowed by your account, enter an asterisk character (\*).
- ,Y (Optional) Suppresses the command confirmation prompt.

**Example:**

Assume that your account allows access to Plug A2 and Plug A3. To switch Plugs A2 and A3 on your local VMR/NPS unit Off, without displaying the optional command confirmation prompt, invoke either of the following command lines:

/OFF A2+A3,Y [Enter] or /OF A2+A3,Y [Enter]

---

**/DPL Set All Plugs to Default States**

---

Sets all switched outlets to their user-defined default state. For information on setting outlet defaults, please refer to Section 6.6.

**Note:** *When this command is invoked in Administrator Mode or SuperUser Mode, it will be applied to all VMR/NPS outlets. When invoked in User Mode, the command will only be applied to the plugs that are allowed by the account.*

**Availability:** Administrator, SuperUser, User

**Format:** /DPL[,Y] [Enter]

Where ,Y is an optional command argument, which can be included to suppress the command confirmation prompt.

**/U Send Parameters to File**

---

Sends all VMR/NPS configuration parameters to an ASCII text file as described in Section 15. This allows you to back up the configuration of your VMR/NPS unit.

**Availability:** Administrator

**Format:** /U [Enter]

**/K Send SSH Key**

---

Instructs the VMR/NPS to provide you with a public SSH key for validation purposes. This public key can then be provided to your SSH client, in order to prevent the SSH client from warning you that the user is not recognized when you attempt to create an SSH connection. For more information, please refer to Section 10.

**Availability:** Administrator

**Format:** /K k [Enter]

Where k is a required argument, which indicates the key type. The k argument provides the following options: 1 (SSH1), 2 (SSH2 RSA), 3 (SSH2 DSA.)

**/UL Unlock Port (Invalid Access Lockout)**

---

Manually cancels the VMR/NPS's Invalid Access Lockout feature. Normally, when a series of failed login attempts are detected, the Invalid Access Lockout feature can shut down the network port for a user specified time period in order to prevent further access attempts. When the /UL command is invoked, the VMR/NPS will immediately unlock all network ports that are currently in the locked state.

**Availability:** Administrator

**Format:** /UL [Enter]

**Response:** The VMR/NPS will unlock all VMR/NPS RS232 Ports.

---

**/TELNET Outbound Telnet**

---

Creates an outbound Telnet connection.

**Notes:**

- *In order for the /TELNET command to function, Telnet/SSH and Outbound Service Access must be enabled for your user account as described in Section 6.4. In addition, Telnet Access and Outbound Access must also be enabled via the Network Parameters menu, as described in Section 6.8.1.*
- *If you have logged in via the Network Port, the /TELNET command will not function.*

**Availability:** Administrator, SuperUser, User

**Format:** /TELNET <ip> [port] [raw] [Enter]

Where:

- ip** Is the target IP address. The IP Address can be entered in either IPv4 or IPv6 format.
- port** Is an optional argument which can be included to indicate the target port at the IP address.
- raw** Is an optional argument which can be included to indicate a raw socket connection. In order to create a raw socket connection, the command line must end with the text "raw".

---

**/SSH Outbound SSH**

---

Creates an outbound SSH connection.

**Notes:**

- *In order for the /SSH command to function, Telnet/SSH and Outbound Service Access must be enabled for your user account as described in Section 6.4. In addition, SSH Access and Outbound Access must also be enabled via the Network Parameters menu, as described in Section 6.8.1.*
- *If you have logged in via the Network Port, the /SSH command will not function.*

**Availability:** Administrator, SuperUser, User

**Format:** /SSH <ip> -l <username> [Enter]

Where:

- ip** Is the target IP address. The IP Address can be entered in either IPv4 or IPv6 format.
- l** (Lowercase letter "L") Indicates that the next argument will be the log on name.
- username** Is the username that you wish to use to log in to the target device.

### 17.3.3. Configuration Commands

#### **/F      Set System Parameters**

---

Displays a menu which is used to define general parameters for the VMR/NPS unit. Note that all functions provided by the /F command are also available via the Web Browser Interface. For more information, please refer to Section 6.2.

**Availability:** Administrator

**Format:** /F [Enter]

#### **/P      Set Serial Port Parameters**

---

Displays a menu that is used to select options and parameters for the VMR/NPS's serial Setup Port. Note that all functions provided by the /P command are also available via the Web Browser Interface. Section 6.7 describes the procedure for defining parameters for the serial Setup Port.

**Availability:** Administrator

**Format:** /P [Enter]

#### **/PL     Set Plug Parameters**

---

Displays a menu that is used to select parameters for the VMR/NPS's switched outlets (plugs). All functions provided by the /PL command are also available via the Web Browser Interface. Section 6.7 describes the procedure for defining plug parameters.

**Availability:** Administrator

**Format:** /PL [Enter]

#### **/G      Plug Group Parameters**

---

Displays a menu that is used to View, Add, Modify or Delete Plug Groups. For more information on Plug Groups, please refer to Section 6.5.

**Availability:** Administrator

**Format:** /G [Enter]

**/N Network Port Parameters - IPv4**

---

Displays a menu which is used to select IPv4 parameters for the Network Port. Note that all functions provided by the /N command are also available via the Web Browser Interface. For more information, please refer to Section 6.8.

**Availability:** Administrator

**Format:** /N [Enter]

**/N\* Network Selection Menu - IPv4/IPv6**

---

Displays the Network Selection menu, which is used to access the configuration menus for both IPv4 and IPv6 protocols. All functions provided by the /N\* command are also available via the Web Browser Interface. For more information, please refer to Section 6.8.

**Availability:** Administrator

**Format:** /N\* [Enter]

**/RB Reboot Options**

---

Displays a menu that is used to configure Scheduled Reboots and Ping-No-Answer Reboots. The Scheduled Reboot function can be used to reboot devices connected to the VMR/NPS's switched outlets according to a user-defined schedule. The Ping-No-Answer Reboot function allows the VMR/NPS to automatically reboot user-designated outlets when a user-specified IP address does not respond to a Ping command. For more information on Reboot options, please refer to Section 7.

**Note:** *If desired, the Ping-No-Answer Reboot function can also be configured to send email notification whenever a Ping-No-Answer Reboot is generated. For more information, please refer to Section 8.5.*

**Availability:** Administrator

**Format:** /RB [Enter]

**/AC Alarm Configuration Parameters**

---

Displays a menu that is used to configure and enable the VMR/NPS unit's monitoring and alarm functions. For more information on Alarm Configuration, please refer to Section 8.

**Note:** *Current and Power Metering functions are not available on NPS units.*

**Availability:** Administrator

**Format:** /AC [Enter]

**/I Reboot System (Default)**

---

Reinitializes the VMR/NPS unit and offers the option to keep user-defined parameters or reset to default parameters. As described in Section 6.9.1, the /I command can also be used to restore the unit to previously saved parameters. When the /I command is invoked, the unit will offer the following reboot options:

- Reboot Only (Do NOT default parameters)
- Reboot & Default (Keep IP Parameters & SSH Keys)
- Reboot & Default (Default ALL parameters)
- Reboot & Restore Last Known Working Configuration

**Availability:** Administrator, SuperUser

**Format:** /I [Enter]

**/UF Upgrade Firmware**

---

When new versions of the VMR/NPS firmware become available, this command is used to update existing firmware as described in Section 16.

**Note:** *When a firmware upgrade is performed, it will take about 15 minutes to upgrade the VMR/NPS unit.*

**Availability:** Administrator

**Format:** /UF [Enter]

**/TEST Test Network Parameters**

---

Displays a menu which is used to test configuration of the Syslog and SNMP Trap functions and can also be used to invoke a Ping Command.

**Notes:**

- *In order for the ping command to function with domain names, Domain Name Server parameters must be defined as described in Section 6.8.4.*
- *The Test Menu's Ping command is not effected by the status of the Network Parameters Menu's Ping Access function.*

**Availability:** Administrator

**Format:** /TEST [Enter]

## Appendix A. Specifications

### Physical/Environmental:

#### **VMR-4HS Series:**

Width: 19" (48.3 cm) (Including Rack Brackets)

Depth: 6.5" (16.5 cm)

Height: 1.75" (4.5 cm) One Rack U

#### **VMR-8HS Series, VMR-8HD Series, VMR-HD4D Series, NPS-8HS Series, NPS-8HD Series, NPS-8H20-ATS Series:**

Width: 19" (48.3 cm) (Including Rack Brackets)

Depth: 8.7" (22.1 cm)

Height: 1.75" (4.5 cm) One Rack U

#### **VMR-HD4D-8 Series:**

Width: 19" (48.3 cm) (Including Rack Brackets)

Depth: 12.25" (31.1 cm)

Height: 3.5" (8.9 cm) Two Rack U

#### **VMR-16HD Series, VMR-HD4D-12B Series, NPS-16HD Series:**

Width: 19" (48.3 cm) (Including Rack Brackets)

Depth: 8.7" (22.1 cm)

Height: 3.5" (8.9 cm) Two Rack U

**Operating Temperature:** 32°F to 122°F (0°C to 50°C)

**Humidity:** 10 - 90% RH

## Appendix B. Interface Descriptions




Figure B.1: RS232 SetUp Port Interface

### B.1. SetUp Port (RS232)

DCD and DTR hardware lines function as follows:

1. **When connected:**

- If either port is set for Modem Mode, the DTR output at either port reflects the DCD input at the other end.
- If *neither* port is set for Modem Mode, DTR output is held high (active).

2. **When not connected:**

- If the port is set for Modem Mode, upon disconnect DTR output is pulsed for 0.5 seconds and then held high.
- If the port is *not* set for Modem Mode, DTR output is controlled by the DTR Output option (Serial Port Parameters Menu, Option 23). Upon disconnect, Option 23 allows DTR output to be held low, held high, or pulsed for 0.5 seconds and then held high.



## Appendix C. Customer Service

Customer Service hours are from 8:00 AM to 5:00 PM, PST, Monday through Friday. When calling, please be prepared to give the name and make of the unit, its serial number and a description of its symptoms. If the unit should need to be returned for factory repair it must be accompanied by a Return Authorization number from Customer Service.

WTI Customer Service  
5 Sterling  
Irvine, California 92618

Local Phone: (949) 586-9950  
Toll Free Service Line: 1-888-280-7227  
Service Fax: (949) 583-9514

Email: [service@wti.com](mailto:service@wti.com)

### **Trademark and Copyright Information**

---

WTI and Western Telematic are trademarks of Western Telematic Inc.. All other product names mentioned in this publication are trademarks or registered trademarks of their respective companies.

Information and descriptions contained herein are property of Western Telematic, Inc.. Such information and descriptions may not be copied, disseminated, or distributed without the express written consent of Western Telematic Inc..

© Copyright Western Telematic Inc., 2017.

July, 2017

Part Number: 14102, Revision: K

### **Trademarks and Copyrights Used in this Manual**

Cisco and EnergyWise are registered trademarks of Cisco Systems, Inc.

ProComm is a trademark of Datastorm Technologies, Inc™.

Teraterm is a copyright of Ayera Technologies, Inc.

JavaScript is a trademark of Sun Microsystems, Inc.

Telnet is a trademark of Telnet Communications, Inc.

All other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.